



## imperii Espia Motion Sensor Spy Clock User Manual

[Home](#) » [imperii electronics](#) » imperii Espia Motion Sensor Spy Clock User Manual

### imperii Espia Motion Sensor Spy Clock User Manual



#### Contents [ [hide](#) ]

- [1 Product Instructions](#)
- [2 Operating Instructions](#)
- [3 Limited Warranty](#)
- [4 Related Posts](#)

### Product Instructions

This table clock is the first HD digital product that can take photos and record videos while charging; the features include detection mode, recording video, taking photos and storage in TF (Micro SD) card. The Desktop Clock with motion detector can take photos and record HD videos. This practical and decorative design clock will help

you monitor your home and know what has happened during your absence.

## Operating Instructions

Status Indicator: the LED status indicator of the clock is visible on the dial. On: The LED lights come on when you turn on the clock. Off: The indicator lights flash 3 times and then turn off. USB Indicator: Connect it to your computer, both indicators will turn on while the computer disk is writing or reading files, the green light will come on and the red light will start flashing. Charge indicator: The green indicator light will come on and the red light will blink while charging, once it is charged both indicators stay lit. Video indicator: Prepares the camera, the green light will flash 6 times, then it will turn off, indicating that it is recording if the video is paused, the green light will turn back on. Photo indicator: The green light will flash once to take the picture, if it stays on, it will be in standby mode. Motion detector indicator: Both indicators will flash 6 times. Low battery indicator: Both indicators will flash at the same time and the system will turn off.

### 1. Buttons:

K1 (3): Press the button to turn the camera on and off.

K2 (4): Press this button to take pictures, to begin the motion detector mode.

A3: USB Connection (1): It is used to charge or connect it to the computer. It is the intermediary to transfer and charge data from the card. The connection by card (2) is used to save the files of photos and videos.

A4. Clock setting button. It is used to set the time

B: ON/OFF button

### 2. On:

When the unit is off, press for a long time the K1 start button, the camera indicator will turn on (the blue and red light will come on at the same time).

### 3. Off:

You can turn off both the standby and work mode (as long as it is not charging), press the K1 button for a long period of time, the machine automatically saves the files and will turn off (the LED lights will turn on and off simultaneously), if the machine is not in any mode of work, it will turn off after 30 seconds.

### 4. Camera mode:

When the clock is in Standby mode, press the K1 button for a short time and a blue light will blink 6 times in the camera, to save it, press the K1 button quickly.

### 5. Video Camera mode:

When the clock is in Standby mode, press the K2 button for a short time, the blue light will blink once and it will stay lit.

### 6. Voice mode:

When the unit is in Standby mode, press the K2 button for a long time, the light will blink 6 times to enter into VOICE mode. When the sound reaches 60db, it will mute every two minutes to save the files. The sound does not come from the camera.

### 7. Webcam:

When the unit is in Standby mode, press the K2 button for a long time, without sharing files with your computer. Once connected to your computer it opens the folders "My Computer" and "USB Video Device". Double click to enter the Webcam mode after the process is complete. (Please be patient waiting for a response from the computer).

### 8. Charger:

Equipped with a USB cable to charge it by connecting it to the computer USB interface, when the battery is

charging the green light will turn on, the red light will flash, and when it is complete, the green light will shine and the red light will turn off completely.

**NOTE:** the camera integrates a high-capacity lithium battery, it has no memory effect, it can be used with the battery, but the initial use of the battery charge is 5 times, then, the battery will work saturated. To activate the maximum capacity of the battery, works in the standard form, so that you increase the capacity. Leave it charging for 30-60 minutes once the maximum battery charge is indicated.

#### 9. Different processing guidelines:

If the battery is running low, the lights will flash rapidly for 3 seconds and all the files will be automatically saved and it will turn off, if you want to continue using the clock, please charge it.

The camera will stop working when they improper operations or other special reasons occur, while pressing the K1 and K2 buttons.

When the K1 and K2 buttons are pressed simultaneously, the clock will turn off. No video is recorded if the card is badly positioned or damaged. If it is not connected to the computer, make sure it has the drivers, USB interface properly connected and the card is not damaged.

**NOTE:** Depending on the configuration of your computer may take a little longer to respond. In order to avoid it not recognizing the identification hardware of the computer for a long period of time, try to connect it again until it can recognize the hardware, make sure that your operation with the system, drivers and USB interface has a good connection

#### 10. Security System:

This product is not professional file storage; we do not guarantee the internal storage of files, for a better security save your files in other storage means, prepared to make backups.

It works in temperatures between 0-40 ° C and 20% to 80%, do not use the product in damp places, this product does not have submersible functions. Light shot. Please do not use the camera directly as a lamp so that the light is not damaged.

**IMPORTANT NOTICE:** According to the regulations and legislation of each country, recording images without permission of the owner (people, audiovisual works, etc.) may constitute a crime. Please make sure you can record images or audio (of a conversation, a listening, an advertisement, etc.) having the consent of the person or the author. IMPERII ELECTRONICS and its authorized distributors are not liable for any misuse or fraudulent use that may be made of their products.

### Limited Warranty

This product is warranted for two years from the time of its purchase.

The warranty comes into force at the time of submission of the commercial invoice of the establishment properly filled and sealed.

If there is a problem with the product, the user must contact IMPERII ELECTRONICS at [sat@imperielectronics.com](mailto:sat@imperielectronics.com). Once received, the doubts, incidents and problems will be solved by email. If this is not possible and the problem persists, the warranty will be processed in accordance with the applicable law. The warranty is extended to 2 years, referring only to manufacturing defects.

The shipping to the nearest technical service or to our headquarters must be carried out with prepaid postage.

The article must arrive well packaged and with all its components.

We deny any responsibility for data that may arise from misuse of the product. The warranty does not apply in the following cases:

1. If the instructions have not been followed correctly
2. If the product has been tampered with
3. If it has been damaged by improper use


4. If the defects have arisen as a result of faults in the electrical supply

PRODUCT \_\_\_\_\_

MODEL \_\_\_\_\_

SERIES \_\_\_\_\_

TECHNICAL SERVICE: <http://www.Imperiielectronlcs.com/contactenos>



imperii Espia Motion Sensor Spy Clock User Manual – [Download \[optimized\]](#)

imperii Espia Motion Sensor Spy Clock User Manual – [Download](#)

imperii Espia Motion Sensor Spy Clock User Manual – [OCR PDF](#)