Inateck BK2007-RGB Keyboard



Inateck BK2007-RGB Keyboard Instruction Manual

Home » inateck » Inateck BK2007-RGB Keyboard Instruction Manual



Contents


- 1 Inateck BK2007-RGB
- **Keyboard**
- **2 Product Diagram**
- 3 Bluetooth Pairing
- 4 Adjust the Keyboard Backlight
- **5 Shortcut Keys**
- **6 LED Indicator**
- **7 Restore Factory Defaults**
- **8 Check Battery Level**
- 9 Charging
- 10 Sleep Mode
- 11 Product Specification
- 12 Packing List
- 13 Documents / Resources
 - 13.1 References



Inateck BK2007-RGB Keyboard



Product Diagram



Bluetooth Pairing

- 1. **Step 1:** For first-time use, snapping the protective case onto the magnetic strip will cause the keyboard to turn on and enter Bluetooth pairing mode automatically. In future use, please press to enter Bluetooth pairing mode. The Bluetooth indicator will blink once it enters pairing mode successfully.
- 2. **Step 2:** On the iPad, select Settings>Bluetooth>On and then "Inateck BK2007-RGB" will show up in "Other Devices"
- 3. **Step 3:** Tap "Inateck BK2007-RGB" to pair it with your iPad and then the Bluetooth indicator will stay solid in seconds, which means that Bluetooth pairing is completed.

Fix Bluetooth Pairing Problems

1. **Step 1:** Go to Settings > Bluetooth, find "Inateck BK2007-RGB" in My Devices tap the info button it, then tap Forget This Device. If there are multiple pairing records related to the keyboard, please clear all of them.

- 2. **Step 2**: Hold simultaneously for 3 seconds and then three indicators will blink for 3 times once the factory reset is completed.
- 3. Step 3: Pair it with your Inateck BK2007-RGB

Adjust the Keyboard Backlight

- 1. Hold fn + simultaneously to adjust the backlight colour. 7 colours are available in total.
- 2. Hold fn simultaneously to adjust the backlight brightness. 3 levels are at your choice.

Shortcut Keys

| esc | Undo | ·: | Brightness- | | Brightness+ |
|-------------------------------|------------|-------------|-------------------|---------------------------------|------------------------|
| Q | Search | X | Take a screenshot | (1) | Switch keyboard layout |
| $\triangleleft \triangleleft$ | Last track | DII | Play/Pause | $\triangleright \triangleright$ | Next track |
| | Mute | □ () | Volume- | □ ()) | Volume+ |
| | Lock | del | Delete | | |

Common Keyboard Shortcuts

| ₩+X | Cut | ₩+C | Сору | ₩+V | Paste |
|-------|------------------------|---------|--------|---------------|------------------------|
| ₩+A | Select all | ₩+Space | Search | control+Space | Switch keyboard layout |
| 第+Tab | Switch between Apps | | | | |

LED Indicator

| Indicator | Status | Meaning | |
|---------------------------------|-------------------|---------------------------------|--|
| Canalaskindisator | White Light Solid | Caps Lock on | |
| Caps Lock Indicator | White Light Off | Caps Lock off | |
| | Fast blinking | Bluetooth Pairing | |
| Bluetooth Indicator | Off | Bluetooth unconnected | |
| Bluetooth malcator | Solid | Bluetooth connected | |
| | Breathing | Bluetooth Reconnecting | |
| Pattery Indicator Dod | Blinking | Non-Charging: Battery level<20% | |
| Battery Indicator - Red | Solid | Charging | |
| Battery Indicator - Green Solid | | Fully charged | |

Restore Factory Defaults

Check Battery Level

Hold + simultaneously to check the battery level according to the blinking frequency of the red battery indicator.

| Blinkina Frequency | Battery Level |
|--------------------|---------------|
| Once | 0-25% |
| Twice | 25%-50% |
| Three Times | 50%-75% |
| Four Times | 75%-100% |

Charging

When the battery level is under 20%, the battery indicator will blink in red. Please use the included USB cable to recharge the keyboard in time. The recommended charging voltage and current are 5V and 200mA respectively. The keyboard will be fully charged in 3 hours. The red battery indicator will stay solid when the keyboard is charging. Once it's fully charged, the green battery indicator will stay solid.

Sleep Mode

- 1. When BK2007-RGB is left idle for 1 minute, the backlight will turn off.
- 2. When BK2007-RGB is left idle for 30 minutes, it will enter sleep mode and the Bluetooth connection will be disrupted. The connection can be rebuilt with a press of any key.

Product Specification

| Bluetooth Range | 10m |
|--------------------------------|--------------|
| Charging Time | About 2~3 h |
| Operating Time (Backlight on) | About 5h |
| Operating Time (Backlight off) | About 105h |
| Operating Temperature | -10° -55° |
| Bluetooth Frequency Range | 2402-2480MHz |
| Actuation Force | 60 ± 10 g |
| Battery Capacity | 500mAh |

Packing List

• BK2007-RGB*1

- Charging Cable *1
- Instruction Manual *1

FCC Note

This device complies with part 15 of the FCC Rules.

Operation is subject to the following two conditions:

- 1. This device may not cause harmful interference, and
- 2. this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the Users, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- · Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Note: The Grantee is not responsible for any changes or modifications not expressly approved by the party responsible for compliance. such modifications could void the user's authority to operate the equipment.

The device has been evaluated to meet general RF exposure requirements. This equipment complies with FCC's RF radiation exposure limits set forth for an uncontrolled environment. This device and its antenna(s) must not be co-located or in conjunction with any other antenna or transmitter.

EU Declaration of Conformity

Inateck Co., Ltd. hereby declares that this device complies with the Directive 2014/53/EU . A copy of the Declaration of Conformity can be accessed from https://www.inateck.de/pages/euro-compliance.

Service Center

Europe

- F&M Technology GmbH
- **Tel**: +49 341 5199 8410 (Working day 8 AM 4 PM CET)
- Fax: +49 341 5199 8413
- Address: Fraunhoferstraße 7, 04178 Leipzig, Deutschland

North America

- Inateck Technology Inc.
- Tel: +1 (909) 698 7018 (Working day 9 AM − 5 PM PST)

• Address: 2078 Francis St., Unit 14-02, Ontario, CA 91761, USA

Manufacturer

Shenzhen Inateck Technology Co., Ltd. Address: Suite 2507, Block 11 in Tian An Cloud Park, Bantian Street, Longgang District, Shenzhen, Guangdong, China

Documents / Resources



Inateck BK2007-RGB Keyboard [pdf] Instruction Manual BK2007-RGB, BK2007-RGB Keyboard, Keyboard

References

User Manual

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.