



inateck KB04111 Bluetooth Keyboard Case Instruction Manual

[Home](#) » [inateck](#) » inateck KB04111 Bluetooth Keyboard Case Instruction Manual 

Contents

- [1 inateck KB04111 Bluetooth Keyboard Case](#)
- [2 Bluetooth Pairing](#)
- [3 Multi-Touch Gestures](#)
- [4 Shortcut Keys](#)
- [5 LED Indicator](#)
- [6 charging](#)
- [7 Sleep Mode](#)
- [8 Product Specification](#)
- [9 Packing List](#)
- [10 Service Center](#)
- [11 Documents / Resources](#)
- [12 Related Posts](#)

inateck®

inateck KB04111 Bluetooth Keyboard Case



Product Information

The product complies with Part 15 of the FCC Rules and has been evaluated to meet general RF exposure requirements. The device can be used in portable exposure condition without restriction. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, the user is encouraged to try to correct the interference by one or more of the following measures:



- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Product Usage Instructions

To use the product, follow these instructions:

1. Ensure that the product is placed in a position that does not cause any interference to radio or television reception.
2. If interference occurs, try reorienting or relocating the receiving antenna, increasing the separation between the equipment and receiver, or connecting the equipment into an outlet on a circuit different from that to which the receiver is connected.
3. If interference persists, consult the dealer or an experienced radio/TV technician for help.
4. When using the product in a portable exposure condition, there are no restrictions on usage.

Bluetooth Pairing

- Step 1: Put the iPad case on and slide the keyboard switch to the On position. Hold down  +  simultaneously and then the keyboard will enter pairing mode with a blinking blue indicator light.
- Step 2: On your iPad, go to Settings > Bluetooth, turn on Bluetooth and then “Inateck KB04111” will show up in “Other Devices” .

- Step 3: Tap “Inateck KB04111” to pair it with your iPad. The Bluetooth indicator will go off in seconds which means that Bluetooth pairing is completed

Note:

Set Up Your iPad:

For better user experience, please follow steps below to set up your iPad at first use once Bluetooth pairing is completed.

- Go to Settings > General > Trackpad and drag the slider to the middle of the tracking speed.
- Go to Settings > General > Trackpad and turn on “Tap to Click” and “Two Finger Secondary Click”
- Go to Settings > Accessibility > Touch and turn off AssistiveTouch.
- Go to Settings > General > Gestures and enable the toggle for the “Four and Five Finger Swipe” setting.

Optional Settings



Steps to stop Caps Lock changing your keyboard language:

Go to Settings > General > Keyboard > Hardware Keyboard and turn off Switch Languages using Caps Lock.

Steps to disable the double tap period shortcut:

Go to Settings > General > Keyboard > Hardware Keyboard and click the switch to turn on 66 99 Shortcut.





Fix Bluetooth Pairing Problems:

- Step 1: Go to Settings > Bluetooth, find “Inateck KB04111” in My Devices and tap the info button i next to it, then tap “Forget This Device” . If there are multiple pairing records related to the keyboard, please clear all of them.
- Step 2: Hold  +  simultaneously for 3 seconds and then the three indicators will blink for 3 times once the factory reset is completed.
- Step 3: Pair your Inateck KB04111 with your iPad




Multi-Touch Gestures

	Drag: Click and hold the item until it lifts up and drag it to another location with another finger.		Scroll: Slide two fingers up or down to scroll.
	Swipe: Swipe left or right with two fingers.		Zoom in or out: Pinch with two fingers to zoom in or out.
	Secondary click: Click or tap with two fingers.		Show desktop: Swipe up with three fingers.
	App Exposé: Swipe up with three fingers and pause.		Swipe between full-screen apps: Swipe left or right with three fingers.

Adjust the Keyboard Backlight


1. Hold  +  simultaneously to adjust the backlight color. 7 colors are available in total.
2. Hold  +  simultaneously to adjust the backlight brightness. 3 levels are at your choice.

Shortcut Keys

esc	Undo/Exit		Brightness-		Brightness+
	Search		Take a screenshot		Switch keyboard layout
	Last track		Play/Pause		Next track
	Mute		Volume-		Volume+
	Lock				

Common Keyboard Shortcuts



 + X	Cut	 + C	Copy	 + V	Paste
 + A	Select all	 + Space	Search	control+Space	Switch keyboard layout
 + Tab	Switch between Apps				

Tip: Hold the  key to see a list of shortcuts that you can use with an app, excluding the top row shortcuts.



LED Indicator

Indicator	Status	Meaning
Indicator 1	Solid	Caps Lock on
	Off	Caps Lock off
Indicator 2	Blinking	Bluetooth Pairing
	Off	Bluetooth connected or unconnected
Indicator 3 - Red	Blinking	Low battery
	Solid	Charging
Indicator 3 - Green	Solid	Fully charged

Restore Factory Defaults

Hold  +  simultaneously for 3 seconds and then the three indicators will blink for 3 times once the factory reset is completed.

Check Battery Level

Hold  +  simultaneously to check the battery level according to the blinking frequency of the red battery indicator.

Blinking Frequency	Battery Level
Once	0-25%
Twice	25%-50%
Three Times	50%-75%
Four Times	75%-100%

charging

When the battery level is under 20%, the battery indicator will blink in red. Please recharge the keyboard in time. The recommended charging voltage and current are 5V and 250mA respectively. To recharge the keyboard, you can connect the included USB cable to the charger of your cellphone or the USB port of a computer. The keyboard will be fully charged in 2-3 hours. The indicator will stay in red when the keyboard is charging and turn green when it's fully charged,

Sleep Mode

1. When KB04111 is left idle for 1 minutes, the backlight will turn off.
2. When KB04111 is left idle for 30 minutes, it will enter sleep mode and the Bluetooth connection will be disrupted. The connection can be rebuilt with a press of any key.
(**Note:** Tapping the trackpad cannot wake up the keyboard.

Product Specification

Bluetooth Version	Bluetooth 5.3
Bluetooth Range	10 m
Charging Time	2-3h
Operating Current (Backlight on)	About 5h
Operating Current (Backlight off)	About 55h
Operating Temperature	-10°C ~ +55°C
Bluetooth Frequency Range	2402-2480MHZ
Actuation Force	60 ± 10g
Battery Capacity	500mAh

Packing List

- KB04111 •1
- Charging Cable• 1
- Instruction Manual •1

EU Declaration of Conformity

Inateck Co., Ltd. hereby declares that this device complies with the Directive 2014/53/EU.

A copy of the Declaration of Conformity can be accessed from <https://www.inateck.de/pages/euro-compliance>.

Service Center

Europe

F&M Technology GmbH

Tel: +49 341 5199 8410 (Working day 8 AM – 4 PM CET)

Fax: +49 341 5199 8413

Address: Fraunhoferstraße 7, 04178 Leipzig, Deutschland

North America

Inateck Technology Inc.

Tel: +1 (909) 698 7018 (Working day 9 AM – 5 PM PST)

Address: 2078 Francis St., Unit 14-02, Ontario, CA 91761, USA

EC REP

F&M Technology GmbH

Fraunhoferstraße 7, 04178 Leipzig, Deutschland

Tel: +49 341 5199 8410

UK REP

Inateck Technology (UK) Ltd.

95 High Street, Office B, Great Missenden, United Kingdom, HP16 0AL


Tel: +44 20 3239 9869

Manufacturer

Shenzhen Inateck Technology Co., Ltd.

Address: Suite 2507, Block 11 in Tian An Cloud Park, Bantian

Documents / Resources

	inateck KB04111 Bluetooth Keyboard Case [pdf] Instruction Manual KB04111 Bluetooth Keyboard Case, KB04111, Bluetooth Keyboard Case, Keyboard Case, Case
---	--