

INBOX ZERO

COMPUTER DESK WITH TWO DRAWERS AND SIDE-SHELF



USER MANUAL

Contents [[hide](#)]

- [1 Safety Instructions](#)
- [2 Disassembly Diagram](#)
- [3 Parts List](#)
- [4 Assembly Instructions](#)
- [5 Customer Service](#)
- [6 Problems You May Encounter](#)
- [7 Documents / Resources](#)
 - [7.1 References](#)

Safety Instructions

Thank You For Choosing Our Product

Before assembly, please read this USER MANUAL first, and check according to Parts List to make sure all parts are included.

Feel free to contact us if you have any concerns or questions about your product, we are always ready to help. Your satisfaction is our first priority!

Precautions



- Avoid long-term direct sunlight exposure.



- Keep away from sharp objects.



- Keep away from heat.



- Keep infants/children away from assembly parts to avoid choking and suffocation.




- Keep away from corrosive substances.



- Pay attention to avoid over-tightening fasteners, or they may induce cracking within the board.

Disassembly Diagram



Parts List

For ease and safety, we recommend two people for assembly.



A x1 	B x1 	C x2 	D x2
F x1 	G x2 	I x1 	J x1
K x1 	L x1 	M x2 	N x2
O x1 	P x2 	Q x2 	

1 x7  1 Spares	2 x14  M6x10 2 Spares	3 x5  M6x20 1 Spares	4 x23  M6x28 3 Spares
5 x5  ST4x14 1 Spares	6 x3  ST4*10 1 Spares	7 x9  ST6x50 1 Spares	8 x5  1 Spares
9 x2  1 Spares	10 x1  	11 x1  	12 x1 
13 x2  1 Spares	14 x1  		

Assembly Instructions







Attention: The shelves can be installed on either side, you can choose one instruction as you prefer.

1R-14R: Drawers on the right side.



1L-14L: Drawers on the left side.







R-5


1. Please note the position of the screw holes when assembling.
2. When installing, please be careful not to completely tighten the screws, just tighten them by 70%~80%. Tighten them completely at step 8.

3. Please note the position and direction of the screw holes indicated by the green arrows when assembling.




R-7

Please note the baffle at the end of part L needs to be in the same direction as the screw holes indicated by the green arrows.



**R-8**

Please note to distinguish the front and back of part M when assembling.




R-9


Please pay attention to the strength you use when tightening the screws. Do not use too much force in case the screws break the desktop.

**R-10**

R-11




R-12




x2



R-13




R-14





L-1



L-2







L-5



1. Please note the position of the screw holes when assembling.
2. When installing, please be careful not to completely tighten the screws, just tighten them by 70%~80%. Tighten them completely at step 8.
3. Please note the position and direction of the screw holes indicated by the green arrows when assembling.

L-5





L-6





L-9


Please pay attention to the strength you use when tightening the screws. Do not use too much force in case the screws break the desktop.

**L-10**


L-11



L-12



L-13





Customer Service

1-Year Warranty



We guarantee your product is free from defects in product material and workmanship for one (1) year starting from the date of purchase during normal use of household conditions.

If your appliance fails to operate properly within our warranty period, we will arrange a new one.

Replacement is free and all shipping costs are covered.

Quick Response within 24 Hours



If you are still unable to resolve the issue you are experiencing, please contact us immediately via our support email. It doesn't matter if the product has been installed or not, our customer support team will respond within 24 hours and assist you quickly and efficiently. The most efficient way to confirm your problem to us is to attach a video, which illustrates your product issues.

Problems You May Encounter

PART	PROBLEM	SOLUTION
Whole Product	Parts are missing, defective or having wrong parts in package.	You can contact us and we will get back to you within 24 hours. Or, you can reach us via after-sales email.
	Having issue(s) while reading the instruction or completing the assembly.	You can contact us and we will get back to you within 24 hours. Or, you can reach us via after-sales email.
	Encountering non-human caused damage during usage.	If the product is damaged due to non-human causes, please keep the product and send us photos of it. We will ascertain the cause of the product damage within 48 hours and provide you with a satisfactory solution.
Table Surface	Board Surface is broken, scratched or lack of some screw holes.	You can contact us and we will get back to you within 24 hours. Or, you can reach us via after-sales email.
	The screw holes that on the board and the steel frame don't line up.	1. Please tighten the screws on the board by 70%, do not tighten completely. 2. Adjusting board and steel frame until the screw holes are lined up, then tighten all the screws.
	The desk board is uneven or not tight that has gaps after being assembled.	1. Loosen the screws in the uneven or gap positions; adjust until the desktops are flat and tight, and then tighten the screws. 2. If your problem still can't be solved, please feel free to contact us.

Steel Frame	The steel frame is bent, broken, painted, rusted or damaged.	You can contact us and we will get back to you within 24 hours. Or, you can reach us via after-sales email.
	The table is unstable after being assembled.	1. Check if the screws are tightened. 2. Read throughout the manual, check are there any parts installed incorrectly or missing assembled. 3. If your problem still can't be solved, please feel free to contact us.
	Encountering non-human caused damage during usage.	If the product is damaged due to non-human causes, please keep the product and send us photos of it. We will ascertain the cause of the product damage within 48 hours and provide you with a satisfactory solution.

Documents / Resources

	Inbox Zero CGES1020 Rodenal Computer Desk [pdf] Installation Guide CGES1020, 20240921, CGES1020 Rodenal Computer Desk, CGES1020, Rodenal Computer Desk, Computer Desk
---	--

References

- [User Manual](#)

📁 Inbox

Zero

🔍 20240921, CGES1020, CGES1020 Rodenal Computer Desk, Computer Desk, Inbox Zero, Rodenal Computer Desk

—

Leave a comment

Your email address will not be published. Required fields are marked *

Comment *

Name

Email

Website

☐ Save my name, email, and website in this browser for the next time I comment.

Post Comment

Search:

e.g. whirlpool wrf535swhz

Search

[Manuals+](#) | [Upload](#) | [Deep Search](#) | [Privacy Policy](#) | [@manuals.plus](#) | [YouTube](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.