

INFINITY Camping Table User Manual

Contents

- 1 Camping Table**
 - 1.1 Camping Table**
 - 1.2 Safety Notices**
 - 1.3 Basic precautions**
 - 1.4 Cleaning and Storage**
 - Instructions**
 - 1.5 Specifications**
 - 1.6 Instructions**
 - 1.7 Service and Warranty**
- 2 Documents / Resources**
 - 2.1 References**
- 3 Related Posts**

Camping Table

INFINITY
G O O D S

Camping Table



User Manual 1.

Please keep the manual in a safe place and read it carefully before using it.

Safety Notices

These “Safety Notices” are designed to prevent injury and damages to customers and third parties. Indicates precautions to be followed for safe use of this product.

Basic precautions

- Keep packaging out of children’s reach to avoid suffocation risks.

- Carefully read this manual before assembly and use.
- Do not let children or individuals with physical, sensory, or mental disabilities assemble this table without supervision.
- Do not use the table if it or any of its parts are damaged. Contact customer service for assistance.
- Place the table only on flat, horizontal surfaces. Avoid heat sources, vertical, slanted, or vibrating surfaces.
- Do not use the table as a chair or stool. Ensure children do not climb on or into it.
- Ensure the locking system is securely tightened before use. Only use the table if it is stable and sturdy.
- The table is waterproof and suitable for indoor and outdoor use.
- Check that the legs are fully closed and locked against the bottom before folding the table.
- Use the handle to move the table when folded.

Cleaning and Storage Instructions

- Clean the table with a damp, clean cloth. Avoid using abrasive or aggressive cleaning agents.
- Store the table in a clean, dry place. Do not expose it to extreme temperatures.

Specifications

Weight	3.8 kg
Size	80 x 60 x 70 cm
Material	HDPE Plastic Aluminum frame
Suited for	2-4 Persons

Instructions

1. Position the table face down on a flat surface.
2. Extend the legs.
3. Lock the joints by sliding them into the correct position.


4. Turn the table upright.
5. To fold the table, reverse the above steps.

Service and Warranty

Infinity Goods offers a 2-year warranty on its products. To receive service during the warranty period, you must return the product with proof of purchase. Product defects must be reported within 2 years from the purchase date. This warranty does not cover:

- Damages caused by misuse or improper repair
- Parts subject to normal wear and tear
- Defects that were known to the customer at the time of purchase
- Damages or defects resulting from customer neglect
- Damages or defects caused by third parties

Documents / Resources

 The icon shows the Infinity logo at the top, followed by the text 'INFINITY Camping Table' and 'User Manual 1. Get to know the table'. Below the text is a small line drawing of a camping table. <p>INFINITY Camping Table [pdf] User Manual Camping Table, Table</p>	
---	--

References

- [User Manual](#)

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.