



InfinityLab Instantgo 5000 Built-In Lightning Cable User Guide

[Home](#) » [InfinityLAB](#) » InfinityLab Instantgo 5000 Built-In Lightning Cable User Guide 



Instantgo 5000 Built-In Lightning Cable User Guide




Contents


- [1 WHAT'S IN THE BOX](#)
- [2 CHARGE YOUR DEVICES](#)
- [3 RECHARGE YOUR POWERBANK](#)
- [4 CHARGE & RECHARGE
SIMULTANEOUSLY](#)
- [5 BATTERY INDICATION](#)
- [6 Documents / Resources](#)
- [7 Related Posts](#)




WHAT'S IN THE BOX




CHARGE YOUR DEVICES



RECHARGE YOUR POWERBANK




CHARGE & RECHARGE SIMULTANEOUSLY





BATTERY INDICATION



To protect battery lifespan, fully charge at least once every 3 months.
Battery life will vary due to usage patterns and environmental conditions.


Model	ILING5000L
Battery type	Lithium-ion Polymer 18.65 Wh
Operating temperature	0~45 °C
Lightning in	5 V 2.4 A
Lightning out	5 V 3 A, 9 V 2 A
Total Output	18 W Max.
Battery charge time	3 hours (5 V 2.4 A)
Dimension	139.6 mm x 71 mm x 12 mm/ 5.5" x 2.8" x 0.47"
Weight	160 g/ 0.35 lbs

IOT_INFINTY_InstantGo 5000 Battery_Lightning_QSG_Global_CR_V11



5503000015651

Documents / Resources



[Infinitylab Instantgo 5000 Built-In Lightning Cable](#) [pdf] User Guide
Instantgo 5000 Built-In Lightning Cable, Instantgo 5000, Built-In Lightning Cable