



Inkeltech RL-480 Ring Light Kit Instruction Manual

[Home](#) » [Inkeltech](#) » Inkeltech RL-480 Ring Light Kit Instruction Manual 

Contents

- [1 Inkeltech RL-480 Ring Light Kit](#)
- [2 Instructions for the Use of Ring Light](#)
- [3 Technical data](#)
- [4 Controls on the rear panel](#)
- [5 Operation instruction](#)
- [6 Included in delivery](#)
- [7 Warranty/service](#)
- [8 Instructions for the Use of Tripod Ballhead](#)
- [9 FREQUENTLY ASKED QUESTIONS](#)
- [10 VIDEO – PRODUCT OVERVIEW](#)
- [11 References](#)




Inkeltech RL-480 Ring Light Kit




Instructions for the Use of Ring Light

Installation of Light stand



The legs are designed upwards, please unfold the legs upside down

Installation of Smartphone



1. Loosen the screw at the end of the ring light
2. Attach the ring light to the top of light stand and tighten the screw again.
3. Install the phone holder on the ring light
4. Clip your smartphone on the phone holder, connect the selfie remote with your phone



1. Adjust the Brightness of the light
2. Warm light
3. Change the light tone
4. Cold light


Technical data

Model	RL-480
Input power	110V/240V 50Hz
Output power,	60W
Adjustment range	Stepless adjustment
Color temperature	3000K~6000K(± 200 K)
Dimensions (mm)	Internal diameter 315 mm, outer diameter 455 mm. Thickness 35 mm

Controls on the rear panel



Front View



Operation instruction

- Please take out the light from the bag. plug in the power line, and connect to a power outlet.
- Turn the left knob and adjust the Power from 0% to 100%. Adjust conversely and turn to the end counterclockwise to switch off the light.
- 3.3 Adjust the right knob to change the color temperature. The color temperature ranges from 3000K to 6000K.

Caution!

- Please protect the device from impacts, humidity, dirt, marked temperature fluctuations and direct sunlight. & Do not drop the device
- Please do not touch the light and do not let the device be exposed to rain or moisture to avoid a short circuit
- Please be careful with handling the light during and after use, as the device may be hot, and you could burn

yourself!

Included in delivery

No	Name	Qty
1	RLSeries light Body	1
2	Selfie Controller	1
3	Adapter	1
4	Bag	1
5	Instruction	1
6	Ball Head	1
7	Mobile phone clip	1
8	Tripod	1
9	Remote Control	1

Warranty/service

In case of a claim under the warranty, please contact your local distributor. In case of returning the unit please add a copy of your receipt and a short report of the defect. The following warranty terms shall apply:

1. The warranty period for this product is 1 year from the date of purchase. In case of a warranty claim, the date of purchase has to be proven using the sales receipt or invoice.
2. Repairs (complete unit or parts of the unit) do not extend the warranty period.
3. The warranty shall not be valid for damages because of
 - Improper treatment, e.g. nonobservance of the user instructions
 - repairs or tampering by the customer or unauthorised third parties
 - transport from the manufacturer to the consumer or during transport to the service centre
 - The warranty shall not be valid for accessories, which are subject to normal wear and tear (cuff, batteries, etc.)
4. Liability for direct or indirect consequential losses caused by the unit is excluded even if the damage to the unit is accepted as a warranty claim.



- **ON/OFF:** Connect either the AC adapter cable to DC socket or SONY NP-F750I970 batteries to supply power for the lamp. Press the Power dimmer knob. and then use the remote control to adjust the lamp. Night Mode: 4% Luminance (brightness)
- **Color Temperature -:** Dimming mode.
- **Color Temperature+:** Dimming mode
- **Brightness -:** Dimming mode
- **Brightness+:** Dimming mode
- **Conservation:** Press and hold for three seconds to save the current dimming mode
- **Warm Light:** 2700K color temperature & 100% power
- **Warm White Light:** 4100K color temperature & 125% power
- **Cold Light:** 5600K color temperature & 100% power
- **1/2Warm light:** 2700K color temperature & 50% power
- **1/2Warm White Light:** 4100K color temperature & 50% power
- **1/2Cold light:** 5600K color temperature & 50% power.



Instructions for the Use of Tripod Ballhead

1. Turn the Locking Ring anti-clockwise to loosen it;
2. Put the 114" Hot Shoe to the Ring Light and tighten the Locking Ring in a clockwise direction;
3. Turn the Ballhead Locking Knob anti-clockwise to loosen it;
4. Adjust the ballhead to the angle you want;
5. Turn the Ballhead Locking Knob clockwise to tighten it

E-mail: contact@inkeltech.com

All rights reserved. Copyright 2019. All items and the Inkeltech logo are the property of Inkeltech.

FREQUENTLY ASKED QUESTIONS

What is the diameter and power rating of the Inkeltech RL-480 Ring Light Kit?

The Inkeltech RL-480 Ring Light Kit has an 18-inch (46 cm) diameter and operates at 60W, providing bright and even lighting for photography, video, and makeup applications.

What is the adjustable color temperature range of the Inkeltech RL-480 Ring Light Kit?

The ring light offers an adjustable color temperature range from 3000K (warm light) to 6000K (cool white light), allowing users to customize lighting without additional filters.

How can I control the brightness and color of the Inkeltech RL-480 Ring Light Kit?

You can adjust brightness (0%-100%) and color temperature via the IR remote controller (from up to 2.5 meters away) or manually using the knob on the stand.

Why is my Inkeltech RL-480 Ring Light not turning on?

Ensure the power adapter is securely connected. If using batteries, check whether they are fully charged and compatible (Sony batteries only).

Why is the indicator light flashing red on the Inkeltech RL-480 Ring Light Kit?

A flashing red light indicates that the battery is low and needs to be recharged or replaced soon.

Why is the IR remote not working with my Inkeltech RL-480 Ring Light?

Check the battery inside the remote and ensure there are no obstructions between the remote and the light. The IR remote must be used within 2.5 meters for effective control.

How do I reset the Inkeltech RL-480 Ring Light if it malfunctions?

Turn off the ring light, unplug it, and let it sit for 5-10 minutes before reconnecting the power source or inserting fresh batteries.

VIDEO – PRODUCT OVERVIEW



[Download Data Sheet Product Inkeltech RL-480 2025/04 Inkeltech RL-480 Ring Light-Kit-Instruction-Manual.mp4](#)

References

- [User Manual](#)

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.