


Contents

- [1 Inrorans AGD0004 Essential Oil Diffuser](#)
- [2 INTRODUCTION](#)
- [3 SPECIFICATIONS](#)
- [4 WHAT'S IN THE BOX](#)
- [5 FEATURES](#)
- [6 SETUP GUIDE](#)
- [7 CARE & MAINTENANCE](#)
- [8 TROUBLESHOOTING](#)
- [9 PROS & CONS](#)
- [10 WARRANTY](#)
- [11 FREQUENTLY ASKED QUESTIONS](#)
- [12 VIDEO – PRODUCT OVERVIEW](#)
- [13 References](#)

INRORANS

Inrorans AGD0004 Essential Oil Diffuser



INTRODUCTION

Aromatherapy and interior design come together beautifully in the Inrorans AGD0004 Essential Oil Diffuser. This ultrasonic cool mist diffuser, which costs \$25.99 and is made by INRORANS, adds elegance to any space with its hand-blown art glass design in a warm Brown Rock finish. With seven color-changing LED lights and adjustable mist settings, this diffuser, which was just released to add a soothing presence to bedrooms, offices, yoga areas, or kids' rooms, creates a whisper-quiet experience. While the 1H, 3H, and 6H timer features allow you to set it and forget it, the integrated auto shut-off feature guarantees safety when the water runs out. It helps you inhale natural oils without dominating your area by supporting sporadic 30-second misting cycles. This BPA-free diffuser enhances your home's aesthetics and well-being by fusing beauty, functionality, and calm. It's an experience rather than just a diffuser.

SPECIFICATIONS

Brand	Inrorans
Model	AGD0004 Hand-Blown Glass Essential Oil Diffuser
Price	\$25.99
Color	Brown Rock
Material	Hand-Blown Glass, BPA-Free
Recommended Use	Home, Office, Bedroom, Yoga Room
Diffuser Type	Ultrasonic Cool Mist
Light Features	7 LED colors with 15 lighting modes (dark/bright), usable as a nightlight
Timer Settings	1H / 3H / 6H Auto-Off Timers
Auto Shut-Off	Yes, when water runs out
Noise Level	Whisper Quiet (<30 dB)
Special Features	Intermittent mist (30s on/off), Separate mist & light control, Silent Operation
Weight	1.6 pounds
Count per Unit	1 Diffuser
Manufacturer	Inrorans

WHAT'S IN THE BOX

- Essential Oil Diffuser
- User Manual

FEATURES

- **Design:** Hand-blown glass with a distinctive Brown Rock design for sophisticated interior design.
- **Function:** Essential oils are distributed without the use of heat thanks to ultrasonic cool mist technology.
- **Noise Level:** Perfect for rest and sleep, whisper-quiet operating at less than 30 dB.

Quiet design brings you better sleep



49dB

Loud Conversation



39db

Air Conditioning



30db

INRORANS Diffuser[®]



0.2db

Flower Blooming



- **Timer Settings:** Adaptable timer with automatic shut-off options of one, three, and six hours.

Timer & Mist Choice setting



4-7 hrs

Continuous mist

Timer: 1H-3H-6H



10-12 hrs

Intermittent Mode

30s on/30s off

High Mist Output
No Damp
on the Desk



- **Night Light:** Independently controllable from mist, with 15 light modes and 7 LED color selections.
- **Safety:** To avoid damage or overheating, it automatically turns off when the water supply runs out.
- **Capacity:** A water tank free of BPA that is safe and healthful to use.
- **Controls:** For versatile customization, separate buttons are provided for light and mist.

Seperate Light & Mist Mode Setting Easy To Control



- **Versatility:** Fits well in offices, living rooms, bedrooms, yoga studios, and kid's spaces.
- **Aroma:** By diffusing without heat, essential oils maintain their integrity.
- **Material:** BPA-free plastic parts and sturdy, premium glass.
- **Size and Weight:** At 1.6 pounds, it is small and lightweight for convenient placement.
- **Energy-efficient:** Ultrasonic technique uses less power.
- **Aesthetic:** Because of the creative glass design, it naturally complements the majority of home decor types.
- **Health Benefits:** Promotes greater sleep, reduced stress, and cleaner air.

Soothing LED Light



SETUP GUIDE

- **Unpack:** Carefully take the diffuser and its attachments out of the box.
- **Water Tank:** Open the BPA-free water tank and fill it to the brim with pure water.
- **Add Oils:** To the water, add a few drops of your preferred essential oil.
- **Assemble:** Set the diffuser on a level platform and firmly seal the water tank.
- **Power:** Attach a power outlet to the diffuser.
- **Power On:** To begin diffusion, press the mist button.
- **Timer Setting:** Depending on your preferences, choose a 1H, 3H, or 6H timer.
- **Light Control:** To choose between 15 settings and 7 colors, use the light button.
- **Independent Controls:** When necessary, operate the light and mist controls separately.
- **Location:** Keep out of direct sunlight and heat sources and use in a well-ventilated environment.
- **Water Monitoring:** To prevent dry running, periodically check the water level while using.
- **Refilling:** To ensure continuing use, replenish oils and water as needed.
- **Cleaning Reminder:** To preserve performance, clean the diffuser on a regular basis.
- **Steer Clear of Overfilling:** To stop leaks, don't go over the maximum water level.
- **Unplug After Use:** Always unplug before cleaning or when not in use.



CARE & MAINTENANCE

- **Unplug:** Before cleaning, always turn off the electricity.
- **Cooling:** Before disassembling, let the diffuser cool.
- **Cleaning Water Tank:** After every usage, empty and rinse the water tank.
- **Deep Cleaning:** Every month, give the tank a thorough cleaning with a solution of vinegar and water.
- **Wipe Exterior:** Use a gentle, moist cloth to clean the exterior surfaces.
- **Steer Clear of Harsh Chemicals:** Steer clear of abrasive solvents and cleaners.
- **Eliminate Residue:** Gently clean the ultrasonic plate with a cotton swab.
- **Dry Completely:** Before reassembling, make sure every component is completely dry.
- **Replace Water:** To prevent the growth of bacteria or mold, use new water every time.
- **Essential Oils:** To avoid blockage and harm, use pure essential oils.
- **Storage:** When not in use, keep in a cool, dry location.
- **Check Cable:** Look for damage to the power cable on a regular basis.
- **Prevent Water Spills:** Keep water out of electrical parts.
- **Use the Correct Voltage:** Verify that the voltage satisfies the requirements of the device.

TROUBLESHOOTING

Issue	Possible Cause	Solution
Diffuser not turning on	Power cord not plugged in or faulty outlet	Plug securely and test with a different outlet.
No mist output	Water tank is empty or below minimum level	Refill the tank to the proper level with clean water.
Weak scent emission	Low oil concentration or improper mixing	Add a few more drops of essential oil and stir gently.
Loud buzzing noise	Build-up of minerals in ultrasonic plate	Clean the ultrasonic plate with a soft cloth and vinegar.
LED lights not working	Light mode not selected or bulb malfunction	Press the light button again to cycle modes.
Stops working after a few minutes	Timer setting too short or auto shut-off	Adjust the timer or refill water if tank is empty.
Leaking from the base	Overfilled tank or tilted placement	Refill correctly and place diffuser on a level surface.
Mist smells burnt or odd	Old or expired oil used	Replace oil with a fresh, high-quality essential oil.
Difficult to remove the top	The glass lid was sealed tightly due to mist residue	Gently twist while supporting the base to lift the lid.
Device is hot to touch	Continuous use for an extended time	Turn off and let cool before restarting.

PROS & CONS

Pros:

- Hand-blown art glass design adds a luxurious aesthetic.
- Silent ultrasonic operation under 30dB for peaceful use.
- 7-colour LED light with dual brightness settings.
- Built-in timer (1H/3H/6H) and automatic shut-off.
- Intermittent misting supports essential oil longevity.

Cons:

- Glass body requires delicate handling.
- No remote control functionality.
- Water tank capacity may not support full-night diffusion.
- Not suitable for very large rooms.
- Limited to wall-outlet operation no battery backup.

WARRANTY

The Inrorans AGD0004 Essential Oil Diffuser includes a **45-day money-back** guarantee and a 24-month manufacturer's warranty. This warranty covers issues related to manufacturing defects and functional problems under normal household use. Damage caused by misuse, drops, or unauthorised modifications is not covered. Users must retain proof of purchase to claim warranty services. For troubleshooting and claims, Inrorans offers responsive customer support committed to resolving inquiries within 24 hours.

FREQUENTLY ASKED QUESTIONS

How does the ultrasonic technology in the Inrorans AGD0004 diffuser work?

It uses high-frequency ultrasonic vibrations to break down water and essential oils into a fine mist without heat, preserving the oils properties and offering quiet, consistent diffusion.

What timer settings are available on the Inrorans AGD0004 diffuser?

This model allows you to choose from 1-hour, 3-hour, or 6-hour timer settings, or use it continuously until the water runs out.

How much noise does the Inrorans AGD0004 diffuser produce?

It operates under 30dB, making it ultra-quiet ideal for bedrooms, nurseries, or workspaces.

How many light color options are there in the Inrorans AGD0004 model?

There are 7 color options, each with a dim and bright mode, totaling 15 light variations to create the perfect mood or nightlight.

What should I do if the light on my Inrorans AGD0004 isnt working?

Check the power connection first. If mist is working but not the light, try toggling the light mode button. If that fails, the LED light may be faulty and require support.

How do I clean the Inrorans AGD0004 diffuser properly?

Wipe the reservoir with a soft cloth and use a cotton swab dipped in vinegar to gently clean the ultrasonic

plate. Avoid harsh chemicals or soaking the base.

Why is my Inrorans AGD0004 diffuser shutting off before the timer ends?

This usually means the water level is too low, triggering the auto shut-off for safety. Refill the tank and restart the unit.

VIDEO – PRODUCT OVERVIEW

<https://manuals.plus/wp-content/uploads/2025/05/Inrorans-AGD0004-Essential-Oil-Diffuser-User-Manual.mp4>

References

- [User Manual](#)

[Manuals+](#), [Privacy Policy](#) | [@manuals.plus](#) | [YouTube](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.