

Insignia Bluetooth Speaker [NS-CSPBTF1] User Manual

[Home](#) » [Insignia](#) » Insignia Bluetooth Speaker [NS-CSPBTF1] User Manual

Contents [[hide](#)]

[1 QUICK SETUP GUIDE Bluetooth Speaker NS-CSPBTF1](#)

[1.1 Related Posts](#)

QUICK SETUP GUIDE Bluetooth Speaker NS-CSPBTF1


PACKAGE CONTENTS

- Bluetooth Speaker
- Micro USB cable
- Quick Setup Guide


Before using your new product, please read these instructions to prevent any damage.

SAFETY INFORMATION

- Use the speaker in normal temperatures.
- Do not use the speaker under the water.
- Do not throw the speaker.
- Do not cover or insert anything into the holes in the speaker.
- Do not put the speaker close to any heat source.
- Contact your retailer if the charging cable does not connect to your speaker.
- Do not disassemble, repair, or modify the speaker.
- Do not charge the speaker using more than 5V.
- High volumes may damage your hearing. Use the speaker at a lower volume.
- Disassembling the speaker voids its warranty.



Power Button, Volume Buttons, Call Button, and Bluetooth LED



Reset Hole, Micro USB Port, Charging LED and AUX In Jack on Speaker Side

CHARGING YOUR SPEAKER

The charging LED blinks red when the speaker's battery is low.

Connect the micro USB cable from your speaker's micro USB port to a USB port (such as a computer or wall charger). The charging LED lights red while charging, then turns off when the battery is fully charged.

CONNECTING AN AUDIO DEVICE – Bluetooth

1. Press and hold (power) to turn on your speaker. The Bluetooth LED blinks blue quickly and your speaker automatically enters pairing mode.
2. Make sure that your Bluetooth device is within 33 ft. (10 m) of your speaker.
3. Turn on your Bluetooth device, turn on Bluetooth, then enter pairing mode. For more information, see the documentation that came with your Bluetooth device.
4. On your Bluetooth device, select NS-CSPBTF1. Your speaker pairs with your Bluetooth device and the Bluetooth LED lights solid blue.
5. To disconnect, un-pair your Bluetooth device from your speaker.






Audio cable: Connect a 3.5 mm audio cable (not included) from your speaker's AUX IN jack to your audio device's headphone/audio out jack.

USING YOUR SPEAKER – Listening to audio

1. Play audio on your connected device.
2. Press + or – to adjust your speaker's volume.
Note: Make sure that your connected device's volume is set to at least 50%.
3. Use the controls on your connected device to control playback.

TAKING A PHONE CALL

The following functions are available when paired to a phone with Bluetooth:

- Reject an incoming call: Press and hold (call). 
- Answer an incoming call: Press (call). 
- Switch audio between your speaker and phone: Press and hold (call). 
- End current call: Press (call). 
- Redial the last dialed number: Press  (call) twice.

LED INDICATORS:

LED Blinks blue quickly: Bluetooth pairing mode

Lights solid blue: Paired to a Bluetooth device

Blinks blue slowly: Connected to an AUX device

Lights red: Speaker is charging (charging complete when LED turns off)

TROUBLESHOOTING

Unable to pair.

- Turn your speaker off, then back on.
- If a passcode is needed, enter 0000.
- Move your speaker and Bluetooth device closer together.

Static or breaks while playing audio.

- Move your speaker and Bluetooth device closer together.
- Use a paper clip to press reset.
- Make sure that the audio cable is connected securely.
- Try a different audio cable.

No sound.

- Turn up the volume on both your speaker and connected device.
- Make sure that your Bluetooth device is paired to your speaker.
- Unplug the audio cable (if connecting with Bluetooth).

No power.

- Make sure that your speaker is fully charged.

Unable to operate.

- Use a paper clip to press reset.

LEGAL NOTICES

If at any time in the future you should need to dispose of this product, note that waste electrical products should not be disposed of with household waste. Recycle where facilities exist. Check with your Local Authority or retailer for recycling advice. (Waste Electrical and Electronic equipment Directive) Owing to continuous improvement, no prior notice will be given regarding changes on features and specifications.



FCC Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC Caution

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Industry Canada Compliance

IC Statement: This device complies with Industry Canada's license-exempt RSSs. Operation is subject to the following two conditions: (1) This device may not cause interference; and (2) This device must accept any interference, including interference that may cause undesired operation of the device.

ONE-YEAR LIMITED WARRANTY

Visit www.insigniaproducts.com for details.

CONTACT INSIGNIA:

For customer service, call 1-877-467-4289

(U.S. and Canada) or 01-800-926-3000 (Mexico)

INSIGNIA is a trademark of Best Buy and its affiliated companies. Distributed by Best Buy Purchasing, LLC

©2016 Best Buy. All rights reserved. Made in China

Insignia Bluetooth Speaker [NS-CSPBTF1] User Manual – [Optimized PDF](#)

Insignia Bluetooth Speaker [NS-CSPBTF1] User Manual – [Original PDF](#)