



INSIGNIA NS-PNC5001 USB Keyboard and Mouse Combo User Guide

[Home](#) » [Insignia](#) » INSIGNIA NS-PNC5001 USB Keyboard and Mouse Combo User Guide 

Contents

- [1 INSIGNIA NS-PNC5001 USB Keyboard and Mouse Combo](#)
- [2 Product Information](#)
- [3 Product Usage Instructions](#)
- [4 Contact Insignia:](#)
 - [4.1 Package contents](#)
 - [4.2 System requirements](#)
 - [4.3 Mouse features](#)
 - [4.4 Keyboard features](#)
 - [4.5 Shortcut keys](#)
 - [4.6 Setting up your mouse](#)
 - [4.7 Setting up your keyboard](#)
 - [4.8 Cleaning your mouse and keyboard](#)
 - [4.9 Troubleshooting](#)
 - [4.10 Legal notices](#)
 - [4.11 One-year limited warranty](#)
- [5 Documents / Resources](#)
 - [5.1 References](#)



INSIGNIA NS-PNC5001 USB Keyboard and Mouse Combo



Product Information

- Product Name: USB Keyboard and Mouse Combo
- Model: NS-PNC5001/NS-PNC5001-C
- Package Contents: Mouse, Keyboard
- System Requirements: Compatible with most computers

Product Usage Instructions

Setting up your mouse:

1. Plug the USB connector of the mouse into an available USB port on your computer.
2. Ensure that the mouse is turned on. The power switch can be found on the bottom of the mouse.

Setting up your keyboard

1. Plug the USB connector of the keyboard into an available USB port on your computer.
2. Ensure that the keyboard is turned on. The power switch can be found on the back or side of the keyboard.

Mouse Features

- Scroll Wheel: Use the scroll wheel to navigate through documents or webpages.
- Left Button: Press the left button to perform a primary action.
- Right Button: Press the right button to perform a secondary action or open context menus.

Keyboard Features

- Shortcut Keys: The keyboard features several shortcut keys for quick access to common functions.
- Volume Down: Press to decrease the volume. Hold down to decrease the volume quickly.
- Mute: Press to turn the sound off.

- Volume Up: Press to increase the volume. Hold down to increase the volume quickly.
- Previous: Press to select the previous music or video track.
- Play/Pause: Press to play or pause music or video.
- Next: Press to select the next music or video track.
- Stop: Press to stop playing music or video.
- Sleep: Press to put your computer into sleep mode.
- Home: Press to open a home page in your browser.
- Refresh: Press to reload an open web page.

Cleaning your mouse and keyboard

To clean your mouse and keyboard, use a soft cloth or cotton swab lightly dampened with water or a mild cleaning solution. Avoid using harsh chemicals or abrasive materials that may damage the surfaces.

Troubleshooting

If you encounter any issues with your USB Keyboard and Mouse Combo, refer to the troubleshooting section in the user manual or visit our website for further assistance.

Legal Notices

This product is covered by a one-year limited warranty. For complete warranty details, please visit our website.

Contact Insignia:

If you have any questions or need support, you can contact Insignia through the following channels:

- Phone (U.S. and Canada): 1-877-467-4289
- Phone (Mexico): 01-800-926-3000
- Website: www.insigniaproducts.com


Package contents

- Wired USB mouse
- Wired USB keyboard
- Quick Setup Guide


System requirements

- Windows® 8.1, Windows® 8, Windows® 7,
- Windows Vista®, or Mac OS 10.X or higher
- Two available USB ports











Mouse features



Keyboard features




Shortcut keys

Icon	Function	Description
	Volume down	Press to decrease the volume. Hold down to decrease the volume quickly.
	Mute	Press to turn the sound off.
	Volume up	Press to increase the volume. Hold down to increase the volume quickly.
	Previous	Press to select the previous music or video track.
	Play/Pause	Press to play or pause music or video.
	Next	Press to select the next music or video track.
	Stop	Press to stop playing music or video.
	Sleep	Press to put your computer into sleep mode.
	Home	Press to open a home page in your browser.
	Refresh	Press to reload an open web page.

Setting up your mouse


- Plug your mouse into an available USB port on your computer.

The computer automatically detects the mouse and you can immediately begin using it.



Setting up your keyboard

- Plug the keyboard into an available USB port on your computer. You can begin using your keyboard immediately after Windows automatically finds and installs the appropriate driver.



Cleaning your mouse and keyboard

- Wipe the mouse and keyboard with a damp, lint-free cloth.

Troubleshooting

My mouse and/or keyboard is not working.

- Make sure that your computer meets the system requirements.
- Make sure that your mouse and keyboard USB cables are securely attached to the USB ports on your computer.
- Only use the mouse on a clean, flat, non-slippery surface to ensure smooth and accurate cursor action.
- Try connecting your mouse and keyboard into different USB ports on your computer.

Legal notices

FCC Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Warning: Changes or modifications not expressly approved by the party responsible for compliance could void

the user's authority to operate the equipment.

IC Statement

CAN ICES-3 (B)/NMB-3 (B)

One-year limited warranty

For complete warranty, visit www.insigniaproducts.com.

Contact Insignia

1-877-467-4289 (U.S. and Canada) or 01-800-926-3000 (Mexico)

www.insigniaproducts.com

INSIGNIA is a trademark of Best Buy and its affiliated companies.

Registered in some countries.


Distributed by Best Buy Purchasing, LLC

7601 Penn Ave South, Richfield, MN 55423 U.S.A.

©2015 Best Buy. All rights reserved.

Made in China

Documents / Resources

	INSIGNIA NS-PNC5001 USB Keyboard and Mouse Combo [pdf] User Guide NS-PNC5001, NS-PNC5001-C, NS-PNC5001 USB Keyboard and Mouse Combo, NS-PNC5001, USB Keyboard and Mouse Combo, USB Keyboard and Mouse, Keyboard and Mouse, Mouse, Keyboard
---	--

References

- [Insignia Consumer Electronic Products](#)