


intelbras LSWM2QP2PInterface Card



intelbras LSWM2QP2P Interface Card User Manual


[Home](#) » [intelbras](#) » intelbras LSWM2QP2P Interface Card User Manual 

Contents

- [1 intelbras LSWM2QP2P Interface Card](#)
- [2 Product Usage Instructions](#)
- [3 Overview](#)
- [4 Installing and removing the card](#)
- [5 Verifying the installation](#)
- [6 Ports](#)
- [7 LEDs](#)
- [8 FAQ](#)
- [9 Documents / Resources](#)
 - [9.1 References](#)
- [10 Related Posts](#)



intelbras LSWM2QP2P Interface Card



Specifications:

- Interface: LSWM2QP2P
- Ports: 2 QSFP+ ports
- Compatibility: Applicable to specific switch models (contact Intelbras Support for an updated list)

Product Usage Instructions

Safety Precautions:

Before installing or removing the card, wear an ESD wrist strap and ensure it is grounded. Avoid using excessive force during installation or removal to prevent device damage.

Installing the Card:

1. Remove any filler panel from the target slot.
2. Unpack the card and insert it slowly into the slot along the guide rails.
3. Rotate the ejector lever inward until the card is in contact with the switch.
4. Tighten the captive screw on the card using a Phillips screwdriver.

Removing the Card:

1. Remove cables from the card.
2. If not replacing the card, install a filler panel in the slot.
3. Loosen the captive screw on the card using a Phillips screwdriver.
4. Pull the card outward by holding the ejector lever until disconnected from the connectors.

Installing and Removing Transceiver Modules and Cables:

Follow specific instructions for installing and removing transceiver modules and cables provided by Intelbras.


Verifying Installation:

After installation, ensure the card operates correctly. If issues persist, reinstall the card following instructions or

contact Intelbras Support.

Overview

The LSWM2QP2P interface card provides two QSFP+ ports.



- The switch models that the LSWM2QP2P interface cards is applicable to may change over time. For the most up-to-date list of applicable switch models, contact Intelbras Support or marketing staff.
- The restrictions for using the LSWM2QP2P vary by device model. For more information, see the installation guide or hardware information and specifications for the device.


Installing and removing the card

Prepare the following tools before you install or remove the card: Phillips screwdriver, flat-blade screwdriver, and ESD wrist strap. No installation tools are provided with the device. Prepare these tools yourself.

1. Safety precautions

- Before you install or remove the card, wear an ESD wrist strap and make sure the strap makes good skin contact and is reliably grounded.
- To avoid device damage, do not use excessive force when you install or remove the card.

2. Installing the card




Remove the filler panel (if any) from the target slot before installing the card. Keep the removed screw and filler panel secure for future use.

1. Unpack the card. Insert the card slowly into the slot along the guide rails.
2. Rotate inward the ejector lever until the card is in close contact with the switch.
3. Use the Phillips screwdriver to tighten the captive screw on the card.

3. Removing the card

To avoid cable damage, remove the cables from the card before removing the card.

If you are not to install a new card after removing the original one, install a filler panel in the slot to prevent dust and ensure good ventilation in the device.



Place the removed card on an anti-static mat or in an anti-static bag.

1. Use a Phillips screwdriver to loosen the captive screw on the card.
2. Hold the ejector lever to pull the card outward until the card is disconnected from the connectors.
3. Hold the card with both hands and take it out slowly.

4. Installing and removing transceiver modules and cables

Verifying the installation

After the installation is complete, determine whether the card is operating correctly. If the card fails to operate correctly, perform the following steps: Reinstall the card following the installation procedures described in this document. If the problem persists, contact Intelbras Support.

Ports

- You can install QSFP+ transceiver modules, QSFP+ cables, and QSFP+ to SFP+ cables in the SFP ports.
- Intelbras transceiver modules and cables available for the card are subject to change over time. For the most recent list of Intelbras transceiver modules and cables available for the card, contact Intelbras Support or marketing staff.

LEDs

The QSFP+ port LEDs are not affected by the port LED mode switching button on your switch. For more information about the port LED mode switching button, see the installation guide for the switch.

LED Status	Description
Steady green	A transceiver module is installed in the port. The port is operating at 40 Gbps, and a link is present on the port.
Flashing green	The port is sending or receiving data at 40 Gbps.
Steady yellow	A transceiver module is installed in the port. The port is operating at 10 Gbps, and a link is present on the port.
Flashing yellow	The port is sending or receiving data at 10 Gbps.
Off	No transceiver module is installed in the port, or no link is present on the port.

FAQ

Q: Can I use any transceiver modules and cables with the LSWM2QP2P interface card?

A: No, only Intelbras transceiver modules and cables are recommended for use with the card. Contact Intelbras Support for the latest compatible options.

Documents / Resources

	intelbras LSWM2QP2P Interface Card [pdf] User Manual LSWM2QP2P, LSWM2QP2P Interface Card, Interface Card, Card
---	---

References

- [User Manual](#)

Manuals+, [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.