



Intermec USB-to-Parallel Adapter Instructions

[Home](#) » [Intermec](#) » Intermec USB-to-Parallel Adapter Instructions 


Intermec USB-to-Parallel Adapter Instructions



Contents

- [1 Installation Instruction](#)
- [2 Documents / Resources](#)
- [3 Related Posts](#)

Installation Instruction



For more information on using this accessory, see the PC23 and PC43 Desktop Printer User Manual. Worldwide Headquarters

6001 36th Avenue West
Everett, Washington 98203
U.S.A.

tel **425.348.2600**

fax **425.355.9551**

www.intermec.com

© 2011 Intermec Technologies
Corporation. All rights reserved.



PC23d, PC43d and PC43t USB-to-Parallel Adapter Instructions

P/N 943-325-001

Intermec

Documents / Resources



[Intermec USB-to-Parallel Adapter](#) [pdf] Instructions

Intermec, USB-to-Parallel, Adapter, PC23d, PC43d, PC43t