



INTOLED Garden Post with Socket Instructions

Home » INTOLED » INTOLED Garden Post with Socket Instructions

Contents

- 1 INTOLED Garden Post with
- Socket
- 2 Step-by-Step Instruction
- 3 Specifications
- 4 FAQs
- 5 Documents / Resources
 - **5.1 References**




INTOLED Garden Post with Socket



Step-by-Step Instruction


Step 1: Power Off

Ensure the power is turned off by switching the main switch to the "OFF" position.




Step 2: Position the Outlet Post

Place the outlet post in the desired location, ensuring it is upright and stable.




Step 3: Secure the Base

Drill holes into the ground and insert anchors to secure the base of the outlet post.




Step 4: Connect the Wiring
Feed the electrical wiring through the base of the outlet post.




Step 5: Connect the Water Supply

- 1. Attach the water supply hose to the outlet post.
- 2. Ensure the connection is tight and secure.
- 3. Check for any leaks.




Step 6: Finalize Installation

Use a screwdriver to tighten all screws and secure the outlet post in place.



Step 7: Power On
Switch the main switch to the "ON" position to restore power.



Specifications

Feature	Details
Power Supply	Standard Electrical Connection
Water Connection	Standard Hose Fitting
Installation Tools	Drill, Screwdriver

FAQs

What tools are needed for installation?
You will need a drill and a screwdriver for installation.

Can this be installed outdoors?
Yes, the outlet post is designed for outdoor use.
Is it necessary to turn off the power before installation?
Yes, always ensure the power is off before starting the installation.

Documents / Resources



INTOLED Garden Post with Socket [pdf] Instructions
10mm, 341, Garden Post with Socket, Post with Socket, with Socket, Socket

References

User Manual

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.