

inventor FT403W Table Fan User Manual

Home » inventor » inventor FT403W Table Fan User Manual

Contents


- 1 inventor FT403W Table Fan
- **2 RULES FOR SAFE OPERATION**
- **3 INSTALLATION INSTRUCTIONS**
 - 3.1 Name of components
- **4 GRILL & FAN BLADE**

ASSEMBLY

- **5 Front and Rear Grill Installation**
- **6 OPERATION INSTRUCTIONS**
- **7 MAINTENANCE INSTRUCTION**
- **8 CLEANING**
- 9 Activate your Warranty
- 10 Documents / Resources
 - 10.1 References
- 11 Related Posts

inventor

inventor FT403W Table Fan



CAUTION

For safe operation please read and follow the below Instructions carefully.

WARNING

- 1. If the supply cord is damaged, it must be replaced by the manufacturer or its service agent or a similarly qualified person in order to avoid a hazard.
- 2. To avoid the risk of electrical shock, do not immerse the unit, cord or plug in water or any other liquids.
- 3. This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved.
 Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.
- 4. When the appliance is not operating, and, prior to cleaning, please unplug from the power socket.
- 5. When assembling the fan, make sure that the protective fan grill covers are properly installed.
- 6. After the fan assembly, do not remove the rotor blade guard.
- 7. Do not disassemble the rotor blade guard to clean the rotor blades.

- 8. Use a slightly damp cloth to clean the fan enclosure and rotor blade.
- 9. Do not allow any water or other liquid to enter the motor housing.
- 10. Do not dispose this product as unsorted municipal waste. This appliance requires special treatment for disposal. It is prohibited to dispose of this appliance in domestic household waste. To prevent possible harm to the environment or human health from uncontrolled waste disposal, recycle it responsibly to promote the sustainable reuse of material resources.


To return your used device, contact the retailer, it is possible they may dispose of it at a recycling facility.

RULES FOR SAFE OPERATION

- 1. While the fan is operating, no sharp objects, such as pencils, should be inserted through the protective grill. Be extra cautious when handling and be certain no fingers penetrate beyond the protective grill area, this should be strictly avoided at all times.
- 2. Be certain that the fan is disconnected when repositioning from one location to another.
- 3. Be certain that the fan is on a stable surface while operating, to avoid accidental tipping.
- 4. Be extra cautious when operating near a window as rain may cause electric shock.
- 5. This device is intended for domestic use only.

INSTALLATION INSTRUCTIONS

Name of components




Note: The figures in this manual are only for explanatory purposes. In case of discrepancies between the illustrations and the actual product, please refer to the product that you purchased.

GRILL & FAN BLADE ASSEMBLY

- 1. Adjust the fan to the chassis.
- 2. Fix the rear grill to the motor carefully.
- 3. Screw clockwise the nut of the grill to secure the position of the grill on the motor.
- 4. Insert the fan blade. Rotate the blade to ensure that it is moving normally.
- 5. Screw the spinner by rotating counterclockwise.
- 6. Place the front grill to the right position base on the below instructions.

Front and Rear Grill Installation



- 1. Align the front grill with the rear grill as illustrated. Use the holes on the outer ring as your guide.
- 2. Press down the 4 buckles of the outer ring to fasten the front and the rear grill.
- 3. Tighten the fan grill locking screw and nut.

OPERATION INSTRUCTIONS

1. Tilt adjustment

To adjust the tilt of the air flow upwards or downwards, push the motor housing lightly to the desired direction.

2. Speed adjustment


There are 3 speeds available. To adjust the fan speed, press the relative buttons located on the bottom of the fan body (1=low/2=medium/3=high/0=off)

3. Oscillation adjustment

To adjust the oscillation press the button located on the left side of the motor housing.

4. Chassis mounting

To release the fan body from the chassis, simply rotate the knob to the left and then lift the fan from the base.



MAINTENANCE INSTRUCTION

This fan requires limited maintenance. Do not attempt to fix on your own. Always refer to qualified personnel if any service is required.

- 1. Prior to cleaning and assembling, the fan must be unplugged.
- 2. To ensure adequate air circulation to the fan's motor, vents at the rear of the fan motor should be free of dust at all times. Do not disassemble the fan in order to remove the dust.
- 3. The exterior parts of the device may be wiped with a soft and damp (with a mild detergent) cloth.
- 4. The use of any abrasive detergent or solvents, gasoline, or paint thinner for cleaning purposes should be avoided as this may result in damaging the surface of the fan.
- 5. Water or any other liquids in the motor housing or interior parts of the fan must be avoided at all times.

CLEANING

- 1. Prior to performing any cleaning the device must be unplugged.
- 2. All plastic parts of the device should be cleaned with a soft moist cloth and with mild soap. Thoroughly clean any soap excess with a dry cloth.

All the pictures in the manual are for explanatory purposes only. The actual shape of the unit you purchased may

be slightly different, but the operations and functions are the same.

The company may not be held responsible for any misprinted information. The design and the specifications of the product for reasons, such as product improvement, are subject to change without any prior notice.

Please consult with the manufacturer at +30 211 300 3300 or with the Sales agency for further details. Any future updates to the manual will be uploaded to the service website, and it is advised to always check for the latest version.



Scan here to download the latest version of this manual. www.inventorappliances.com/manuals

Activate your Warranty

Follow the next quick steps to activate your warranty:

1. STEP:1

https://www.inventorappliances.com/warranty-car or by scanning the QR code, as follows:




2. STEP:2

Fill ed in the "Owner's details" and "Unit's details":



3. **STEP 3**

Click SEND button at the end of the submission form:



4. STEP 4

Wait for the confirmation email you will receive at the email address you have filled in PLEASE your spam folder.

5. **STEP 5**

Documents / Resources



inventor FT403W Table Fan [pdf] User Manual FT403W, Table Fan, FT403W, Fan

References

- 🐧 Κλιματιστικά Inverter WiFi, Ψυγεία, Αφυγραντήρες, Air Conditioners Inventor
- Diblioteca media Inventor
- 🗗 Αρχεία και Υποστήριξη Inventor
- Dedienungsanleitungen Inventor appliances
- Manuels de produits Inventor appliances
- © Registro de la tarjeta de garantía de 2 años Inventor appliances
- 6 2 Jahre Garantie Registrierung Inventor appliances
- Certificato di Garanzia di 2 anni Inventor appliances
- Dinventor Appliances User Manuals Inventor appliances
- Inventor
- O Carte de Garantie de 2 ans Inventor appliances
- 6 2 Year Warranty Card Registration Inventor appliances

Manuals+.