

IOGEAR GKM551R Media Center Desktop Keyboard and Mouse Combo Instruction Manual

Home » logear » IOGEAR GKM551R Media Center Desktop Keyboard and Mouse Combo Instruction Manual



IOGEAR GKM551R Media Center Desktop Keyboard and Mouse Combo



Contents

- 1 Welcome
- 2 Package Contains
- 3 Features
- 4 Requirements
- **5 Hardware Features**
- **6 Hardware Installation**
- 7 Trouble Shooting
- **8 Limited Warranty**
- 9 Contact
- 10 About Us
- 11 Documents /

Resources

- 11.1 References
- **12 Related Posts**

Welcome

Thank you for purchasing the 2.4G Wireless RF Media Center Keyboard/Laser Mouse Combo. Enjoy the freedom of wireless connectivity with IOGEAR's wireless keyboard/mouse combo. The keyboard and mouse allow you to work up to 33 feet away from the USB receiver connected to your computer. In addition, the laser mouse provides

great accuracy over most surfaces and minimal hand movement due to its 800 dpi resolution.

Easily interact and take complete control of your entertainment center with Media Center features of this combo.

The different hotkeys give you quick access to some of your most common Media Center tasks such as My TV, My Music, My Video, and My Picture. Additional four hotkeys allow users to Play/Pause, Volume Down, Volume Up,

Package Contains

and Mute.

- 1 X Wireless keyboard
- 1 X Wireless laser mouse
- 1 X Wireless receiver
- 1 X 3 ft. USB extension cable
- 1 X Quick Start Guide
- 4 X AAA batteries for both keyboard and mouse

Features

- 2.4G RF technology offers greater range up to 33 feet away from the USB receiver, and enable less interferences in your WiFi environment
- 800 dpi high resolution laser mouse delivers precise cursor movement and can be used on most surfaces
- Scissor-Structure keycap, ultra thin, portable and long range keyboard make ideal presentation tool
- · Control home entertainment functions with Media Center features on the keyboard
- Control keyboard and mouse with one USB receiver
- Newly designed slim and stylish keyboard provides better tactile feel and accurate key response
- Easy Installation and running in minutes
- Solid 3-year limited warranty

Requirements

- Available USB port
- IBM-compatible PC or Mac*
- PC System requires Windows 2000/XP/Vista*
- Mac System requires MAC OS X (10.2.x or later)*

Hardware Features

1. Keyboard -Front View

- 1. Fn & On/Off switch-hold Fn key and press ESC key will allow users to turn on/off the keyboard for extended battery life
- 2. MCE button Media Center Start Key
- 3. My TV
- 4. My Music
- 5. My Video
- 6. My Picture


^{*}Media Center hotkeys support XP MCE and Vista Premium or higher

- 7. Play/Pause button-play or pause your music or video
- 8. Volume Down button-decrease the volume of your system
- 9. Volume Up button- increase the volume of your system
- 10. Mute button-mute button to turn volume off
- 11. Battery LED-turn red when batteries are getting low



2. Keyboard - Back View

- 1. Foldable legs allow you to adjust the angle of the keyboard
- 2. Reset button press to connect to the receiver
- 3. Battery compartment store the two batteries



3. Mouse

- 1. Battery Compartment-store two batteries
- 2. Connect Button press to connect to the receiver
- 3. Laser Sensor 800 dpi laser sensor
- 4. On/Off Switch-turn mouse On/Off for extended battery life
- 5. Battery LED-turn red when batteries are getting low Scroll Wheel third button
- 6. Left-click button
- 7. Right-click



4. USB Receiver

1. USB Type A connector

- 2. Connect button press this button to connect receiver to keyboard/mouse
- 3. LED status



Hardware Installation

Before installing this product please make sure you have one available USB port reserved for the wireless receiver. The product is plug and play, no software installation needed. Control your PC or Mac wirelessly right out of the box.

A. Setting up the wireless receiver

- 1. Plug the wireless receiver into an available USB port.
- 2. Wait for Windows/Mac to install drivers for the dongle receiver, keyboard, and mouse.
- 3. When the wireless receiver has been properly initialized, the LED in the receiver will stay on.
- B. Setting up the Keyboard and Mouse
- 1. Open the keyboard's battery compartment cover and insert two AAA Alkaline batteries. Make sure they are properly installed.
- 2. Replace the keyboard battery compartment cover.
- 3. Open the mouse's battery compartment cover and insert two AAA Alkaline batteries. Make sure they are properly installed.
- 4. Replace the mouse battery compartment cover.
- 5. Press the reset button on the wireless receiver. The LED Indicator on the receiver will flash. It means the receiver is sourcing for available devices.
- 6. Flip the keyboard around and gently press the reset button.
- 7. Press the reset button on the wireless receiver. The LED indicator on the receiver will flash. It means the receiver is sourcing for available devices.
- 8. Flip the mouse around and gently press the reset button.
- 9. The LED indicator on the dongle receiver will go off when the connection has been properly set and the keyboard and mouse are working.

Once the connection has been established, when you type the keyboard or move the mouse around, the LED on the receiver will flash. It means the keyboard/mouse have made successful connection with the receiver.

Trouble Shooting

1. When low-battery indicator lights up, please change the batteries. We recommend using alkaline batteries for both keyboard and mouse.

- 2. The keyboard/mouse will go to sleep mode if the device is not in use for 8 minutes. While the keyboard/mouse is in sleep mode, please press any key/button to wake it up.
- 3. If your keyboard/mouse cannot work after installation, please check the followings:
 - a. Make sure you have connected the receiver correctly to the computer. The receiver has been properly plugged into your computer's USB port.
 - b. Make sure you have inserted batteries into its compartment correctly.
 - c. If without any interference, such as other computer peripherals, the working distance (distance between keyboard and receiver) is about 33 feet.
 - d. If using more than two units and interference occurred, please reset connection again by following instructions in section B above.

Windows Key	Mac Function
F12	Dashboard
Hold F12	Eject CD
Scroll Lock	Brightness –
Pause Break	Brightness +
▶ /II	Play/Pause
■ ()	Volume –
■□»)	Volume +
	Mute

Limited Warranty

WE'RE HERE TO HELP YOU! NEED ASSISTANCE SETTING UP THIS PRODUCT?

Make sure you:

1. Use the live chat at www.iogear.com to try and solve any issues you may be having with the product

- 2. Visit the Tech Info Library/FAQ on www.iogear.com (under the Support tab)
- 3. Call the 24/7 tech support line at 1-866-946-4327 (U.S. only) or 1-949-453-8782

Warranty Information

This product carries a 3 Year Limited Warranty. For the terms and conditions of this warranty, please go to http://www.iogear.com/support/warranty or call 1-866-946-4327 Register online at http://www.iogear.com/register

Important Product Information

Product Model	
Serial Number	

Contact

IOGEAR Inc.

Address: 23 Hubble, Irvine, CA 92618 USA

Toll Free: 866-9-IOGEAR
Phone: 949-453-8782
Web site: www.iogear.com
Email: support@iogear.com

About Us





FUN

IOGEAR offers connectivity solutions that are innovative, fun, and stylish, helping people enjoy daily life using our high technology products.



GREEN

IOGEAR is an environmentally conscious company that emphasizes the importance of conserving natural resources. The use of our technology solutions helps reduce electronic waste.



IOGEAR supports healthy and fit lifestyles. By integrating products with the latest scientific developments, IOGEAR's solutions enhance the life of end-users.



Documents / Resources



IOGEAR GKM551R Media Center Desktop Keyboard and Mouse Combo [pdf] Instruction M anual

GKM551R Media Center Desktop Keyboard and Mouse Combo, GKM551R, Media Center Desktop Keyboard and Mouse Combo, Desktop Keyboard and Mouse Combo, Keyboard and Mouse Combo, Mouse Combo, Combo

References

• User Manual

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.