



ION ISP149C Party Splash Waterproof Bluetooth Enabled Speaker User Guide

[Home](#) » [ION](#) » ION ISP149C Party Splash Waterproof Bluetooth Enabled Speaker User Guide 

ION ISP149C Party Splash Waterproof Bluetooth Enabled Speaker User Guide



Package Contents:

- Party Splash™ Link
- USB-A to USB-C® Charging Cable (3.28 ft/1 m)
- Quick start Guide

Contents

- 1 GETTING STARTED
- 2 PLUG IN TO FULLY CHARGE PRODUCT BEFORE USE, AND THEN POWER ON
- 3 ION SOUND CONTROL™ APP
- 4 CREATE YOUR SOUND EXPERIENCE
- 5 CUSTOMISE YOUR SOUND EXPERIENCE
- 6 Important Safety Instructions
- 7 Safety Notices
- 8 Documents / Resources
 - 8.1 References
- 9 Related Posts


GETTING STARTED

- REGISTER YOUR PRODUCT
- DOWNLOAD THE USER GUIDE
- SIGN UP FOR THE NEWSLETTER



IONAUDIO.COM

PLUG IN TO FULLY CHARGE PRODUCT BEFORE USE, AND THEN POWER ON



Note: Adaptor not included. Charge time based on 5V, 2A adaptor specification.
Input Voltage: 5V, 2A

ION SOUND CONTROL™ APP

Connect to the ION SOUND CONTROL™ App for a more dynamic experience:

- a. Connect phone to speaker via Bluetooth” (**Step 4**).
- b. Download App from Apple App Store or Google Play Store.
- c. Open the App on your device.



CREATE YOUR SOUND EXPERIENCE

BLUETOOTH




- Press and hold POWER to turn on, speaker will enter Bluetooth mode.
- Choose “Party Splash Link” in your Bluetooth settings menu.
- Press Play in music player App of choice on device.
- Press and + to adjust volume.
- Press and hold + to skip to the next track.
- Press and hold to revert to the beginning of the track. Press again within one second to skip to the previous track.

RADIO



- Press RADIO button on product or select RADIO in App.
- Press and hold +/- buttons to seek.
- Radio presets can be selected in the App. To navigate through presets on the speaker, quick press the PLAY/PAUSE button.

AUX IN



- Plug any sound source into the AUX input with a 1/8" cable (not included).
- To adjust the volume, turn your sound source volume up or use the + and buttons on the speaker.

BASS BOOST



- Press BASS BOOST button to enhance the overall bass frequency response in Bluetooth mode.


CUSTOMISE YOUR SOUND EXPERIENCE

LIGHT MODES



- Press LIGHTS button or use App to cycle through five light modes, or to turn the lights off.

MULTI-SYNC™™




- a. Connect your Bluetooth device to one Party Splash™ Link.
- b. Double-press BLUETOOTH on primary speaker.
- c. Power on second Party Splash™ Link or other Multi-Sync™ compatible speaker and double-press BLUETOOTH to initiate linking.

- For best results, keep speakers within 50 ft. with clear line of sight.

See User Guide or App for more instructions.

CALL ANSWERING



- When a phone is connected through Bluetooth, an incoming call will pause audio playback.
- Quick press the PLAY/PAUSE button to answer the call. Press and hold PLAY/PAUSE button to reject the call.
- During the call, the - and + buttons will adjust volume. Pressing PLAY/PAUSE button will end the call and audio playback will begin.

STANDBY MODE



- Quickly press and release POWER to enter low-power standby mode.
- To wake from standby, quickly press and release POWER, or use app.
- To power off the speaker, press and hold POWER.

Important Safety Instructions

1. Read and keep these instructions. Heed all warnings and follow all Instructions.
2. **Warning (if applicable):** Please refer to any important information (e.g., electrical, safety, etc.) printed on the exterior bottom enclosure or rear panel before installing or operating the product.
3. Clean only with dry cloth.
4. **Water and Moisture (if applicable):** Do not use this apparatus near water. The apparatus shall not be exposed to dripping or splashing and that no objects filled with liquids, such as vases, shall be placed on the apparatus. Electrical equipment should NEVER be kept or stored in damp environments.
5. (If applicable) Do not block any ventilation openings. Install in accordance with the manufacturer's instructions. Do not install this equipment in a confined or "boxed-in" space such as a bookcase or similar unit, and maintain good ventilation conditions. The ventilation should not be impeded by covering the ventilation openings with items such as newspaper, tablecloths, curtains, etc.
6. Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat. Do not place exposed flame sources such as lighted candles on the apparatus.
7. (If applicable) This product should be connected to a power supply only of the type described in these operating instructions, or as marked on the unit.
8. (If applicable) Be careful not to damage the power cord. When moving or not using the appliance, secure the power cord (e.g., wrap it with a cable tie). Before using it again, make sure the power cord has not been damaged. If the power cord has been damaged at all, bring the unit and cord to a qualified service technician for repair or replacement as specified by the manufacturer.
9. Unplug this apparatus during lightning storms or when unused for long periods of time.
10. Only use attachment/accessories specified by the manufacturer.
11. (If applicable) Use only the cart, stand, tripod, bracket or table specified by the manufacturer, or sold with the apparatus. When a cart is used, use caution when moving the cart/apparatus combination to avoid injury from tip-over.



12. **Internal/External Voltage Selectors (if applicable):** Internal or external voltage selector switches, if any, should only be reset and re-equipped with a proper plug for alternative voltage by a qualified service technician. Do not attempt to alter this yourself.
13. **Caution (if applicable):** Danger of explosion if battery is incorrectly replaced. Replace only with the same or equivalent type. Batteries (a battery pack or an installed battery) shall not be exposed to excessive heat such as sunshine, fire, etc.
14. (If applicable) Do not defeat the safety purpose of the polarised or grounding-type plug.



15. **Protective earthing terminal (if applicable):** The apparatus should be connected to a mains socket outlet with a protective earthing connection.



16. **For Class II apparatus only:** This symbol means the equipment is a Class II or double-insulated electrical appliance. It has been designed in such a way that it does not require a safety connection to electrical earth. When servicing use only identical replacement parts installed by an instructed person or with the use of ready-made leads or cords.
17. **Warning (if applicable):** Provide an earthing connection before the mains plug is connected to the mains. When disconnecting the earthing connection, be sure to disconnect it after pulling the mains plug out from the mains.
18. (If applicable) Where the mains plug or an appliance coupler is used as the disconnect device, the disconnect device shall remain readily operable.



19. **Warning (if applicable):** To prevent possible hearing damage, do not listen at high volume levels for long periods.
20. **This apparatus is for professional use only. Intended operational climate:** moderate.

Safety Notices



CAUTION

Risk of electric shock. Do not open.



SA 1966



SA 1965

CAUTION: TO REDUCE THE RISK OF ELECTRIC SHOCK, DO NOT REMOVE ANY COVER. NO USER-SERVICEABLE PARTS INSIDE. REFER SERVICING TO QUALIFIED SERVICE PERSONNEL ONLY.

DANGEROUS VOLTAGE: The lightning flash with arrowhead symbol within the equilateral triangle is intended to alert the user to the presence of insulated "dangerous voltage" within the product's enclosure that may be of sufficient magnitude to constitute a risk of electric shock.

INSTRUCTIONS: The exclamation point within the equilateral triangle is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying this appliance.

CAUTION (for U.S.A. & CANADIAN models only): TO PREVENT ELECTRIC SHOCK DO NOT USE THIS (POLARISED) PLUG WITH AN EXTENSION CORD, RECEPTACLE OR OTHER OUTLET UNLESS THE BLADES CAN BE FULLY INSERTED TO PREVENT BLADE EXPOSURE. **NOTICE CONCERNING LASER PRODUCTS: DANGER:** INVISIBLE LASER RADIATION WHEN OPEN AND INTERLOCK FAILED OR DEFEATED. AVOID DIRECT EXPOSURE TO BEAM. USE OF CONTROLS OR ADJUSTMENTS OTHER THAN THOSE SPECIFIED HEREIN MAY RESULT IN HAZARDOUS RADIATION EXPOSURE.

NOTICE CONCERNING FCC REGULATIONS: You are cautioned that changes or modifications not expressly approved by the part responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- (a) reorient or relocate the receiving antenna;
- (b) move this unit;
- (c) increase the separation between the equipment and receiver;
- (d) connect the equipment into an outlet on a circuit different from that to which the receiver is connected;
- (e) be sure that all cables are properly shielded, using a choke or ferrite where appropriate; or
- (f) consult the dealer or an experienced radio/television technician for help.

This device complies with Part 15 of the FCC rules.

Operation is subject to the following two conditions:

1. this device may not cause harmful interference, and
2. this device must accept any interference received, including interference that may cause undesired operation.

RF Warning Statement: The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction. Avoid using this device in a high RF-radiated environment

For Canadian models: This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development (ISED) Canada's licence-exempt RSS(s).

Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device. Under ISED regulations, this radio transmitter may only operate using an antenna of a type and maximum (or lesser) gain approved for the transmitter by ISED. To reduce potential radio interference to other users, the antenna type and its gain should be so chosen that the equivalent isotropic ally radiated power (e.i.r.p.) is not more than that necessary for successful communication.

This radio transmitter (identify the device by certification number, or model number if Category II) has been approved by ISED to operate with the antenna types listed below with the maximum permissible gain and required antenna impedance for each antenna type indicated. Antenna types not included in this list, having a gain greater than the maximum gain indicated for that type, are strictly prohibited for use with this device.

This unit does not exceed the Class B limits for radio noise emission from digital apparatus set out in the radio interference regulations of the Canadian Department of Communications. This device operates on a no-protection, no-interference basis. Should the user seek to obtain protection from other radio services operating in the same TV bands, a radio licence is required.

For further details, consult Innovation, Science and Economic Development Canada's document Client Procedures Circular CPC-2-1-28, Voluntary Licensing of Licence-Exempt Low-Power Radio Apparatus in the TV Bands.

For wireless products supporting the 5.15-5.35 GHz frequency band (if applicable): Usage of the 5.15-5.35 GHz band are restricted to indoor operation only. This applies to the following countries: AT, BE, BG, CZ, DK, EE, FR, DE, IS, IE, IT, EL, ES, CY, LV, LI, LT, LU, HU, MT, NL, NO, PL, PT, RO, SI, SK, TR, FI, SE, CH, UK, HR. For 240-volt use in U.K., use NEMA-style 240-volt plug. For other countries use proper plug for local outlet.



ESD/EFT Warning: This unit may contain a microcomputer for signal processing and control functions. In very rare situations, severe interference, noise from an external source, or static electricity may cause it to lock up. In the unlikely event that this should happen, turn off the unit, wait at least five seconds, and then turn it back on again. The pins of connectors identified with this ESD warning symbol should not be touched.



If the product or remote control contains a coin/button-cell battery:

Warning: Do not ingest the battery-chemical burn hazard. If a coin/button-cell battery is swallowed, it can cause severe internal burns in just 2 hours and can lead to death. Keep new and used batteries away from children. Tell others about the risk associated with button batteries and how to keep their children safe. If a battery compartment does not close securely, stop using the product and keep it away from children. If you think batteries might have been swallowed or placed inside any part of the body, seek immediate medical attention. Dispose of used button batteries immediately and safely. Flat batteries can still be dangerous.

Disposal of Batteries (if applicable): Never dispose of any types of batteries in fire or near excessive heat or direct sunlight. Overheated batteries can rupture or explode. If you are unsure of how or where to dispose of a battery, refer to your local ordinances for the proper location, method, etc.

- **Alkaline batteries & lithium button cell batteries:** You can safely dispose of alkaline and lithium button cell batteries with normal household waste. They do not pose a health or environmental risk during normal use or disposal. (Alkaline batteries are composed primarily of common metals like steel, zinc, and manganese.) Do not dispose of large amounts of alkaline or lithium button cell batteries in a group. Used batteries are often not completely "dead." Grouping them together can bring these "live" batteries into contact with one another, creating safety risks. To avoid this, insulate each battery with tape or other non-conductive material to ensure it does not discharge. Proven cost-effective and environmentally safe recycling processes are not yet universally available for alkaline and lithium button cell batteries. Some communities offer recycling or collection of these batteries. For more information, refer to your local ordinances or contact your local government.
- **Lead-acid batteries:** Dispose of lead-acid batteries by bringing them to an electronic waste center or recycling center, or dispose of them in accordance with your local ordinances. (Rechargeable lead-acid batteries are the same type used in automobiles and should be disposed of in a similar fashion.)

ION Audio is a trademark of in Music Brands, Inc., registered in the U.S. and other countries.

NAME® is the registered trademark and service mark of the National Electrical Manufacturers Association. All other product names, company names, trademarks, or trade names are those of their respective owners.

IONAUDIO.COM/SUPPORT

For articles, videos, and chat support


IONAUDIO.COM/WARRANTY

For complete warranty information



ionaudio.com

Documents / Resources



[ION ISP149C Party Splash Waterproof Bluetooth Enabled Speaker](#) [pdf] User Guide
ISP149C Party Splash Waterproof Bluetooth Enabled Speaker, ISP149C, Party Splash Waterpr
oof Bluetooth Enabled Speaker, Splash Waterproof Bluetooth Enabled Speaker, Bluetooth
Enabled Speaker, Enabled Speaker, Speaker

References

- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.