



PF11 Ionchill Automatic Ice Maker User Guide

[Home](#) » [ionchill](#) » PF11 Ionchill Automatic Ice Maker User Guide 

ionchill™ Quickcube Automatic Ice Maker User Guide



Contents

- [1 Introduction](#)
- [2 Features](#)
- [3 What's Included](#)
- [4 Setting Up](#)
- [5 Using the Ice Maker](#)
- [6 Self-cleaning Feature](#)
- [7 Cleaning & Maintenance](#)
- [8 Important Safeguards](#)
- [9 Specifications](#)
- [10 Documents / Resources](#)
 - [10.1 References](#)

Introduction

Quench your thirst easier than ever with the ionchill Quickcube! With just the press of a button, this lightweight, compact ice maker creates ice cubes in as little as 9 minutes, and can make up to 26 lbs. of bullet-shaped ice in 24 hours. Perfect for refreshing smoothies, coffees, cocktails, iced tea and even seafood, the Quickcube is low-noise and ultra-portable, and cleans itself in 30 minutes for ultimate hands-free maintenance.

Features

- Quick and easy ice making with the press of a button.
- Self-cleaning program for hands-free maintenance.
- Low-noise and highly efficient.
- Ultra-portable thanks to its adjustable handle.
- Lightweight and compact design.

What's Included

- ionchill Quickcube
- Ice Scooper
- Ice Basket
- Handle
- User Guide



Setting Up

1. Remove all components from the package.
2. Remove the tape from the ice basket and ice scooper, then thoroughly clean the tank and ice basket.
3. Place the ice maker on a flat, hard surface, away from direct sunlight, and leave 4 inches on each side of the unit.
4. Let the ice maker sit for 2 hours so the refrigerant fluid can settle.
5. To insert the handle into the ice maker, rotate it to the same angle as the mounting hole on the unit, then insert it. Check that it is firmly connected with the ice maker.

Using the Ice Maker

1. Plug the power cord into an AC outlet.
2. Open the top cover, remove the ice basket, and pour clean water into the tank until it reaches the maximum water level line.
3. Press the Power Button on the control panel to begin making ice. It will take approximately 9 minutes depending on the surrounding room temperature.
4. The ice maker will stop making ice when the ice basket is full, and the "Ice Full" indicator will turn on. Scoop ice from the basket and enjoy!

Self-cleaning Feature

1. Press and hold the Power Button for at least 5 seconds.
2. The ice maker will begin its self-cleaning cycle.
The "Ice Full" and "Add water" indicators will flash during the self-cleaning process.

3. After 30 minutes, the indicators will stop flashing.

Drain the water from the inner tank through the drain cap at the bottom of the ice maker.

Cleaning & Maintenance

1. Remove the ice basket from the ice maker.
2. Gently wipe the interior of the ice maker with a soft cloth, warm water and diluted detergent, then use water to rinse the interior. Use a mild detergent solution and warm water to clean the exterior.
3. Drain out any water by unplugging the drain cap on the bottom of the ice maker.
4. Dry both the interior and exterior of the ice maker with a clean, soft cloth.
5. Change the water inside the water tank every 24 hours to maintain proper hygiene.

Important Safeguards

Carefully read these safety precautions to avoid serious personal injury and/or damage to the product:

- Only use the ice maker on a hard, flat surface.
- Do not place your hand in or near the ice maker while it is making ice.
- Do not use the ice maker if its power cord is damaged in any way.
- Unplug the ice maker before cleaning or performing any maintenance on it.
- Use caution when using the ice maker around children.
- Do not cover the cord or submerge it in water.
- Do not use an extension cord with the ice maker.
- Do not tilt or tip the ice maker over.
- Only use water to make ice cubes with the ice maker.
Do not use any other liquid.
- Do not attempt to repair or disassemble the ice maker.
Doing so may void any warranty in place.
- Do not use the ice maker outdoors in direct sunlight, near heat sources, or near water or any other liquid.
- Keep a minimum distance of 4 inches free on each side of the ice maker.

Customer Support

If you have any questions about using the ionchill Quickcube, we are here to help. Call or email us and an experienced customer support representative will be happy to assist you: 1-855-GO-TZUMI or Support@tzumi.com.

Specifications

- Input: 115V/60Hz
- Power: 95W
- Ice cubes per cycle: 9
- Water Tank Capacity: 1.2L
- Ice Basket Capacity: 0.6L
- Weight: 14.55 lbs. (6.6kg)
- Size: 8.74 x 11.57 x 11.42 in.



ionchill Quickcube. Distributed by tzumi Inc. NY, NY 10016. ©Copyright 2023 tzumi Inc. All Rights Reserved. Made in China. All other trademarks and trade names are the property of their respective owners. All pictures shown are for illustration purposes only. Actual product may vary due to product enhancement. Subject to change without prior notice.

⚠ WARNING: This product can expose you to chemicals including DEHP, which is known to the State of California to cause cancer and birth defects or other reproductive harm. For more information go to www.P65Warnings.ca.gov.



Documents / Resources

	ionchill PF11 ionchill Automatic Ice Maker [pdf] User Guide 8958, PF11, PF11 Ionchill Automatic Ice Maker, PF11, Ionchill Automatic Ice Maker, Automatic Ice Maker, Ice Maker, Maker
--	---

References

- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.