



IQUNIX A80 Series Explorer Wireless Mechanical Keyboard User Guide

[Home](#) » [IQUNIX](#) » **IQUNIX A80 Series Explorer Wireless Mechanical Keyboard User Guide** 

Contents


- [1 IQUNIX A80 Series Explorer Wireless Mechanical Keyboard](#)
- [2 Details](#)
- [3 Product Specification](#)
- [4 Three Ways of Connecting Devices](#)
- [5 Function Keys Combinations](#)
- [6 Documents / Resources](#)
- [7 Related Posts](#)



IQUNIX A80 Series Explorer Wireless Mechanical Keyboard



Details




- A Type-C Port B Indicator C Feet
- D Mode Switch
- E Silicone Pads

Product Specification

- Product Name: AVER 80
- Connect Interface: USB Type-C
- Keyboard Type: Mechanical Keyboard
- Cable Length: 180cm
- Key Quantity: 83 Keys
- Dimensions: 321*158*52mm
- Keyboard Material: ABS Case + PBT Keycaps
- Origin: Shenzhen, China
- Character Technology: Dye Sublimation
- Web: www.IQUNIX.store
- Large Key Structure: Costar Stabilizers
- Support E-mail: support@iqunix.store
- Rating: 5Vm1A


Three Ways of Connecting Devices

Bluetooth Connection Mode




1. Toggle the keyboard Mode Switch to wireless side
2. Press FN+1, then hold FN+1 for 5 seconds if the indicator blinks in blue ight. (Bluetooth matching mode on when blue light blinks.)
3. Enable Bluetooth matching (Computer/ Phone / Tablet)
4. Select the matching device [IQUNIX AVER80 BT 1
5. Indicator light turning off when matching successfully. Olf you need to connect a new device, please hold FN+1 for 5 seconds to remove the previous device. When the LED indicator blinks blue light, you can connect your device following the Step 3.

2.4GHz Connection Mode




1. Toggle the keyboard Mode Switch to “wireless mode”()
2. Plug the 2.4GHz receiver into your computer.
3. Press FN+4 to enter 2.4GHz matching mode FN 4 (2.4GHz matching mode on when pink light blinks.)
4. Indicator light turning off means successful matching.

Wired Connection Mode



1. For Wireless Version, toggle the keyboard () On Mode switch to wired side.
2. Plug the USB cable into your device.

Function Keys Combinations



LED Indicator Keys Combinations (RGB Version)




Special Keys Combinations (Hold for 5 Seconds)

Mac / Windows Layout Switching



Special Keys Combinations (Wireless Mode)



LED Indicator Status Description

 Yellow Light Blinking	 Green Light Blinking 3 Times	 Green Light On	 Red Light Blinking
Charging	Charging Completed (Wired Mode)	Charging Completed (Wireless Mode)	Less than 10% (Wireless Mode)

Bluetooth Device Matching

 Blue Light Blinking	 Turquoise Light Blinking
Bluetooth Matching on	Bluetooth Device Re-Connection

Special Status


 White Light Blinking 5 Times	 White Light On
Reset to Default	CapsLock On

2.4GHz Mode

 Pink Light Blinking
Enter 2.4GHz Mode



Mac/Windows Layout Switch



To learn more details, please reach out to us on the official website or social media. Official website: www.IQUNIX.store

Follow us:

Download IQUNIX
IQUNIX Official App



Documents / Resources



[IQUNIX A80 Series Explorer Wireless Mechanical Keyboard](#) [pdf] User Guide
A80 Series, Explorer Wireless Mechanical Keyboard, Mechanical Keyboard, Keyboard