

IQUNIX OG80 Series Mechanical Keyboards User Guide

Home » IQUNIX » IQUNIX OG80 Series Mechanical Keyboards User Guide

Contents [hide

1 IQUNIX OG80 Series Mechanical

Keyboards


- **2 Product Specification**
- 3 Three Ways of Connecting Devices
- **4 LED Indicator Status Description**
 - **4.1 Devices ReConnecting**
 - **4.2 Special Status**
- 5 Mac/Windows Layout Switch
- 6 Documents / Resources
- **7 Related Posts**

IQUNIX

IQUNIX OG80 Series Mechanical Keyboards



- Type-C Port
- Indicator
- Silicone Pads
- Mode Switch



Product Specification

Product Name

OG80

Keyboard Type

Mechanical Keyboard

Key Quantity

83 Keys

Connect Interface

USB Type-C

Dimensions

325*162*45mm

Brand

IQUNIX

Origin

China

Web: www.IQUNIX.store Support E-mail: support@iqunix.store

Three Ways of Connecting Devices


Bluetooth Mode

- Toggle the keyboard Mode Switch to the wireless side.
- Press FN+1, then hold FN+1 for 5 seconds if the indicator blinks in blue light. Bluetooth pairing mode is on when the blue light blinks.
- Enable Bluetooth Pairing Computer / Phone / Tablet.
- Select the pairing device IQUNIX OG80 BT 1
- Indicator light turns off when the keyboard is paired successfully.
- In order to complete the pairing of the keyboard with a second or third new Bluetooth device, repeat the instructions from and replace the "FN+1" with "FN+2" or "FN+3". The devices will be shown as IQUNIX OG80 BT 2 and IQUNIX OG80 BT 3.




2.4GHz Mode

- Toggle the keyboard Mode Switch to the wireless side.
- Plug the 2.4GHz receiver into your computer.
- Press FN+4 to enter 2.4GHz pairing mode 2.4GHz pairing mode on when pink light blinks.
- Indicator light turns off when the keyboard is paired successfully.




Wired Mode


- For Wireless Version, toggle the keyboard Mode Switch to wired side.
- Plug the USB cable into your device.




Function Keys Combinations Windows




Backlightn Keys Combinations RGB Version





Battery Level Check
The LED Indicator blinks 1, 2, 3,...10 times,
which stands for 10%, 20%, 30%,...100% battery level

Special Keys Combinations Hold for 5 Seconds



LED Indicator Status Description

Device Charging and Battery Status

Yellow light Blinking3 Times

Charging

Green Light Blinking 3 Times

• Charging Completed Wired Mode

Green Light On

• Charging Completed Wireless Mode

Red Light Blinking

• Less than 10% Wireless Mode

Bluetooth Device Pairing

- Blue Light Blinking
- Bluetooth Pairing On

2.4GHz Mode

- · Pink Light Flashing
- Entering 2.4GHz Mode

Devices ReConnecting

Blue Light Blinking

• Bluetooth Device #1 ReConnecting

Turquoise Light Blinking

Bluetooth Device #2 ReConnecting

Yellow Light Blinking

• Bluetooth Device #3 ReConnecting

Pink Light Blinking

• 2.4GHz Device ReConnecting

Special Status

White Light Blinking 3 Times

• Special Keys Combination Enabled

White Light Blinking 5 Times

Reset to Default


White Light On

• CapsLock On



Mac/Windows Layout Switch

Hold for 5 seconds to switch the layout between macOS and windows systems



To learn more details, please reach out to us on official website or social media. Official website: www.lQUNIX.store

Documents / Resources



IQUNIX OG80 Series Mechanical Keyboards [pdf] User Guide

OG80 Series, Mechanical Keyboards, OG80 Series Mechanical Keyboards



IQUNIX OG80 Series Mechanical Keyboard [pdf] User Guide

OG80, 2A7G9-OG80, 2A7G9OG80, OG80 Series Mechanical Keyboard, OG80 Series, Mechanical Keyboard

Manuals+, home

privacy