



ITC 21060-001 Color Module Installation Guide

[Home](#) » [ITC](#) » ITC 21060-001 Color Module Installation Guide 

Contents

1 ITC 21060-001 Color Module

2 PARTS / TOOLS NEEDED

3 Safety Instructions

4 DIMENSION

5 Documents / Resources

5.1 References


6 Related Posts



ITC 21060-001 Color Module



PARTS / TOOLS NEEDED

				
RGB Fixed Color Module	RGB Lighting (Varies)	Double Stick Tape x 2	Butt Splices (not provided)	Alcohol Wipes (not provided)


Safety Instructions

- Disconnect power before installing, adding or changing any component.
- To avoid a hazard to children, account for all parts and destroy all packing materials.
- Do not install any luminaire assembly closer than 6" from any combustible materials.
- Positive (+) outputs require a fuse if the attached wire leads are not rated to handle the max current


DIMENSION

1. Determine the installation location for your color module. Make sure to consider the size of the module (3.2"L x 2"W x 0.8"H) when determining your location. Note, it will require room for access and for wiring. Once determined, clean the back of the module and the install location with alcohol wipes (not provided). Place the double stick pads (included) on the back of the module as shown below. Remove the paper and stick the module in place.

- Do not mount in area where water can be splashed over unit.




2. Follow the wiring diagram below to wire the module to your system.



For warranty information please visit www.itc-us.com/warranty-return-policy

3030 Corporate Grove Dr.
Hudsonville, MI 49426
Phone: 616.396.1355
itc-us.com

Documents / Resources

	ITC 21060-001 Color Module [pdf] Installation Guide 21060-001 Color Module, 21060-001 Color Module, Color Module
--	--

References

- [ITC ITC Warranty & Return Policy](#)