



ITC 69394 Modular Docking Light Installation Guide

[Home](#) » [ITC](#) » ITC 69394 Modular Docking Light Installation Guide 

Contents

- [1 ITC 69394 Modular Docking Light](#)
- [2 PARTS/TOOLS NEEDED](#)
- [3 Documents / Resources](#)
 - [3.1 References](#)
- [4 Related Posts](#)



ITC 69394 Modular Docking Light



PARTS/TOOLS NEEDED

			
Docking Light	1-1/8" Spade Bit (not provided)	Marine Grade Connectors (not provided)	Power Drill (not provided)


IMPORTANT SAFETY INSTRUCTIONS. READ CAREFULLY FOR YOUR PROTECTION AND SAVE ALL INSTRUCTIONS.

- Disconnect power before installing, adding or changing any component.
- To avoid a hazard to children, account for all parts and destroy all packing materials.
- It is recommended that fuse protection be added to the positive (+) input.


1. Determine the installation location for your light and drill a hole using a spade bit.



2. Wire the light following the wiring diagram below.



3. Insert light and tighten nut on the back.



For warranty information please visit www.itc-us.com/warranty-return-policy
DOC #: 710-00167

- Rev A
- 05/28/20

ADDRESS: 3030 Corporate Grove Dr. Hudsonville, MI 49426
Phone: 616.396.1355
itc-us.com

Documents / Resources

	ITC 69394 Modular Docking Light [pdf] Installation Guide 69394 Modular Docking Light, 69394, 69394 Light, Modular Docking Light, Docking Light, 69394 Docking Light, Modular Light, Light
--	--

References

-  [ITC Warranty & Return Policy](#)