



ITC 69502 Button Light Instruction Manual

[Home](#) » [ITC](#) » ITC 69502 Button Light Instruction Manual 

Contents

- [1 ITC 69502 Button Light](#)
- [2 PARTS/TOOLS NEEDED](#)
- [3 INSTALLATION](#)
- [CONSIDERATIONS](#)
- [4 Documents / Resources](#)
 - [4.1 References](#)
- [5 Related Posts](#)



ITC 69502 Button Light





PARTS/TOOLS NEEDED

				
Button Light	Power Drill	Butt Splice Connectors (Not Provided)	Wire Grommet (Not Provided)	Silicone Sealant (Not Provided)



INSTALLATION CONSIDERATIONS

- Disconnect power before installing, adding or changing any component.
- To avoid a hazard to children, account for all parts and destroy all packing materials.
- It is recommended that fuse protection be added to the positive (+) input.





1. Drill a 3/4" hole (or 1" if using the decorative collar) in your mounting surface. To prevent damage to the wires install a wire grommet.




2. Wire the light based on the wiring diagram. Feed wires back into the hole and push the light in place. Use silicone sealant to hold it in place.

3030 Corporate Grove Dr.
Hudsonville, MI 49426
Phone: 616.396.1355
itc-us.com

For warranty information please visit www.itc-us.com/warranty-return-policy DOC #: 710-00036 • Rev C • 04/07/20

Documents / Resources

	<p>ITC 69502 Button Light [pdf] Instruction Manual 69502 Button Light, 69502, Button Light</p>
--	--

References

- [ITC ITC Warranty & Return Policy](#)