



JABLOTRON PS-001 Parking Sensor Instructions

[Home](#) » [JABLOTRON](#) » JABLOTRON PS-001 Parking Sensor Instructions 

Contents

- [1 JABLOTRON PS-001 Parking Sensor](#)
 - [1.1 Technical Specification](#)
- [2 Documents / Resources](#)
- [3 Related Posts](#)



JABLOTRON PS-001 Parking Sensor





PS-001 Parking sensor

The kit contains 4 ultrasonic sensors to be installed in the rear plastic bumper. The main unit and the speaker are designed for installation into the interior of a car .

Technical Specification

- **Power** 10 to 16 V DC
- **Current consumption** 20 to 200 mA
- **Frequency of sensors** 40 kHz 4 / PS-SEN.S28
- **Number of sensors / sensor type** 4 / PS-SEN.S28
- **Detection distance** 0.4 to 1.5 meters
- **Temperature** -30 to 70 ° C
- **Speaker dimensions** (diameter x height without handles) 42×16 mm

Documents / Resources

	JABLOTRON PS-001 Parking Sensor [pdf] Instructions PS-001 Parking Sensor, PS-001, Parking Sensor, Sensor
---	---