



# How Do I Set My Jabra Sevice as the Default Audio Device on my Windows Computer? User Manual

[Home](#) » [Jabra](#) » How Do I Set My Jabra Sevice as the Default Audio Device on my Windows Computer? User Manual 

## Contents

- [1 How Do I Set My Jabra Sevice as the Default Audio Device on my Windows Computer?](#)
- [2 Documents / Resources](#)
  - [2.1 References](#)
- [3 Related Posts](#)



**How Do I Set My Jabra Sevice as the Default Audio Device on my Windows Computer?**



### How do I set my Jabra device as the default audio device on my Windows computer?

To manually set your Jabra device as the default audio device, follow these steps.


1. Open the Sound settings on your computer. For example, in the taskbar, right-click the Sound icon, and then click Open Sound settings





2. In the Output and Input sections, select your Jabra device from the drop-down lists.  
If you are using a Jabra wireless device, select the connected Bluetooth adapter, such as the Jabra Link 380.

<https://www.jabra.com.au/supportpages/jabra-evolve-75/7599-848-109/faq/953231e4-5462-4618-924b-92a221cb0350>

## Documents / Resources

	<p><a href="#"><u>Jabra How Do I Set My Jabra Sevice as the Default Audio Device on my Windows Computer?</u></a> [pdf] User Manual</p> <p>How Do I Set My Jabra Sevice as the Default Audio Device on my Windows Computer</p>
---	---

## References

-  [\[FAQTitle\] | Jabra Evolve 75 SE - UC Stereo | FAQ | Jabra Support](#)
-  [How do I set my Jabra device as the default audio device on my Windows computer? | Jabra Evolve 75 SE - UC Stereo | FAQ | Jabra Support](#)