

Jawbone Jambox Wireless Bluetooth Speaker User Guide

Home » Jambox » Jawbone Jambox Wireless Bluetooth Speaker User Guide 12

Contents

- 1 Jawbone Jambox Wireless Bluetooth Speaker User
- **2 SAFETY INFORMATION**
- **3 CONNECT TO JAMBOX**
- **4 Product Functions**
 - **4.1 BUT TONS**
 - 4.2 IF THE LED DRINGIS . . .
- **5 POWER UP**
- **6 GET CONNECTED**
- **7 GET LISTENING**
- **8 PERSONALIZE & UPDATE**
 - 8.1 PE RSONALI Z E
 - **8.2 UPDATE**
- 9 TROUBLESHOOTING
- 10 SPECIFICATIONS
- 11 FCC Compliance
- 12 Related Posts



Jawbone Jambox Wireless Bluetooth Speaker User Guide



WELCOME

Welcome to your new Jawbone® JAMBOXTM, the world's first intelligent speaker and speakerphone. JAMBOX delivers killer wireless audio without the hassle of cables and docking stations. JAMBOX also gives you the freedom to share music, movies, games and calls whenever you want. It's the perfect companion to any phone, mp3 player, tablet or laptop.

Whatever your jam may be, amp it up with JAMBOX.

SAFETY INFORMATION

WARNING

Please read these safety warnings and cautions carefully to ensure your personal safety and prevent property damage.

Fire and Electric Shock Hazard

- Do not expose your Jawbone® Speaker to liquid, moisture, humidity, or rain. Do not use the Jawbone® Speaker near a bathtub, sink, sauna, pool, or steam room. Exposure of the Jawbone® Speaker to moisture could result in electric shock.
- Do not drop, disassemble, open, crush, bend, deform, puncture, shred, microwave, incinerate, paint, or insert foreign objects in to the Jawbone® Speaker. Such actions could result in electric shock.
- Clean the Jawbone® Speaker only with a dry cloth.
- Do not expose your Jawbone® Speaker to extremely high or low temperatures.
- Do not leave your Jawbone® Speaker in direct sunlight for extended periods of time.
- Do not leave your Jawbone® Speaker near open flames such as cooking burners, candles, or fireplaces.
- Do not block any ventilation openings.

Battery/Charger Hazard

- Do not dispose of your Jawbone® Speaker in a fire. The battery could explode causing injury or death.
- Only charge the battery in accordance with the user instructions supplied with the Jawbone® Speaker.
- Do not attempt to disassemble the Jawbone® Speaker charger or force open the built-in battery because this may result in electric shock.
- Do not charge the Jawbone® Speaker in damp areas or in extremely high or low temperatures because this could result in electric shock.
- Do not clean the Jawbone® Speaker when it is being charged. Always unplug the charger first before cleaning the Jawbone® Speaker.

Automobile Accident Hazard

• Do not leave or store the Jawbone® Speaker or any of its accessories near or over your automobile's airbag

because serious injury may result when an air bag deploys.

Fall Hazard

• Do not place the Jawbone® Speaker on high surfaces such as shelves. During music playback, the Jawbone® Speaker may move which could cause the Jawbone® Speaker to shift and fall off of the edge.

CAUTION

- Do not use abrasive cleaners to clean your Jawbone® Speaker because this could cause scratches and damage.
- Do not bring your Jawbone® Speaker in to contact with any sharp objects because this could cause scratches and damage.
- Do not insert anything into your Jawbone® Speaker unless otherwise specified in the user instructions. This may damage the internal components.
- Do not attempt to repair, modify, or disassemble your Jawbone® Speaker yourself, it does not contain any user-serviceable components.
- Do not attempt to replace your Jawbone® Speaker battery, it is built-in and is not changeable.
- Use only the manufacturer-supplied charger to charge your Jawbone® Speaker. Other chargers may look similar, but using them could result in electric shock and could damage the Jawbone® Speaker.
- Observe all signs and displays that require an electrical device or RF radio product to be switched off in designated areas.
- Turn off your Jawbone® Speaker prior to boarding an aircraft. Do not use the Jaw bone® Speaker inside an aircraft unless allowed by your airline.
- Dispose of the Jawbone® Speaker and the Jawbone® Speaker's battery in accordance with local regulations. Do not dispose of the battery with regular household waste.


CONNECT TO JAMBOX



CHARGE & UPDATE JAMBOX



Product Functions



BUT TONS

TALK BUTTON

Use this button to answer or end a call, access DialApps like Voice Dial (press and hold for 2 seconds) or hear battery status updates (single press).

VOLUME CONTROL S

Increase and decrease volume using the P LUS and M I NUS BUT TONS on JAMBOX.

IF THE LED DRINGIS ...

• FLASH I NG WH ITE

JAMBOX is trying to connect to your phone or Bluetooth® device.

• FLASH I NG RE D

The battery is low. Power up!

• FLASH I NG RE D + WH ITE

JAMBOX is in pairing mode and ready to connect to your phone or Bluetooth® device. Go to your phone's Bluetooth® settings to connect.

POWER UP

Your Jawbone® JAMBOX™ is partially charged and ready to use right out of the box.

• FOR A FULL CHARGE

Plug JAMBOX into your wall charger or computer via micro USB cable.

• TO HEAR THE REMAINING BATTERY LIFE

Press the TALK BUTTON when not on a call.

WHEN THE BATTERY IS LOW

The LED RING flashes RED.

WHEN FULLY CHARGED

The LED RING turns WHITE.

NOTE It takes 1.5 hours to give your JAMBOX an 80% charge. A full charge takes 2.5 hours.

GET CONNECTED


CONNECTION OPTIONS

Connect to JAMBOX™ wirelessly via Bluetooth® or via 3.5mm stereo input.



When using JAMBOX as a speakerphone, please note that JAMBOX's built-in microphone only works while connected via Bluetooth.

CONNECT WIRE LESS LY



Your JAMBOX can wirelessly stream audio from any Bluetooth device within 33 feet. Just follow the steps on the next page.

PREPARE YOUR JAMBOX FOR PAIRING

- 1. Hold the ON/OFF SWITCH in the utmost position for about 3 seconds.
- 2. Wait for the LED RING to flash red & white.
- 3. You will hear JAMBOX say that it is ready to pair.
- 4. Release the ON/OFF SWITCH to the middle/on position.

PRE-PARE YOUR PHONE OR DEVICE

Turn on Bluetooth®.

• ON AN IPHONE ®, IPOD ®, OR IPAD ®

Go to S E T TI NGS > GENE RAL > and enable BLUE TOOTH

• ON A BLACKBERRY®

Go to S E T TI NGS/OP TI ONS > B LUE TOOTH and enable BLUE TOOTH

• OTHER CELL PHONES

Go to JAWBONE .COM/PAIR ING or review the instruction manual that came with your phone.

MAKE THE CONNECTION ON

Go to your device's Bluetooth® settings.

• ADD OR SEARCH FOR DEVICES

When "Jawbone JAMBOX" appears, select it.

IF ASKED FOR A PASSCODE

Enter "0000"

This is a one-time event per device. To pair your Jawbone JAMBOX to another device, repeat steps 1.2 to 1.4.

OR P LUG & P L AY

No Bluetooth? JAMBOX also connects via 3.5mm stereo input.



Play audio from any device with a headphone jack or audio output.

GET LISTENING

GET THE BEST SOUND

For best listening results, make sure your Jawbone® JAMBOX™ is resting on its base and facing forward. When connected wirelessly via Bluetooth®, it's best to turn the volume on your phone/device fully up and then use the P LUS and M I NUS BUT TONS on your JAMBOX.

When connected via 3.5mm stereo input, your phone/device may distort the audio signal if turned up too loud. Turn down

the volume on your phone/device before adjusting the volume on your JAMBOX.

WHISPERS INfO

Jawbone JAMBOX tells you important information like the remaining battery life and caller ID for incoming calls.

BATTERY LIFE

Press the TALK BUTTON to hear the remaining battery life. When your battery is low, you will hear automatic battery status alerts.

CONNECT ON PRIOR IT Y

Incoming and outgoing calls will always take precedence over audio playback. Audio content via 3.5mm stereo input will override wireless audio via Bluetooth. Your JAMBOXTM can be used as a wireless speakerphone. Just speak in the direction of the front grill. The built-in microphone only works when connected via Bluetooth®.

ANSWER/ENDACALL

Press the TALK BUTTON on your Jawbone® JAMBOX to both answers and end a call.

DECLINE AN INCOMING CALL

Hold the TALK BUTTON for 2 seconds.

MAKE A CALL

Use your phone to dial as usual. Listen and talk through your Jawbone JAMBOX.

ACTIVATE DIAL APP

Hold the TALK BUTTON until you hear a beep, then release and follow the voice prompts. Voice Dial is preloaded.

REDIAL LAST NUMBER

Press the TALK BUT TON twice.

MUTING

Mute the built-in microphone by holding the P LUS and M I NUS BUT TONS for 2 seconds until you hear a beep

SIMU LIGNEOUS CALLS

To answer another call, just press the TALK BUTTON.

PERSONALIZE & UPDATE

Jawbone® MY TALK lets you personalize and update your Jawbone JAMBOX™ via the web.

Visit MYTALK.JAWBONE.COM

NOTE To be recognized by MYTALK, your JAMBOX must be turned Off when plugging in via USB.

PE RSONALI Z E

AUDIO APPS

Change the voice that tells you information like remaining battery life and caller ID.

DIAL APPS

Customize your TALK BUTTON to speed dial your favorite number, or link directly to 411, voice-to-text, and other voice services.

INNOVATIONS

Try our newest software creations designed exclusively for Jawbone products.

UPDATE

SOFTWARE

Make sure you are using the latest version of the Jawbone JAMBOX software by logging on to MYTALK.JAWBONE.COM and plugging in. JAMBOX must be turned off.

TROUBLESHOOTING

1. 1 HEARING DISTORTION

- Lower the volume on your JAMBOX™ and/or phone/device. (See section 2.1 Get The Best Sound)
- B Make sure it's charged up. Check for low battery, then charge JAMBOX via USB.

2. NOT LOUD ENOUGH?

- Turn up the volume on your phone/device or your JAMBOX.
- B Make sure it's charged up.
- C Plug JAMBOX in to your phone/device via 3.5mm stereo cable.

3. UNABLE TO PAIR WITH BLUETOOTH® DEVICE?

- 1. Confirm that your phone/device is Bluetooth is compatible.
- 2. B Follow GET CONNECTED instructions in this guide (page 7).
- 3. C Visit www.jawbone.com/support

4. EXPERIENCING SIGNAL LOSS OR DROPOUTS VIA BLUETOOTH?

- 5. Move Jawbone JAMBOX closer to your phone/device.
- 6. B Make sure it's charged up.

7. C Turn off your JAMBOX and phone/device, then power up and reconnect.

SPECIFICATIONS

- BATTERY LIFE About 8 hours (varies by volume level and audio content)
- POWER 2W x 2 < 0.1%THD
- OUTPUT 85dB @ 0.5m
- FREQUENCY 60Hz 20kHz
- AC ADAPTER 5V550mA Max 2.5W DIMENSIONS 151mm x 57mm x 40mm WEIGHT 347g (12oz)
- BLUETOOTH® RANGE 33ft (10m)

FCC Compliance

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- 1. This device may not cause harmful interference, and
- 2. This device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

FCC I D: V3 J - J B E. I C: 7589A-JBE.

To locate the FCC and IC identification numbers, please look on the underside of the Jawbone® Speaker. Please only use with the power supply adapter provided, Jawbone model number S PA- K 9 01. When you see this symbol on an Aliph product, do not dispose of the product with household waste.

GET MORE HELP (IF YOU NEED IT)

VISIT jawbone.com/support for video tutorials
CALL 1 – 877 – 254 – 7426
Go to jawbone.com/warranty for warranty info
Purchase Jawbone products and accessories at www.Jawbone.com
Become a fan of Jawbone on Facebook®
Visit JAWBONE.com/FACEBOOK
©2010 ALIPHCOM. ALL RIGHTS RESERVED. 770 – 00061 REV 1

Download PDF: Jawbone Jambox Wireless Bluetooth Speaker User Guide

Manuals+