



JAR SYSTEMS REBBCU32 USB-C Charging Retrofit for Cube Cart User Guide

[Home](#) » [JAR SYSTEMS](#) » JAR SYSTEMS REBBCU32 USB-C Charging Retrofit for Cube Cart User Guide 

JAR SYSTEMS REBBCU32 USB-C Charging Retrofit for Cube Cart User Guide



Version A

#M00025

Last Modified 06/21/2024

For a copy of the most up-to-date manual, please contact a

JAR Systems representative or visit:


JAR-Systems.com/Support

Contents

- [1 Installation Instructions](#)
- [2 Quick Start](#)
- [3 Normal Operation](#)
- [4 Trouble-Shooting](#)
- [5 Disclaimer](#)
- [6 Warranty](#)
- [7 Documents / Resources](#)
 - [7.1 References](#)
- [8 Related Posts](#)

Installation Instructions


- Quick-Sense 16-Port Charging Hubs




- USB-C Cables



- Mounting Brackets



- M3 Anti-theft Screws




- M5 Anti-Theft Screws




- Torx Key T25



- M5 Nut with Crown



- Wrench for Nuts M5




- Spring Washer




- Washer




- Power Cord




- T10 H Torx Tool



1. Secure the mounting brackets to the sides of the cart using the T25 Torx key and 2 M3 screws each. Make sure to align and level both sides. On the top brackets, install in the 3rd vent holes from the bottom up. At the bottom, use the first vent hole from the bottom. Make sure that the cut-out in the bracket is facing the front of the cart.



2. Pass one end of each power cord to the back of the cart. Connect the other ends of the power cords to the hubs and set the hubs on the mounting brackets. Align the hubs with the screw holes on the brackets and secure them using M5 screws and lock nuts.



3. Access the back of the cart and connect the power cables to the power strip. Plug in the cart and connect your devices.



Quick Start

1. Connect cart to power source
2. Plug in powered down devices
3. Connected devices will automatically charge as efficiently as possible
4. Connect/disconnect devices any time



LED Charging Port Indicator Lights



White: Port Ready



Blue: Device Charging



Green: Charge Level >90%

Normal Operation

- Plug the power cable into a standard 15A outlet. LEDs will illuminate white to indicate the cart is connected to a power source.
- Power off devices fully before connecting them to the cart for charging.
- Connect the devices to the USB-C charging cables.

Ensure that devices are placed in the cart so that the charging ports are as close as possible to the USB-C charging port on the cart. Incorrectly connecting devices can strain the cable over long periods of time and lead to damage.

- You may hear a clicking sound, and the LED lights will change color according to the power draw of the attached devices.
- The system will automatically limit power consumption by turning some of the USB-C ports off temporarily.
- Refer to the device for the level of charge. Connected devices will charge as fast and evenly as possible, up to 65W, without drawing too much power.
- To remove devices from the carts with the greatest level of charge first, disconnect devices with the green LEDs first before you disconnect devices with the blue LEDs.
- Devices that do not feature a USB-C charging port can be charged using USB-C emulator cables. (Not Included, contact JAR Systems for more info)



Trouble-Shooting

Always start troubleshooting with a simple reboot

Unplug and replug the power cord. When the cart is connected to power, the LEDs will change color based on the power draw of connected devices (see light indication).

Single Port or Device Issue

Ensure that both of the USB-C cable ends plug into the cart and the device correctly.

If there is still no charge, disconnect the device from that port (A) and plug into another port (B). If it is still not charging, it may be an issue with the device.

If charging begins when using port (B), exchange the cable from port (B) to port (A). If it begins to charge, the cable (A) is defective and will need to be replaced.

Entire Charging Hub/Shelf Issue

Check the back of the charging hub to see if the cart's power cable is plugged in and connected correctly. When the cart is powered back on, the LED lights will begin to illuminate.

Remove/Replace USB-C Cables

Each cable lock may be secured with up to three screws. Remove all screws with the supplied Torx key. Remove the cable lock. Unplug the cables from the USB-C ports and route them through the cable track. Reverse the process to replace a cable.



Warnings

- Power down all devices prior to connecting them to the hub for charging.
- Keep away from moisture and harsh chemicals. Do not place any liquids near the charging cart.
- Any electrical equipment must be used by an adult or with adult supervision.
- Do not connect unsupported items to the cart or use for any purpose other than its intended use.
- Do not attempt to obstruct any ventilation openings or dismantle, open, or modify the system in any way.
- Do not sit or stand on the cart or charging hubs.
- Do not use an extension cable or daisy-chain to any other devices.
- Not intended for operation at altitudes greater than 2000 m or 6561 ft above sea level and should not be used in extreme temperatures. For indoor use only.

Disclaimer

Failure to read, thoroughly understand, and follow all instructions can result in serious personal injury, damage to equipment, or voiding of factory warranty. Since the use of this information, the equipment connected, and the conditions by which any JAR Systems product is used is beyond the control of JAR Systems, it is the obligation of the owner and/or user to determine the correct and safe use of any equipment and product. To the extent that the law permits, any liability which may be incurred as a result of the use or future use of a product manufactured or sold by JAR Systems is limited to the cost of repairing or replacing the failed product or component at the discretion of JAR Systems either within, or outside of warranty periods, and does not extend to any loss or damage which may be caused as a consequence of misuse or failure of the equipment, product or the information contained herein. JAR Systems shall not in any event be liable for economic loss of profits, indirect, special, bodily injuries or consequential damages. Specifications and images are for illustration purposes only. Final product may differ and is subject to change without notice.

Warranty

This product comes with a warranty that covers any defects in material or workmanship and extends to the original consumer of the product only. JAR Systems, LLC will replace the product with a new or refurbished product, repair the product, send replacement parts, or refund the purchase price of the product, at JAR Systems, LLC's discretion. This warranty does not cover accidental damage, unreasonable use, neglect, tampering or other causes not arising from defects in material or workmanship.

Any implied warranties last only as long as the warranty periods listed above except where state law does not allow limitations on how long an implied warranty lasts.

This includes but is not limited to the implied warranties or merchant ability and fitness. JAR Systems, LLC's responsibility is limited to the actions listed above and nothing else.

This warranty does not cover, and JAR Systems, LLC will not be responsible for, any damages due to loss of use of the product, or any other costs or expenses incurred by you or anyone else who uses the product, whether due to defects, breach of contract, negligence, strict liability or otherwise. JAR Systems is not liable for any indirect,


special, incidental or consequential damages related to the product or this warranty. Some states do not allow exclusions or limitations on consequential or incidental damages, so these limitations or exclusions may not apply.

This warranty gives you specific legal rights and you may also have other rights that vary from state to state. This warranty is governed by the laws of Florida, excluding its conflict of laws principles, unless your state requires that its law be used. Contact JAR Systems for information on the length of warranty on your product(s).

3 For Additional Support
Call: 866.393.4202
or
Email: Support@JAR-Systems.com

JAR SYSTEMS

Documents / Resources

	<p>JAR SYSTEMS REBBCU32 USB-C Charging Retrofit for Cube Cart [pdf] User Guide REBBCU32, REBBCU32 USB-C Charging Retrofit for Cube Cart, USB-C Charging Retrofit for Cube Cart, Charging Retrofit for Cube Cart, Retrofit for Cube Cart, Cube Cart, Cart</p>
---	---

References

- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.