



JAXSUNNY HG61X1227 Rustic X Shape Flip Top Side Table of User Manual

[Home](#) » [JAXSUNNY](#) » JAXSUNNY HG61X1227 Rustic X Shape Flip Top Side Table of User Manual 

Contents

- [1 JAXSUNNY HG61X1227 Rustic X Shape Flip Top Side Table of](#)
- [2 You need](#)
- [3 Hardware List](#)
 - [3.1 Product Assembly](#)
- [4 Documents / Resources](#)
- [5 Related Posts](#)



JAXSUNNY HG61X1227 Rustic X Shape Flip Top Side Table of



Dear Customer,

Thank you for your purchase.

JAXSUNNY is committed to providing affordable high-quality furniture worldwide.

Each piece is made with the respect for human and the environment.

Thousands of families use JAXSUNNY products as a home fashion.

When you receive the product, please make sure that all the parts are intact.

Then please browse the entire installation manual before assembly.

If problems occur unsatisfactorily as follows:


- a. The outer box is damaged.
- b. The product is damaged / bent / cracked while you open the box.
- c. The parts / accessories / assembly tools are missing.
- d. The product is hard to assemble.
- e. The instructions are not clear and can not be referred to.
- f. The product has functional problems.
- g. Other aspects that you are not satisfied with.

Please do not hesitate to contact us for help (Be sure to mark the SKU NUMBER, e.g., HG91S0320, and the TRACKING NUMBER).

Our JAXSUNNY team with factory direct after-sales service will reply within 24 hours and will do our best to resolve the problem for you. Our services are available at any time.


You need

1 Tools required




A Phillips head screwdriver is required for the assembly of this product. (not included)





























Power tools should not be used to assemble this product.



2 1 person is needed




Hardware List


	①	1PC
	②	1PC
	③	1PC
	④	1PC
	⑤	1PC
	⑥	1PC
	⑦	1PC
	⑧	1PC
	⑨	1PC
	⑩	1PC
	⑪	1PC
	⑫	1PC
	⑬	1PC
	⑭	1PC
	⑮	1PC
	⑯	1PC
	⑰	2PCS
	⑱	2PCS
 Φ15 x 10mm	A	21PCS
	B	21PCS
 M6 x 30mm	C	4PCS
 M4 x 35 mm	D	4PCS
 M4 x 14mm	E	10PCS
	F	1PC
 M6.5 x 50mm	G	4PCS
	H	1PC
	I	1PC
 Φ12 x 10mm	J	4PCS

Product Assembly


STEP 1




STEP 3





STEP 4




STEP 5





STEP 6




			
A	4PCS	E	8PCS





STEP 7



STEP 8



STEP 9



Documents / Resources

	<p>JAXSUNNY HG61X1227 Rustic X Shape Flip Top Side Table of [pdf] User Manual HG61X1227 Rustic X Shape Flip Top Side Table of, HG61X1227, Rustic X Shape Flip Top Side Table of, Flip Top Side Table of</p>
---	---