



JBC PHST Table Built In Panel for PHS Instruction Manual

[Home](#) » [JBC](#) » JBC PHST Table Built In Panel for PHS Instruction Manual 

JBC PHST Table Built In Panel for PHS

Contents

1 ARSALAN POST COMPLETE

- 1.1 Packing List
- 1.2 Features
- 1.3 Options
- 1.4 Assembly
- 1.5 Specifications
- 1.6 Customer Support
- 1.7 Documents / Resources
 - 1.7.1 References

ARSALAN POST COMPLETE



This manual corresponds to the following reference:
PHS-STA


Packing List

The following items should be included:

- Table-Built-In Panel for PHS1 unit



- Windowed Cover for PHS 1 unit



- Small Cover for PHS 1 unit



- Screws 6 units
Velox 4×20 – zinc plated in black




- Manual 1 unit
Ref. 0019676




Features

PHST comes with four covers, which can be used interchangeably depending on your needs. See the different usage options on the next page.


- Cover for Console:



- Cover for PHS



Windowed Cover for PHS:



- Small Cover for PHS:





Table-Built-In Panel for PHS is designed to accommodate the preheater unit and its console and to be integrated into the workbench.




Options

Cover and protect the work space using the different covers provided with PHST.

The console can be covered by the console cover. For the other three PHS covers see the following usage options:


Option 1:

While working with the preheater, the side area next to the heating zone can be covered using the windowed cover for PHS.




Option 2:

When work is no longer in progress, the entire preheater area can be covered. The cover protects the preheater and keeps more space free on the workbench.





Option 3:

While working with the preheater and the support, the side area next to the support can be covered using the small cover for PHS.





Note: If the preheater is used the other way round, all preheater covers can also be fitted the other way round.



Assembly

Cut an opening on your work table according to the dimensions on the drawing (see next page). Fit the panel into the opening and fix it to your workbench with the supplied screws.

Opening Dimensions for Panel Installation



mm / in

Specifications

PHST
Table-Built-In Panel for PHS
Ref. PHS-STA

Product Dimensions: (L x W)	602 x 302 mm 23.7 x 11.9 in
Package Dimensions (L x W x H)	640 x 350 x 120 mm 25.2 x 13.78 x 4.72 in
Complies with CE standards. ESD Safe.	

Warranty

JBC's 2 year warranty covers this equipment against all manufacturing defects, including the replacement of defective parts and labor. Warranty does not cover product wear or misuse. In order for the warranty to be valid, equipment must be returned, postage paid, to the dealer where it was purchased.



This product should not be thrown in the garbage. In accordance with the European directive 2012/19/EU, electronic equipment at the end of its life must be collected and returned to an authorized recycling facility.




Customer Support

www.jbctools.com

JBC

Documents / Resources

 <p>JBC www.jbctools.com INSTRUCTION MANUAL</p> <p>PHST Table Built-In Panel for PHS</p>	<p>JBC PHST Table Built In Panel for PHS [pdf] Instruction Manual</p> <p>PHS-STA, PHST Table Built In Panel for PHS, PHST, Table Built In Panel for PHS, Built In Panel for PHS, Panel for PHS, PHS</p>
---	---

References

- [User Manual](#)

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.