

**JENSEN®
CD-65 Portable
Personal CD
Player**



Jensen CD-65 Portable Personal CD Player User Manual

[Home](#) » [Support](#) » Jensen CD-65 Portable Personal CD Player User Manual 

Contents

- [1 Jensen CD-65 Portable Personal CD Player](#)
- [2 Introduction](#)
- [3 Specifications](#)
- [4 Package Includes](#)
- [5 Features](#)
- [6 Usage](#)
- [7 Care and Maintenance of Jensen CD-65 Portable Personal CD Player](#)
- [8 Troubleshooting for Jensen CD-65 Portable Personal CD Player](#)
- [9 Pros and Cons](#)
- [10 Warranty](#)
- [11 FAQs](#)
- [12 References](#)
- [13 Related Posts](#)

JENSEN®

Jensen CD-65 Portable Personal CD Player



Launch Date: December 1, 2022

Price: \$29.99

Introduction

For music fans who are always on the go, the Jensen CD-65 Portable Personal CD Player is a small and easy-to-carry option. This CD player plays high-quality music from CD, CD-R, CD-RW, and MP3 CDs, even though it is rather small and light. The Jensen CD-65 is a great pocket music player that you can take with you when you're working out, driving, or traveling. It has an LCD screen that is easy to read, different playing modes like repeat, random, and start, and an anti-skip safety system that keeps playback smooth even when you move. The player can be charged by either two AA batteries or an AC adapter, so it can be used anywhere. The Jensen CD-65 also has a 3.5mm headphone jack or an AUX input for better sound quality, so you can listen to your music in a variety of ways. The Jensen CD-65 is a great portable CD player that is easy to use and reliable. It lets you enjoy great music wherever you are.

Specifications

- **Brand:** Jensen
- **Model:** CD-65
- **Connectivity:**
 - 3.5mm headphone jack
 - AUX input for external speakers
- **Display:** LCD screen for track information and playback status
- **Battery Type:**
 - 2 AA batteries (not included)

- AC adapter (sold separately)
- **Playback Formats:**
 - CD
 - CD-R
 - CD-RW
 - MP3 CDs
- **Playback Modes:**
 - Repeat 1
 - Repeat All
 - Random Play
- **Anti-Skip Protection:** Yes, ensuring uninterrupted playback
- **Audio Output:**
 - 3.5mm headphone jack
 - AUX output for connecting to speakers
- **Power Supply:**
 - AC adapter (sold separately)
 - 2 AA batteries (not included)
- **Weight:** 10.6 ounces
- **Dimensions:** 5.5 x 5.5 x 1.5 inches
- **Color:** Black
- **Special Feature:** Portable design for on-the-go listening
- **Included Components:** Owner's Manual
- **Product Dimensions:** 5.5 x 5.5 x 1.5 inches
- **Item Weight:** 10 ounces
- **Item Model Number:** CD-65

Package Includes

- 1 x Jensen CD-65 Portable Personal CD Player
- 1 x User Manual
- 1 x 3.5mm AUX cable (for external speaker connection)

Features

1. Protection Against Skipping

Anti-skip safety built into the Jensen CD-65 makes sure that music plays smoothly even when you're moving around. This feature is particularly helpful when you're walking, running, or traveling because it keeps the sound from being stopped by movement or bumps, so you can listen to music nonstop.

2. Small and Lightweight Design

The Jensen CD-65 is designed to be as portable as possible. It is small and light, so it is easy to take and store. You can take this personal CD player with you anywhere, like when you travel, work out, or just chill out at home. Its small size makes it easy to put into bags or backpacks, so you can listen to music while you're on the go.

3. Different Playback Modes

The Jensen CD-65 has several playing modes that let you change how you listen. You can select Repeat 1, which plays the current track over and over, Repeat All, which plays the whole CD over and over, or Random Play, which mixes up the songs. You can enjoy your music in any way you choose with these choices, whether you want to listen to the same song over and over or find new favorites by playing them in any order.

4. Compatible with several formats

There are many disc types that the Jensen CD-65 can play, such as regular CDs, CD-Rs, CD-RWs, and MP3 CDs. This support gives you more options because you can use the same device to listen to both your old CDs and MP3 files saved on discs.

5. 3.5mm Jack for Headphones

The Jensen CD-65 has a 3.5mm headphone jack for private hearing. You can plug in your best headphones and listen without bothering other people. You can listen to your music without anyone else hearing it, whether you're at home or on the bus. This function makes sure that you can enjoy your own music without using extra speakers.

6. Extra Output for Speakers Outside the System

There is an extra outlet on the Jensen CD-65 that lets you connect the CD player to additional speakers to boost the sound. This is great for listening with family or friends or to make the sound experience more intense at home or in a bigger room.

7. LCD Screen

The Jensen CD-65 has an LCD screen that is easy to read and shows information about the tracks, the state of the playing, and the mode settings. The 60-second LCD screen on the side makes it easy to see important details like the track number, the play mode (repeat, mix, etc.), and how much time is left on the current track. This makes sure you can easily skip tracks without missing a beat while listening to music.

8. Powered by batteries

Two AA batteries (sold separately) run the Jensen CD-65, which makes it great for use on the go. Because it's battery-powered, you can listen to music without having to constantly plug it in or charge it. This is great for when you're on the road or just want to be away from an outlet.

9. Radio AM/FM

Besides being able to play CDs, the Jensen CD-65 also has an AM/FM radio with a digital sound LCD screen. This lets you listen to your favorite radio stations, giving you a wider range of songs to choose from. This tool gives you more ways to have fun, whether you like music, news, or talk radio.

10. Bass Boost for Better Sound

The Bass Boost feature on the Jensen CD-65 improves the sound quality by boosting the low frequencies. This makes your music sound fuller and more lively. This feature makes sure that the sound quality is the best it can be, whether you're listening to a soft acoustic track or a loud pop song.

11. Go Back and Skip/Search Forward

The Jensen CD-65 makes it easy to look through songs and skip ahead or backward. You have full control over your music library with this feature, which makes it easy to find your favorite songs or move between records.

12. Memorable Scripts

The Jensen CD-65 has customizable memory, which means you can make your own set by choosing the songs you want to play and the order you want them to play them in. This is great for people who don't want to manually skip tracks and would rather enjoy a custom mix made right on the CD player.

13. Comes with sport stereo earbuds

The Jensen CD-65 comes with sport sound earbuds for people who like to listen while they're moving. They're

made to fit easily while you're doing active activities like walking or running. They keep your ears safe while you listen to music without having to worry.

14. **Automatic Turn Off**

The Jensen CD-65 has an auto power-off mode that turns the player off after a certain amount of time of inaction to save battery life. This keeps the battery from going to waste when not in use, which makes the player's battery last longer.

15. **LCD Screen with Multiple Functions**

The multi-function LCD screen shows information about your music playing that is easy to understand. It shows information about tracks, radio stations, and settings. You can easily switch between tasks with this feature, which makes the whole user experience easier to understand and less complicated.

Usage

The **Jensen CD-65 Portable Personal CD Player** is simple to use. To start, insert your desired CD into the disc compartment and close the lid. Turn the device on using the power button. For listening privately, plug in a pair of headphones via the 3.5mm jack. If you prefer to play music through external speakers, connect the CD player using the AUX input. You can switch between different playback modes (Repeat 1, Repeat All, or Random Play) using the mode button, and the LCD screen will display track information for easy navigation. When finished, simply turn the device off and remove the CD.

Care and Maintenance of Jensen CD-65 Portable Personal CD Player

1. **Battery Care:** Always remove batteries if the player will not be used for an extended period to prevent leakage.
2. **Cleaning:** Use a soft, dry cloth to clean the device. Avoid harsh chemicals or abrasive materials that could damage the surface.
3. **Storage:** Store the player in a dry and cool location, away from direct sunlight, to prevent overheating and prolong its lifespan.
4. **Disc Care:** Clean CDs with a soft, lint-free cloth, wiping from the center outward, to avoid scratches and ensure smooth playback.

Troubleshooting for Jensen CD-65 Portable Personal CD Player

No Sound or Low Sound Output:

- Check if the headphones or external speakers are properly connected.
- Ensure that the volume is turned up and not muted.

CD Doesn't Play:

- Make sure the CD is inserted correctly with the label side facing up.
- Ensure the CD is clean and free of scratches that could hinder playback.

Skipping or Stuttering Playback:

- Ensure the **anti-skip protection** feature is activated if you're moving or walking while playing.
- Clean the CD and ensure there is no dirt or dust on the lens.

Player Doesn't Turn On:

- Check if the batteries are correctly inserted and are not dead. Try replacing them with fresh AA batteries.
- If using an AC adapter, ensure it's properly plugged into both the CD player and the power outlet.

No Display:

- Ensure that the LCD display is working properly by pressing any buttons to activate it. If it remains unresponsive, check if the batteries need replacing.

Device Freezes or Malfunctions:

- Turn off the device, remove the CD, and restart it to reset the player.
- If problems persist, consult the user manual or contact customer support for further assistance.

Pros and Cons

Pros:

- Compact and lightweight design for portability
- Versatile playback options including radio and programmable memory
- Bass boost feature enhances audio experience

Cons:

- Requires AA batteries which may need frequent replacement
- Limited internal storage for MP3 playback compared to modern devices

Warranty

The Jensen CD-65 comes with a one-year limited warranty covering defects in materials and workmanship. Please retain your purchase receipt for warranty claims.

FAQs

What is the power source for the Jensen CD-65 Portable Personal CD Player?

The Jensen CD-65 can be powered by 2 AA batteries (not included) or an AC adapter (sold separately), offering flexibility for portable or stationary use.

How do I connect the Jensen CD-65 to external speakers?

You can connect the Jensen CD-65 to external speakers using the AUX input, providing amplified sound.

What playback modes are available on the Jensen CD-65?

The Jensen CD-65 offers multiple playback modes including Repeat 1, Repeat All, and Random Play for varied listening experiences.

What playback modes are available on the Jensen CD-65?

The Jensen CD-65 weighs approximately 10.6 ounces, making it lightweight and easy to carry.

What are the dimensions of the Jensen CD-65?

The Jensen CD-65 measures 5.5 x 5.5 x 1.5 inches, offering a compact and portable design.

What kind of batteries does the Jensen CD-65 require?

The Jensen CD-65 operates on 2 AA batteries, which are not included with the player.

What formats are supported by the Jensen CD-65 Portable Personal CD Player?

The Jensen CD-65 supports CD, CD-R, CD-RW, and MP3 CDs, allowing for versatile music choices.

How can I adjust the sound quality on the Jensen CD-65?

The Jensen CD-65 has a built-in bass boost feature, which enhances sound quality for a richer listening experience.

References

- [User Manual](#)

Manuals+. Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.