



Jetson Nitro Hoverboard Electric Scooter Bluetooth Speaker User Manual

[Home](#) » [Jetson](#) » [Jetson Nitro Hoverboard Electric Scooter Bluetooth Speaker User Manual](#) 

Contents


- [1 Jetson Nitro Hoverboard Electric Scooter Bluetooth Speaker User Manual](#)
- [2 WHAT'S IN THE BOX](#)
- [3 FEATURES & SPECS](#)
- [4 CHARGING THE BATTERY](#)
- [5 INDICATOR LIGHTS](#)
- [6 HOW TO RECALIBRATE](#)
- [7 CONNECTING TO BLUETOOTH®](#)
- [8 CARE AND MAINTENANCE](#)
- [9 SAFETY WARNINGS](#)
- [10 ADDITIONAL OPERATION CAUTIONS](#)
- [11 Related Posts](#)




Jetson Nitro Hoverboard Electric Scooter Bluetooth Speaker User Manual



WHAT'S IN THE BOX



1. FRONT LED LIGHTS
2. CHARGING PORT
3. POWER BUTTON



4. CHARGER
5. CHARGING CABLE

FEATURES & SPECS

- Product Dimensions: 24.3" x 7.64"x 7.32"
- Weight Limit: 250 lbs.
- Product Weight: 20 lbs.
- Recommended Age: 13+
- Tire Size: 6.5"
- Max Speed: Up To 12 mph
- Max Range: Up To 10 Miles
- Battery: 36V, 2.0Ah Lithium-Ion
- Motor: 200W*2, Dual Hub Motor
- Charger: 110-240V
- Charge Time: Up To 3 Hours
- Climbing Angle: Up To 15°


CHARGING THE BATTERY

A few must-dos:


- Only use the included charger
- Plug the charger into the wall before the Charging Port
- Don't turn on the Nitro while it's charging (it needs its rest)
- Charge the battery until it is fully charged – up to 3 hours
- Replace the cover over the Charging Port when done
- Remember to have fun!

CHARGING INDICATOR ON THE CHARGER:

- Red Light: The battery is charging
- Green/ Blue Light: Charging is complete



INDICATOR LIGHTS



1. Battery Indicator Light:


- Greenlight – Over 35% power.
- Flashing green light – 20-34% power.
- Red light with an alarm – Less than 20% power. Time to charge!

Warning: If the battery power goes below 10%, the Nitro will automatically turn off as a safety precaution.

Status Indicator Light

Lights up green when you step onto the Nitro. If the Status Indicator Light turns red or if you are having issues with the Nitro, you may need to recalibrate it.

HOW TO RECALIBRATE




Hold for
5 seconds

Follow these simple steps...

1. Place the Nitro on a flat, level surface. Now say something nice to it. Just kidding, but, go ahead if you like.
2. Hold the Power Button (for about 5 seconds) until you are notified of a successful recalibration.
3. Restart the Nitro by turning it off and then on.
4. You're all set! The Nitro is ready to roll.

RIDING THE NITRO

NEUTRAL



TURN LEFT



TURN RIGHT



CONNECTING TO BLUETOOTH®

Your Jetson Nitro is Bluetooth® 4.0 enabled, so you can pair it with the Ride Jetson app on your personal Bluetooth® enabled device. The Ride Jetson app is available for download from the App Store and the Google Play Store, and it's free!

1. Turn on the Nitro.
2. Open the Ride Jetson app on your handheld device.
3. Tap the Bluetooth® symbol in the top left corner of the app. (If you have not activated your Bluetooth® on your handheld device, the app will remind you).
4. Select your Nitro.
5. The default Bluetooth password is 000000. If you would like to customize your password, go to Settings in the

app.

If you are having issues connecting to Bluetooth®, follow these steps...

1. Try restarting the Nitro by turning it off and then on.
2. Click the Scan button to refresh.
3. Restart the Ride Jetson app.
4. Contact Jetson Customer Support for assistance.

MODE SETTINGS

In the Ride Jetson app you can choose from three settings:

- Beginner mode max speed: Up to 8 mph
- Intermediate mode max speed: Up to 10 mph
- Advanced mode max speed: Up to 12 mph

CARE AND MAINTENANCE

RIDING RANGE

The maximum range is 10 miles. However, a lot of factors will affect how far you can go per charge:

- Driving Surface: A smooth, flat surface will increase driving distance.
- Weight: More weight means less distance.
- Temperature: Ride and store the Nitro above 50°F.
- Maintenance: Timely battery charging and maintenance will increase driving distance.
- Speed and Driving Style: Frequent starting and stopping will reduce driving distance.

CLEANING THE NITRO

To clean the Nitro, carefully wipe with a damp cloth, then dry with a dry cloth. Do not use water to clean the Nitro, as the electrical and electronic systems may get wet, resulting in personal injury or malfunction of the Nitro.

BATTERY

- Keep the Nitro away from fire and excessive heat.
- Do not subject the Nitro to intense physical shock, severe vibration, or impact.
- Protect from water or moisture.
- Do not disassemble the Nitro or its battery.
- If there are any issues with the battery, please contact Jetson Customer Support.

STORAGE

- Fully charge the battery before storing. The battery should be fully charged once a month after this.
- To protect against dust, cover the Nitro.
- Store the Nitro indoors, in a dry place, and at a suitable temperature.
- You should bring the Nitro into a warm environment for charging.

SAFETY WARNINGS

- For your safety, please read the user manual and safety warnings carefully, and make sure you understand and accept all the safety instructions. The user will be responsible for any loss or damage caused by improper use.
- Children, the elderly, pregnant women, and those with heart conditions should not use Nitro.
- The rider should not exceed 250 lbs.
- Do not ride at night.
- Do not use near motor vehicles.
- Do not ride after drinking or taking prescription medication.
- Do not ride the Nitro if you have had any head, back, or neck ailments, or prior surgeries in those areas.
- Persons with any mental or physical conditions that may make them susceptible to injury or impair their dexterity or mental capabilities should recognize, understand, and perform all of the safety instructions and be able to assume the hazards inherent in using the Nitro.
- Do not carry items when riding.
- Always wear shoes, a helmet, and appropriate safety gear.
- Prior to each ride, inspect each part of the Nitro to ensure it has been maintained correctly and is functioning properly.
- Always give way to pedestrians.
- Always comply with local traffic laws and regulations.
- Be alert to things in front and far away from you.
- Make sure your feet are always placed securely on the deck.
- The Nitro cannot be ridden by more than one person.
- When you ride the Nitro along with other riders, always keep a safe distance to avoid a collision.
- When turning, be sure to maintain your balance.
- Do not allow distractions when riding, such as answering the phone or engaging in any other activities.
- Avoid riding in the rain or on smooth surfaces such as snow or ice.
- Do not ride on roads with obstacles (such as litter, small stones, etc.).
- Avoid riding in narrow spaces or on steep slopes.
- Avoid riding around flammable gas, steam, liquid, or dust that could cause a fire.
- Never operate the products barefoot and keep shoelaces tied.
- Riding with improperly adjusted brakes is dangerous and can result in serious injury or death.
- Applying brakes too hard or too suddenly can lock up a wheel, which could cause you to lose control and fall. Sudden or excessive application of the brake may result in injury or death.
- Do not ride without proper training. Do not ride at high speeds, on uneven terrain, or on slopes. Do not perform stunts or turn abruptly.
- The area where the Nitro is to be operated should be safe and suitable for safe operation.
- Check whether all safety labels are in place and understood before riding.
- The owner shall allow the use and operation of the unit after a demonstration so that such operators can understand and operate all components of the unit before use.
- Operators shall adhere to all of the manufacturer's recommendations and instructions, as well as comply with all laws and ordinances.
- Only ride the Nitro with adequate daylight conditions for visibility.
- We encourage you to highlight the Nitro, for visibility, by using lighting, reflectors, and signal flags on flexible poles.

CALIFORNIA WARNING

This product can expose you to a chemical such as Cadmium that is known to the State of California to cause cancer or birth defects or other reproductive harm. For more information go to

www.p65warnings.ca.gov/product

MODIFICATIONS

Do not attempt to disassemble, modify, repair, or replace the Nitro or any components of the unit without instruction from Jetson Customer Support. This will void any warranty and can lead to malfunctions that may cause injury.

ADDITIONAL OPERATION CAUTIONS

Do not lift the Nitro off the ground while it is on and the wheels are in motion. This can result in freely spinning wheels, which may cause injury to yourself or others nearby. Do not jump on or off the Nitro, and do not jump while using it. Always keep your feet firmly planted on the deck while in operation. Always check the battery charge before using. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. 1-(888) 976-9904 help@ridejetson.com
www.ridejetson.com

Download PDF: [Jetson Nitro Hoverboard Electric Scooter Bluetooth Speaker User Manual](#)