


JIECANG JCHR35W6A1 Hand Hled Remote Controller User Manual

[Home](#) » [JIECANG](#) » JIECANG JCHR35W6A1 Hand Hled Remote Controller User Manual 

JIECANG JCHR35W6A1 Hand Hled Remote Controller




Contents

- [1 Product Info](#)
- [2 Buttons](#)
- [3 Models & Parameters](#)
- [4 Caution!](#)
- [5 Instructions](#)
- [6 Documents / Resources](#)
- [7 Related Posts](#)

Product Info


- **JCHR35W6A1**

16-channel remote controller Application: Roller shade/Curtain




- **JCHR35W6A2**

Single channel remote controller Application: Curtain




- **JCHR35W6A3**

Single channel dual control remote controller Application: Curtain




- **JCHR35W6A4**

16-channel remote controller Application: Venetian blind



- **JCHR35W6A5**


Single channel remote controller Application: Venetian blind




Buttons

a.Front


- JCHR35W6A1




- JCHR35W6A2




- CHR35W6A3




- JCHR35W6A4



- JCHR35W6A5




b. Back



d. Low Voltage Warning

(only apply to JCHR35W6A2/A3/A5)



c. For operations' please refer to the motor operation instruction

Models & Parameters

(more info please refer to the nameplate)

Electrical Specification	Standard
Battery Type	AAA battery*2
Working Temperature	-10°C-50°C
Radio Frequency	433.92M \pm 1 00KHz
Transmit Distance	\geq 30m indoor




Caution!

1. The transmitter should not be exposed to moisture or impact, so as not to affect its life.
2. During use, when the remote control distance is significantly shorter or less sensitive, please check whether the battery needs to be replaced.
3. When the voltage is too low, JCHR35W6A2/A3/A5 orange LED will flicker during operation, JCHR35W6A1/A4 LCD screen digital display will be weak, indicating to replace the battery.
4. Please properly dispose of used batteries according to the local garbage classification and recycling policy.


Instructions

a . Number of Channels Setting (only apply to JCHR35W6A1/A4)



Note: Max&Min number is 16&1 when it's set under channel 1-16.

Documents / Resources



[JIECANG JCHR35W6A1 Hand Hled Remote Controller](#) [pdf] User Manual
JCHR35W6A1, JCHR35W6A2, JCHR35W6A3, JCHR35W6A4, JCHR35W6A5, JCHR35W6A1
Hand Hled Remote Controller, JCHR35W6A1, Hand Hled Controller, Remote Controller, Contro
ller