

Jingqi Remote Control Device for Walk Device



Jingqi Remote Control Device for Walk Device Instructions

[Home](#) » [Jingqi](#) » Jingqi Remote Control Device for Walk Device Instructions 

Contents

- [1 Jingqi Remote Control Device for Walk Device](#)
- [2 Product Usage Instructions](#)
- [3 Product overview](#)
- [4 Documents / Resources](#)
 - [4.1 References](#)
- [5 Related Posts](#)



Jingqi Remote Control Device for Walk Device



Product Usage Instructions

1. **START:** Press the button in standby or pause mode, Start running the treadmill.
 - **STOP:** Long Press the button while the treadmill is running or pause mode, Stop the treadmill.
 - **PAUSE:** Short Press the button while the treadmill is running, Stop the treadmill.
2. **MENU:**
 - **A.** Rest is displayed in standby mode, Press the key to switch cycle: ready mode →time counter mode-range reversal mode→Calorimeter mode-Standby mode.
 - **B.** In working condition, Press the key to switch cycle:0.00 → (time) T:00:00→ (distance) D:0.00→ (calorie) C:0000→ (speed) S: 0.00
3. **SPEED UP and SPEED DOWN:**
 - **A.** Rest is displayed in standby mode, Press the key to adjust the parameter settings, Long press to adjust quickly
 - **B.** In working condition short press key to adjust the speed change, Long press to adjust quickly.
4. **SPEED-2:**

In working condition, press key to adjust the speed to 2.0.
5. **SPEED-4:**

In working condition, press key to adjust the speed to 4.0.
6. **User Manual**


Please add the required statement below into the user manual as required per 15.21

CAUTION: Any changes or modifications not expressly approved could void the user's authority to operate the equipment.

Product overview



Documents / Resources

	<p>Jingqi Remote Control Device for Walk Device [pdf] Instructions JQ00001, 2BGX2JQ00001, Remote Control Device for Walk Device, Remote Control Device, W alk Device Remote Control, Remote Control, Remote</p>
--	---

References

- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.