



Home » Jkjoy » Jkjoy M32 Mini Handheld Fan User Manual 📆

Contents [hide]

- 1 Jkjoy M32 Mini Handheld Fan
- 2 INTRODUCTION
- 3 SPECIFICATIONS
- 4 FEATURES
- **5 SETUP GUIDE**
- 6 CARE & MAINTENANCE
- 7 TROUBLESHOOTING
- 8 PROS & CONS
- 9 WARRANTY
- 10 FREQUENTLY ASKED QUESTIONS
- 11 References

JKJOY

Jkjoy M32 Mini Handheld Fan



INTRODUCTION

The Jkjoy M32 Mini Handheld Fan is a small, lightweight cooling device made to be comfortable anywhere, at any time. This lightweight fan, which was introduced by Jkjoy in 2023, costs only \$5.99, making it a dependable and reasonably priced friend for hot days. The fan has a 2000mAh rechargeable battery that can run continuously for 6 to 12 hours after a single 3-hour USB charge. It may be used as a practical desk fan or as a handheld fan thanks to its multipurpose 2-in-1 design. Depending on their comfort level, users may effortlessly vary between medium, strong, and mild breeze airflow thanks to the three adjustable speeds. Its ultra-compact dimensions (4.72 inches height, 4.1 oz weight) and foldable design make it perfect for everyday commuting, travel, and outdoor activities. The fan prioritizes user safety without sacrificing performance thanks to its soft, safe blades that stop immediately if touched.

SPECIFICATIONS

Product Name	Jkjoy M32 Mini Handheld Fan
Price	\$5.99
Brand	Jkjoy
Color	Light Purple
Electric Fan Des	Table Fan, Handheld Fan
Style	Modern
Power Source	Battery Powered, USB Rechargeable
Battery Capacit	2000mAh Lithium Battery
Voltage	5 Volts
Runtime	6–12 Hours
Charging Time	3 Hours
Number of Spee ds	3 Adjustable Speeds
Number of Blad es	2
Control Type	Button Control, Touch
Material	Plastic
Finish Type	Unfinished
Special Feature s	Portable, Lightweight, Foldable, Safety Auto-Stop Blades

Product Dimensi ons	1.69"D x 1.61"W x 4.72"H
Weight	4.1 oz (Lightweight)
Mounting Type	Handheld, Freestanding (Foldable for Desk Use)
Included Compo nents	Mini Handheld Fan, USB Charging Cable, Instruction Manual
Surface Recom mendation	Home, Office, Outdoor
Recommended Uses	Cooling for Travel, Outdoor, Office, Walking
Key Functions	2-in-1 Design (Handheld + Desk Fan), USB Rechargeable, Soft Saf e Blades with Auto-Stop on Contact
Reusability	Yes
Model Name	M32
Indoor/Outdoor Usage	Both
Efficiency	Energy Efficient

FEATURES


• 3 Wind Speeds: Adjustable low, medium, and high speeds for personalized cooling.



• 2000mAh Rechargeable Battery: Long-lasting battery supports 6–12 hours of use per charge.



- Fast Charging: Fully charges in just 3 hours with a USB cable.
- Safe Blade Design: Soft blades automatically stop if touched, ensuring user safety.



- 2-in-1 Function: Can be used as both a handheld and a tabletop fan.
- Compact Size: Measures1.69"D x 1.61"W x 4.72"H fits easily in bags or pockets.



- Lightweight Build: Weighs only 4.1 ounces, perfect for travel or daily use.
- Foldable Handle: Convenient foldable design for flexible use and storage.
- **USB Powered:** Charges with laptops, power banks, car chargers, or adapters.
- Quiet Operation: Low noise level, ideal for office, library, or bedtime use.
- Modern Design: Stylish light purple color with a sleek and minimal look.
- **Durable Material:** Made of quality plastic for long-lasting use.
- Button Control: Simple and intuitive one-button operation.
- Energy Efficient: Consumes minimal power while providing effective cooling.
- Perfect Gift Idea: Ideal for summer gifts for women, kids, or travelers.

SETUP GUIDE

- Unbox Carefully: Remove the fan, USB cable, and user manual from the package.
- Charge Fully: Plug the USB cable into a charger, power bank, or computer before first use.

- Check Battery Indicator: Ensure it's fully charged (charging typically takes 3 hours).
- Unfold Handle: If using as a desk fan, unfold the handle until it clicks into position.
- Press Power Button: Short press to start the fan at low speed.
- Adjust Speed: Press the button again to switch to medium and high speeds.
- **Turn Off:** Press the power button a fourth time to turn the fan off.
- Set for Desk Use: Place it on a flat surface with the handle unfolded for stable use.
- Use Handheld Mode: Fold the handle down to hold it comfortably in hand.
- **Test Safety Blades:** Tap blades gently to check soft-stop safety function.
- Position Correctly: Angle the fan towards your face or area for optimal airflow.
- Use Indoors or Outdoors: Suitable for home, office, camping, or walking.
- Portable Charging: Keep a power bank handy for recharging on the go.
- Store Accessories: Keep the USB cable in your bag for convenience.

CARE & MAINTENANCE

- Regular Charging: Don't let the battery drain completely; charge after use.
- Clean Blades: Use a soft dry cloth to clean dust off the fan blades.
- Avoid Water: Keep the fan away from water to prevent damage.
- Check USB Port: Ensure the charging port is clean and dust-free.
- Store Safely: Store in a dry, cool place when not in use.
- Avoid Dropping: Handle with care to avoid breaking the blades or casing.
- Fold Handle Gently: Don't force the fold to prevent damage to the joint.
- Charge Correctly: Use the provided USB cable or a certified replacement.
- **Wipe Exterior:** Clean the body of the fan regularly with a microfiber cloth.
- Inspect Blades: Check for dirt buildup on the blades and clean as needed.
- Battery Care: Avoid overcharging to extend battery life.
- Avoid Extreme Heat: Don't expose the fan to high temperatures or direct sunlight.
- Keep Away from Children: Although safe, avoid letting very young kids play unsupervised.
- **Test Before Trips:** Check battery and fan operation before travel.
- Replace if Damaged: Stop using immediately if you notice any damage to the fan, blade, or charger.

TROUBLESHOOTING

Issue	Possible Cause	Solution
Fan won't turn on	Battery drained	Recharge fully using the USB cable
Fan runs but stops sud denly	Overheat protection t riggered	Let the fan cool for a few minutes
Fan not charging	Faulty cable or adapt er	Try another cable or USB port
Weak airflow	Low battery or clogge d blades	Recharge and clean the fan blades
Noise during operation	Debris stuck in blade	Power off and clean blades carefully
Speed button unrespo	Button stuck or dirty	Gently clean around the button area
Fan blades won't spin	Motor fault or obstruc	Check for blockages; contact suppor t if persists
Charging light not sho wing	Loose cable or faulty indicator	Reconnect firmly or try a different U SB charger
Runs for a short time a fter charge	Battery not fully char ged	Ensure a complete 3-hour charge
USB port loose	Frequent plugging ca using wear	Adjust cable angle gently; contact fo r repair if needed

PROS & CONS

PROS	CONS
Lightweight, foldable, and pocket-sized	Small airflow area, not for large spaces

PROS	CONS
3 adjustable speeds for customized cooling	Only 2 fan blades, less powerful than bi gger fans
2000mAh battery with up to 12 hours runti me	Requires 3 hours for full charge
USB rechargeable, no need for battery repl acements	Plastic body may feel less premium
Safe blades that auto-stop on accidental contact	No indicator for battery percentage

WARRANTY

The Jkjoy M32 Mini Handheld Fan comes with a **6-month** limited warranty from the date of purchase. This warranty covers defects in materials and manufacturing, including motor failure, charging issues, or button malfunction under normal use. It does not cover damages caused by accidents, misuse, water exposure, or unauthorized repairs. For any warranty-related claims, customers are advised to contact Jkjoy customer support with their purchase receipt for assistance.

FREQUENTLY ASKED QUESTIONS

What is the battery capacity of the Jkjoy M32 Mini Handheld Fan?

The Jkjoy M32 fan has a 2000mAh rechargeable battery that provides 6-12 hours of working time after a full charge.

How long does it take to fully charge the Jkjoy M32 Mini Fan?

The fan fully charges in approximately 3 hours via USB charging.

How many speed levels does the Jkjoy M32 Fan offer?

The Jkjoy M32 provides 3 adjustable speed settings, allowing you to control the airflow based on your needs.

Can the Jkjoy M32 Mini Fan be used as a desk fan?

Absolutely, the 2-in-1 design allows it to function as both a handheld fan and a desk fan with its foldable stand.

What should I do if my Jkjoy M32 fan doesnt turn on?

Check if the fan is fully charged and that the power button is held down long enough to activate. Inspect the charging cable for damage.

Why does my Jkjoy M32 Mini Fan stop working suddenly?

It may be due to low battery, or if the blades are obstructed or touched, the fans safety auto-shutdown feature may activate.

What kind of charging cable does the Jkjoy M32 use?

The fan includes a USB charging cable, compatible with power banks, laptops, car chargers, and standard USB adapters.

References

- User Manual
 - B0CTGB9TQ7, Jkjoy, Jkjoy M32, M32, Mini Handheld Fan, user
- Jkjoy manual

Leave a comment

Comment *	
Name	
Email	
Website	
vvebsite	
☐ Save my name, email, and website in this browser for the next time I comment.	
Post Comment	
Search:	
e.g. whirlpool wrf535swhz	h
Manuals+ Upload Deep Search Privacy Policy @manuals.plus YouTube	

Your email address will not be published. Required fields are marked*

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.