Manuals+ — User Manuals Simplified.

JLAB GO Talk USB Microphone User Guide

We love that you are rocking JLab!
We take pride in our products and fully stand behind them.
GO TALK USB
MICROPHONE

YOUR WARRANTY
All warranty claims are subject to JLab authorization and at our sole discretion. Retain your proof of purchase to ensure warranty coverage.

CONTACT US
Reach out to us at **support@jlab.com**
or visit **jlab.com/contact**

REGISTER TODAY
**jlab.com/register**
Product updates | How-to tips

Contents

ASSEMBLY

BASE ① ②

5/8" & 1/4" ADAPTER
5/8"
1/4"

Place the microphone through 5/8" or 1/4" mount and screw on adapter to lock.

SETUP

Connect to your PC or Mac USB INPUT.

SETUP GO TALK WITH PC (WINDOWS 7, 8, or 10)

1. From the Start menu, select the Control Panel.
2. From the Control Panel, select the Sound icon.
3. Select the Recording tab and select "JLab Go Talk".
4. Select the Playback tab and select "JLab Go Talk".

Enter your PC or Mac settings to make sure the connection is established.

SETUP GO TALK WITH MAC (macOS 10.10 or HIGHER)

1. Open System Preferences and select the Sound icon.
2. Select the Input tab and select "JLab Go Talk".
3. Select the Output tab and select "JLab Go Talk".
4. From this screen, set the Output volume to the desired level.

CONTROLS

LIGHT INDICATOR

VOLUME GAIN MUTE

SWITCH VOLUME/ GAIN CONTROL:
Press Hold
(Light indicator will change)

MUTE ON/OFF:
Quick Press

VOLUME/GAIN WHEEL

Maximum Setting:
Light Blinks 3x
Minimum Setting:
Light Blinks 1x

RECORDING SETTING

HEADPHONE AUX

USB-C POWER INPUT

CARDIOID
Record front

OMNI
Record all surroundings

IN USE

Incorrect position

Correct position

TIPS / TROUBLESHOOTING

- The GO Talk works with almost any recording software installed on macOS, Windows, or Linux. Review your software's settings and adjust accordingly.
- No additional drivers/software is needed for the GO Talk. Simply plugin and set up in device settings.
- GO Talk will not work through most tablets or mobile phones due to their power limitations. The output power source needs to produce 5v or greater to operate.
- GO Talk will not work through a power bank/battery pack. It will only work with USB-A input with an operating system.
- If you are connecting through a USB hub or 3rd party adapter, make sure the product has the correct power output support and connection support.
- Using external speakers for playback can cause microphone reverberation and echo. It is recommended to use headphones/earbuds for recording playback if this occurs.

Shop products | Product alerts | Burn-in your headphones
JLab Store + Burn-in Tool

JLAB.COM

Documents / Resources

JLAB GO Talk USB Microphone [pdf] User Guide
GO Talk, USB Microphone, GO Talk USB Microphone

References

- ⊛ **JLab: True Wireless Headphones, Earbuds, Microphones, Personal Audio**
- ⊛ **Contact Us – JLab**
- ⊛ **Register Your Product – JLab**