



JOCEL JVM030573 Desktop Table Fan 15 CM Instruction Manual


[Home](#) » [JOCEL](#) » JOCEL JVM030573 Desktop Table Fan 15 CM Instruction Manual 

Contents

- [1 JOCEL JVM030573 Desktop Table Fan 15 CM](#)
- [2 OPERATING INSTRUCTIONS](#)
- [3 GENERAL WARRANTY TERMS](#)
- [4 Documents / Resources](#)
 - [4.1 References](#)
- [5 Related Posts](#)



JOCEL JVM030573 Desktop Table Fan 15 CM



1. Place the bottom of the motor housing into the top of the base, aligning the holes in the bottom of the housing with the holes in the base.
2. Insert the tilt adjustment knob through the holes and tighten the bolt on the end of the knob.

OPERATING INSTRUCTIONS

1. To turn on the fan, turn the power switch to the desired fan speed setting: "1" or "2".
2. To turn off the fan, turn the power switch to the "0" position.
3. To adjust the fan tilt:
 - Loosen the tilt adjustment knob.
 - Adjust the fan to the desired angle.
 - Securely tighten the tilt adjustment knob.
4. Unplug the product from the electrical outlet when it is not in use or is left unattended.

SAFETY PRECAUTIONS

1. This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
2. Children should be supervised to ensure that they do not play with the appliance.
3. Any repairs carried out solely by a qualified electrician. Do not try to repair the appliance yourself.

GENERAL WARRANTY TERMS

1. The warranty is valid only on presentation of invoice of purchase.
2. This WARRANTY is limited exclusively to parts substitution ineffective due to faulty manufacture, made in our workshops.
3. The elimination of several faults of the scope of the guarantee is made for repair or replacement of defective parts, according to the discretion of our technical services. Defective parts are our property.
4. Are not covered under warranty damage caused by transportation, neglect or poor use, improper assembly or installation, as well as external influences such as: lightning strikes or power, flooding, humidity, etc..
5. Lose warranty, all appliances that are not being used according to the instructions, or connected to FEEDING NETWORKS not guarantee a constant voltage of 220/240V.
6. The warranty does not cover damages for personal injury or damage caused directly or indirectly in any capacity whatsoever.
7. This warranty terminates when it is found to have been undergoing repairs, alterations or interventions by any person not authorized by Jocel.

THE WARRANTY EXPIRES

1. With the modification or disappearance of the nameplate of the appliance.
2. Exceeded the period of 2 years for home appliances and 06 months for industrial appliances, warranty expires and assistance will be made by charging the costs of manpower, according to current fees.

TECHNICAL ASSISTANCE

For technical assistance request, our services are available through the following contacts:

Telef. 00 351 252 910351

Fax: 00 351 252 910367

E-mail: assistencia@jocel.pt

<http://www.jocel.pt>

DECLARATION OF CONFORMITY

We declare on our own responsibility that the machine indicated below

Product : TABLE FAN 15CM

Brand : JOCEL


Model : JVM030573

Complies with the following European directives and standards implementation

Low Voltage : 2014/35/EU

Electromagnetic Compatibility : 2014/30/EU

Documents / Resources

 <p>JOCEL VENTOINHA DE MESA 15CM VENTILADOR DE SOBREMESA 15CM TABLE FAN 15 CM JVM030573 MANUAL DE INSTRUÇÕES MANUAL DE FUNCIONAMIENTO INSTRUCTION MANUAL</p>	<p>JOCEL JVM030573 Desktop Table Fan 15 CM [pdf] Instruction Manual JVM030573, Desktop Table Fan 15 CM, Table Fan 15 CM, JVM030573, Desktop Fan 15 CM</p>
---	---

References

- [JOCEL Electrodomésticos](#)
- [JOCEL Electrodomésticos](#)

[Manuals+.](#)