


Johnson Controls BW App User Guide

[Home](#) » [Johnson Controls](#) » Johnson Controls BW App User Guide 

Johnson Controls BW App



Contents

- 1 [Bentel Security](#)
- 2 [Supported Phones](#)
- 3 [App Installation](#)
- 4 [CUSTOMER SUPPORT](#)
- 5 [Documents / Resources](#)
 - 5.1 [References](#)
- 6 [Related Posts](#)

Bentel Security

App for monitoring and managing BW control panels User guide

Welcome to BW App, a free, user-friendly mobile app for Bentel Wireless security systems users. This guide includes instructions on installing BW App on your mobile phone.

Supported Phones

- Android v4.4 and up

- iOS v8 and up

App Installation

1. Locate the BW App in one of the following app marketplaces and install it on your mobile device:

- iTunes
- Google Play



2. Once installed, click on the **BW App** icon on your home screen to open it.
3. Read the end user license agreement (EULA), tap **I accept end user license agreement**, and then tap **ACCEPT**.
4. Read the privacy policy, tap **I accept privacy notice**, and then tap **ACCEPT**.
5. In the **Server address** field, enter bentel.tycomonitor.com, and then tap **OK**.
6. If you have not yet signed up on the server bentel.tycomonitor.com, tap Sign up.
7. In the E-mail field, enter an email for signing up on the server, and then tap **SIGN UP**.
8. In the **E-mail code** field, enter the code you received in the email you entered in the previous step, and then tap **PROCEED**.
9. In the **Password** field, enter a password: the password must be at least eight characters, and must contain at least one letter, one number, and one special character.
10. In the **Repeat password** field, enter the password you entered in the previous step, and then tap **PROCEED**.
11. In the Panel name field, enter your panel name.
12. In the Panel serial field, enter the serial number of your control panel: to know the control panel serial number, refer to the control panel instructions.
13. In the **Master User code** field, enter the control panel master user code: the default master user code is **1111**.
14. Tap **CONNECT**

Now you can use the **BW App** to monitor and manage your BW control panel.

CUSTOMER SUPPORT

© 2024 Johnson Controls. All rights reserved. JOHNSON CONTROLS and BENTEL SECURITY are trademarks and/or

registered trademarks. Unauthorized use is strictly prohibited.

Johnson Controls Products Italia S.r.l. – Via Gabbiano, 22 – Zona Ind. S. Scolastica – 64013 Corropoli (TE) – Italy


Tel.: +39 0861 839060 – **Fax:** +39 0861 839065 – bentel.info@jci.com – www.bentelsecurity.com

BW App User Guide English

BW App User Guide English ISTISJBEBWAPP 0.0 220124 MW22



Documents / Resources

	<p>Johnson Controls BW App [pdf] User Guide ISTISJBEBWAPP-0.0, 220124, MW22, BW App, App</p>
---	--

References

- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.