



JONSBO V11 Mini- ITX Tower Computer User Manual

[Home](#) » [JONSBO](#) » JONSBO V11 Mini- ITX Tower Computer User Manual 







JONSBO V11 Mini- ITX Tower Computer







Contents

- [1 PACKAGE CONTENTS](#)
- [2 Connectors](#)
- [3 Parts Diagram](#)
- [4 Installation Guide](#)
- [5 Documents / Resources](#)
- [6 Related Posts](#)


PACKAGE CONTENTS

Image	Q'ty	Used for
	13	Screws- PSU, MB, Riser cable
	13	Washer
	8	Screws -2.5"SSD
	4	Aluminum Feet
	1	PCI-E riser cable
	5	Cable


Connectors

	USB 3.0		PWR SW
	HD AUDIO		PWR LED


Parts Diagram

	Parts
	1 External cover
	2 DC Fan
	3 Aluminum Case Feet
	4 Steel Chassis/
	5 Plastic Guide/

Installation Guide


<div> <div>1</div> <div>Remove cover</div>  </div>	
	<div> <div>1. Release the rear screw</div> <div>2. Pull the handle to release the steel chassis</div> </div>

2 MB installation



1. Place 10 shield to rear panel opening
2. Secure the MB with screws


3 PCI-E Riser cable installation



1. Insert the board end of the riser cable to the PCI-E slot on MB
2. Secure the PCI-E slot end of the riser cable to the case with screws

4


GPU / add-on card installation



1. Remove PCI slot brackets
2. Insert the GPU to PCI-E Slot on Riser cable, secure with screw
3. Remove Front fan and bracket for max GPU length 10330mm


5

PSU Installation



Insert the PSU to corresponding position, secure with screws


6 2.5" SSD Installation



1. Remove the 2.5" device cage first, secure 2.5" SSD with screws
2. Place the 2.5" cage back to chassis, secure it with screws

7


Close the cover



1. After the hardware installation, slide the chassis into the external cover
2. Secure it with thumb screw

8


For Vertical use



Install the aluminum feet to the corresponding positions on the rear panel



Documents / Resources



[JONSBO V11 Mini- ITX Tower Computer](#) [pdf] User Manual

V11, Mini- ITX Tower Computer, ITX Tower Computer, Mini- Computer, Computer, Tower Computer

[Manuals+](#).