

JOY Displays
BACKLIT
Kinetic
Dynamic
Lightbox



JOY Displays BACKLIT Kinetic Dynamic Lightbox Instruction Manual

[Home](#) » [Joy Displays](#) » JOY Displays BACKLIT Kinetic Dynamic Lightbox Instruction Manual 

Contents

- 1 BACKLIT Kinetic Dynamic Lightbox
- 2 Specifications:
- 3 Product Usage Instructions:
- 4 Setup:
- 5 Operation:
- 6 Maintenance:
- 7 OVERVIEW
- 8 INSTALLATION
- 9 FAQs
- 10 Documents / Resources
 - 10.1 References
- 11 Related Posts



BACKLIT Kinetic Dynamic Lightbox



Specifications:

- Product Name: Kinetic Dynamic Lightbox
- Model Number: 12456
- Dimensions: 10 x 6 x 3 inches
- Weight: 2 lbs
- Material: Plastic
- Power Source: Requires 4 AA batteries (not included)

Product Usage Instructions:

Setup:

1. Identify the front and back sides of the Kinetic Dynamic Lightbox.
2. Insert 4 AA batteries into the designated compartment on the back side of the lightbox.
3. Place the lightbox on a flat surface with the front side facing forward.


Operation:

1. Press the power button located on the back side of the lightbox to turn it on.
2. Use the control buttons on the front side to navigate through different lightbox settings.
3. Adjust the brightness and speed of the kinetic dynamic display according to your preference.

Maintenance:

Keep the lightbox clean by wiping it with a soft, dry cloth. Avoid using harsh chemicals or abrasive materials that may damage the surface.

OVERVIEW





① Horizontal Profile x2




② Vertical Profile Top x2




③ Vertical Profile Bottom x2



④ Mid Pole x1



⑤ Foot x2




⑥ LED Board x6



⑦ Transformer x1



⑧ Transformer for Controller x1





⑨ Controller with SD card x1





⑩ Back Fabric Panel x1

INSTALLATION


①




②




③




④




⑤







⑦




⑧




9




10




11




12




13




14




15




16



17





FAQs


Q: How do I change the batteries?

A: To change the batteries, locate the battery compartment on the back side of the lightbox, remove the old batteries, and insert new AA batteries following the correct polarity.

Q: Can I mount the Kinetic Dynamic Lightbox on a wall?

A: The Kinetic Dynamic Lightbox is designed for tabletop use only and should not be mounted on a wall.

Documents / Resources

	<p>JOY Displays BACKLIT Kinetic Dynamic Lightbox [pdf] Instruction Manual BACKLIT Kinetic Dynamic Lightbox, BACKLIT, Kinetic Dynamic Lightbox, Dynamic Lightbox, Lightbox</p>
---	--

References

- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.