



JOYO R-30 Tidal Wave User Guide

[Home](#) » [JOYO](#) » JOYO R-30 Tidal Wave User Guide 

Contents

1 JOYO R-30 Tidal Wave

2 Specifications

3 Documents / Resources

3.1 References

4 Related Posts






JOYO R-30 Tidal Wave



Specifications

- Dimensions: 130'110'50mm
- Weight: 442g
- Input Impedance: 1M Ω
- Output Impedance: 1 Kn
- Working Current: <1 00mA
- Working Voltage: DC 9V (center min us)




JOYO TECHNOLOGY CO., LTD

Address: 2/F, Lushi Industry Building, 28th District, Bao'an, Shenzhen, 518133 China. Email:

info@joyoaudio.com Tel: 0086-755-29765381 www.joyoaudio.com MADE IN CHINA

Documents / Resources

	JOYO R-30 Tidal Wave [pdf] User Guide R-30 Tidal Wave, R-30, Tidal Wave, Wave
---	--

References

- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.