



JOYUSING V1XS Document Camera Optical Digital Zoom User Guide

[Home](#) » [JOYUSING](#) » JOYUSING V1XS Document Camera Optical Digital Zoom User Guide 



Document Camera




Contents

- 1 Package list
- 2 Remote control and interface instruction
- 3 Device connection
- 4 Attention
- 5 Warranty card
- 6 Documents / Resources
 - 6.1 References

Package list

☐ Document Camera




☐ Remote Controller



☐ CD



☐ USB2.0 Cable




☐ HDMI Cable




☐ VGA Cable



☐ DC Adapter (12V1A)





☐ Location Soft Pad













☐ User Manual



Remote control and interface instruction




	Menu
	on/off LED Light
	Change to HDMINGA
	Freeze the image
	Rotate image by 90°/180°/270°/360°
	Record a video clip
	Capture a still image
	Change the resolution/back to main menu
	Press to realize the function/auto focus
	Power on/off

Device connection


PC Connection

1. Plug in the power adapter to the power socket and Document Camera.
2. Connect the USB cable to the PC and Document Camera.
3. Install the software.



PC-Less

1. Plug in the power adapter to power socket and Document Camera.
2. Connect the HDMINGA cable to the Document Camera and Touch screen.
3. Connect the USB cable to the Document Camera and Touch screen (touch usb port).



★ Calibration need to be done first for the touch function after connection.

Document Camera and external equipment connections as below:

Document Camera Interface	Connection Cable	External Equipment Interface
HDMI_OUT 		HDMI_IN
VGA_OUT 		VGA_IN
VGA_IN 		VGA_OUT

Attention

Before use:

- Do not leave it under direct sunlight or by heaters. It maybe discolored or damaged.
- Do not place this product in any humid, dusty, or vibrating locations.
- Carry the product by holding the base in both hands. Never hold the product by the arm or the camera head.
- Use a soft, dry cloth for cleaning instead of any volatile solvent.
- When the device is not in use for a while, please turn off the power.
- Fold the arm when the product will not be used for a long time.

During use:

- Please prevent children from operating the device without supervision.
- Recommended environmental conditions: Temperature: 0°C – 40°C (32°F – 104°F) .
- Humidity: 30% – 85% (No condensation) .
- Use the product on a stable base, desk, or table.
- Do not turn or flip the camera head or arm to its limitation as below manual instructs.
- Do not point the camera lens directly at the sunlight. It may be damaged and fails to take pictures.
- Do not look directly to the LED lamps to prevent your eyes from being damaged.
- The product may not be operated properly if a USB hub is used to connect the product and a PC.

- transfer the data from the SD card onto a device such as a PC to save a backup copy. Malfunction of the product or repairs may cause the data in the SD card to be deleted
- Be careful to prevent the unit from dropping or overturning
- Please prevent the camera head to hit the desk top or any other hard objects, or it can be damaged easily.

Warranty card

Model
 Add
 Tel
 E-mail
 Date

Certification

Model
 Inspector No.
 Production date
 Manufacturer Joyusing Technology Co., Ltd.
Joyusing Technology Co., Ltd.



<http://www.joyusing.com>


Website: www.joyusing.com

Tel: 0086-591-86399086

Email: sales@joyusing.com


Address: No.27 Yangzhou Road Cangshan District, Fuzhou, Fujian, China

Documents / Resources



[JOYUSING V1XS Document Camera Optical Digital Zoom](#) [pdf] User Guide
 V1XS, V1XS Document Camera Optical Digital Zoom, V1XS, Document Camera Optical Digital Zoom, Camera Optical Digital Zoom, Optical Digital Zoom, Digital Zoom, Zoom

References

-  **[JOYUSING: Digital Teaching Tools | Visual Collaboration Solutions](#)**
- **[User Manual](#)**

Manuals+. Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.