



JPHTEK Three Layer Folding Touchpad Keyboard User Manual

[Home](#) » [JPHTEK](#) » JPHTEK Three Layer Folding Touchpad Keyboard User Manual 

JPHTEK Three Layer Folding Touchpad Keyboard



Contents

1 Product features

1.1 Three system switching languages

2 Android Connection Instructions

3 Win 10 Connection Instructions

4 iOS Connection Instructions

4.1 Three Layer Folding Touchpad Keyboard

5 Warranty Card

6 FAQ

7 Troubleshooting

8 Keyboard Maintenance

9 Touch pad function description (Android), must be switched to Android system

10 Status Display LED

11 Touch pad function description (iOS 13.4.1 and above), must be switched to iOS system

11.1 User-defined









12 Technical Specifications

















13 Touchpad function description (Windows10), must be switched to Windows system

14 Documents / Resources

15 Related Posts

Product features

10 S/ Andro id		Windows	
Fn+	Corresponding function	Fn+Shift+	Corresponding function
 Esc	Return to Desktop	 Esc	Home
 F1	Search	 F1	Search
 F2	Select	 F2	Select
 F3	Copy	 F3	Copy

<div>\$ 4</div> <div> F4</div>	Stick	<div>\$ 4</div> <div> F4</div>	Stick
<div>% 5</div> <div> F5</div>	Cut	<div>% 5</div> <div> F5</div>	Cut
<div>^ 6</div> <div> F6</div>	Pre-Track	<div>^ 6</div> <div> F6</div>	Pre-Track
<div>& 7</div> <div> F7</div>	Play/Pause	<div>& 7</div> <div> F7</div>	Play/Pause
<div>* 8</div> <div> F8</div>	Ne xt	<div>* 8</div> <div> F8</div>	Ne xt
<div>(9</div> <div> F9</div>	Mute	<div>(9</div> <div> F9</div>	Mute
<div>) 0</div> <div> F10</div>	Volume-	<div>) 0</div> <div> F10</div>	Volume-
<div>— —</div> <div> F11</div>	Volume+	<div>— —</div> <div> F11</div>	Volume+


<div> <div>+</div> <div> <div></div> <div></div> </div> </div> <div>= F12</div>	Lock	<div> <div>+</div> <div> <div></div> <div></div> </div> </div> <div>= F12</div>	Lock
---	------	---	------

Three system switching languages


- iOS : control+Space key switch language
- Windows : Alt+Shift switch language
- Android : Shift+Space key switch language

Android Connection Instructions


- Please turn on the power at the side of the keyboard, blue lights up,press the Bluetooth connection button, blue light will twinkle and into the match mode quickly.




- Open “Settings” and then click “Connect”




- Turn on Bluetooth to search for the pair name.



4. Click the pair name "Bluetooth Keyboard". pair request is displayed, click OK.




5. There is a tip for connecting successfully ,you can use your keyboard comfortably .




Remarks After connecting successfully the next time you don't need match code, just open the Bluetooth keyboard power switch and the tablet PC "Bluetooth." The BT keyboard will search the device and automatic connects.

Win 10 Connection Instructions


1. Please turn on the power at the side of the keyboard, blue lights up, press the Bluetooth connection button, blue light will twinkle and into the match mode quickly.




2. Open settings, turn on Bluetooth, click Add Bluetooth or other devices.




3. Select “Bluetooth” in the Add Device to search.



4. . You will find the “Bluetooth keyboard ” and then click the pairing name to connect.




5. There is a tip for connecting successfully , you can use your keyboard comfortably .




iOS Connection Instructions


1. Please turn on the power at the side of the keyboard, blue lights up, press the Bluetooth connection button, blue light will twinkle and into the match mode quickly.




2. Open the tablet PC setting “Bluetooth” into searching and pairing status .



3. You will find the “Bluetooth Keyboard” and then click to next step .





4. There is a tip for connecting successfully ,you can use your keyboard comfortably .



Front

Multi-Function Keys





Compatible System

Win /iOS /Android

Three Layer Folding Touchpad Keyboard

Note: Please read the user manual carefully before you start using this product

Warranty Card

User information

Company or personage full name

Contact address

TEL Zip

The purchased product name and model NO.

Purchased date

This reason due to the product broken and damage is not include on the warranty.

1. accidents, misuse, improper operation, or any unauthorized maintenance, alteration, or disassembly;
2. Improper operation or maintenance, violation of product instructions or improper connection of power during use;
3. Or use consumables (such as spare batteries) that are not provided by the company but applicable laws
Except where such restrictions are prohibited

FAQ

1. The tablet PC can't connect the BT keyboard
 - 1 At first check the BT keyboard is into match code state, then open the table PC Bluetooth searching.

2. Checking the BT keyboard Battery is enough, the battery low is also lead to can't connect, you need charge
2. The keyboard indication light always flashing when use? Keyboard indication always flashing when use, is means the keyboard will be no power ,please charge the power as soon as possible.
3. The table PC display BT keyboard is disconnect?

The Bluetooth keyboard is not used for a period of time, the device will automatically enter the sleep state in order to save power. Press any key on the keyboard to wake up, and the Bluetooth connection will be automatically restored.

Troubleshooting

Please contact the after-sales service.

Copyright

It is forbidden to reproduce any part of this manual without the permission of seller.

Safety instructions

Do not open or repair this device, Do not use the device in a damp environment. Clean the device with a dry cloth.

Warranty


The device is provided with one-year limited hardware warranty from the purchase day

Keyboard Maintenance


1. Please keep the keyboard away from liquid or humid environment, saunas, swimming pool, steam room and don't let the keyboard get wet in the rain.
2. Please don't expose the keyboard at too high or too low temperature condition.
3. Please don't put keyboard under sun for a long time.
4. Please don't put keyboard close to the flame, such as cooking stoves, candles or fireplace.
5. Avoid sharp objects scratching products, timely to recharge products to ensure the normal use.

Touch pad function description (Android), must be switched to Android system


- Tap — The left of mouse button



- Two-finger tap Return



- Two-finger slides vertically / horizontally — Mouse wheel



- Drag — Mouse cursor



Status Display LED

- Connect : Open the power switch, blue lights up, press the connect button, blue light twinkles.
- Charging : Indicator light will be on red, after fully charging, the light crush out.
- Low Voltage Indication : When the voltage is below 3.3 V, red light twinkles.

Remarks: In order to prolong the life span of the battery, when you do not use the keyboard for a long time, please switch off the power.

Touch pad function description (iOS 13.4.1 and above), must be switched to iOS system


- Tap—Tap (user-defined)




- Drag — Mouse cursor




- Single finger double tap and then drag — Drag




- Two-finger tap — Open the menu (user-defined)




- Two-finger slides vertically — Mouse wheel



- Two-finger slides horizontally — Slide the desktop left and right




- Two-finger separation / collapse — Zoom in / out




- Three-finger tap — Desktop (user-defined)



- Three-finger slides up — Open/hide the bottom of the application bar (Cmd+Alt+D)




- Three-finger slides down — Open all the active windows (Click the Homepage button twice)



- Three-finger slides left — Active windows (Cmd+shift+Tab)



- Three-finger slides right — Active windows (Cmd+Tab)



- Four-finger tap — Regional screenshots (Cmd+shift+4)



User-defined

Settings – Auxiliary Functions – Touch – Auxiliary Touches – Device – Click the keyboard's pairing name, and then customize the function of 'single finger, Two-finger, Three-finger'.

Technical Specifications

Keyboard size: 304.5 x 97.95 x 8 mm (open)

Working distance 10 m

Lithium battery capacity 140 mAh

Working voltage 3.7 V

Key working current < 5 mA

Touchpad working current <11 mA

Touchpad size 54.8 x 44.8 mm

Weight 197.3 g

Standby current < 1.5 mA


Sleep current < 60 μ A

Sleep time Ten minutes


Awaken way Press key

Touchpad function description (Windows10), must be switched to Windows system


- Tap — The left of mouse button




- Two-finger tap — The right of mouse button



- Two-finger slides vertically / horizontally — Mouse wheel




- Two-finger separation / collapse — Zoom in / out




- Three-finger tap — Search




- Three-finger slide to the left continuously — Switch the active window




- Three-finger slides up — Open the browser window



- Three-finger slide to the right continuously — Active window switch



- Three-finger slides down — Go Home



- Four-finger tap — Open the (Action + Center)



Documents / Resources

	JPHTEK Three Layer Folding Touchpad Keyboard [pdf] User Manual Three Layer Folding Touchpad Keyboard, Touchpad Keyboard, Three Layer Folding Keyboard, Folding Keyboard, Keyboard
--	---