Jrl LED2020 Remote Control Instruction Manual

**LED2020 Remote Control
Instruction Manual**

Contents

Remote Operating Instructions

Remote Controller
RF Remote control, long-distance,mini size, wire connection is simple and very easy to use;

1. Functions Of Each Button:

2. Usages:

ON/OFF	AUTO	SPEED UP	SPEED DOWN	MODE UP	MODE DOWN	BRIGHTNESS UP	BRIGHTNESS DOWN	MATCH	SETTING	RED	GREEN	BLUE	WHITE	YELLOW	CYAN	PURPLE
⏻	AUTO	SPEED+	SPEED-	MODE+	MODE-	☀	☀	🔒	⚙	R	G	B	W	Y	C	P

Model usage	Press the mode button to select the lighting movement model you want. Currently LED has below 6 models: 1. Multi-colour lighting twinkle consistently 2. single color lighting twinkle consistently (total 7 colors) 3. Mult-color light moves consistently 4. Single color light moves consistently (total 7 single colors) 5. Multi-color lighting moves discontinuously 6. Single color lighting moves discontinuously.
Speed usage	Continuously press the speed up or down button untill the speed you want.
Matching	Continuously press the **MATCH** button 5 times until the LED flashes in white quickly to match the Remote control with the receiving controller. Pressing the **MATCH** button for 5 times till LED flash in white slowly to un-match;
Reorder RGB	Differ from kinds of LED, The **R G B** keys may don't perfectly match your LED, Reorder them if needed. Continuously press the **SETTING** button 5 times until the LED flash in white once and then turn into all-white, Pressing the **R** button until LED is red, Pressing the **G** button until LED is green, pressing the **B** button till LED is blue, then press the **SETTING** button once to confirm your setting;

Receiving Controller:

Cautions: Please make sure the power supply voltage matches your controller before you power it. Warning

Warning

This product contains a Button battery. If swallowed, it could cause severe injury or death in just 2 hours. Seek medical attention immediately.

Always purchase the correct size and grade of battery most suitable for the intended use. Replace all batteries of a set at the same time.
Clean the battery contacts and also those of the device prior to battery installation.
Ensure the batteries are installed correctly with regard to polarity (+and -).
Remove batteries from equipment that is not to be used for an extended period of time.
Remove used batteries promptly.

FCC Regulatory Compliance

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC
Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.
If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Documents / Resources

Jrl LED2020 Remote Control [pdf] Instruction Manual
LED2020, 2AZCF-LED2020, 2AZCFLED2020, LED2020 Remote Control, Remote Control