



JTECH EXTEND Two Way Radios Scanning Instructions

[Home](#) » [JTECH](#) » JTECH EXTEND Two Way Radios Scanning Instructions 

Contents

- [1 JTECH EXTEND Two Way Radios Scanning](#)
- [2 PRODUCT FEATURES](#)
- [3 Additional Features](#)
- [4 SCAN SEQUENCE](#)
- [5 Priority Channel](#)
- [6 Documents / Resources](#)
 - [6.1 References](#)
- [7 Related Posts](#)



JTECH EXTEND Two Way Radios Scanning



PRODUCT FEATURES

- **Turn On Scanning**

Press the key programmed as “Scan,” a short press of the S/M is the default.



- **How to Know it's Working**

The scan icon displays and the radio begins to scan the channels.



- **Activity Detected**

When the radio detects activity, it stops on that channel and displays the channel number.



- **Talking On Active Channel**

- To talk to the person transmitting without switching channels, press the Push-to-talk button before scan resumes.
- If no activity occurs for 4 seconds, scanning will resume.



- **Turn Off Scanning**

To stop scanning, press the “Scan” key, a short press of the S/M is the default.



- **How to Call on Original Channel**

Press the Push-to-talk button while the radio is scanning, and the radio will transmit on the channel you were on before you activated scan.



Additional Features

- **Scan Advance**

If the radio stops scanning on a channel you do not want to listen to, press the up key to resume scanning for the next active channel.




- **Nuisance Delete**

- Press and hold the down key to temporarily remove a channel from the scan list.
- The channel returns to the scan list when the radio is turned off & then on again.




SCAN SEQUENCE

Normal Scan Sequence



Priority Scan Sequence




Priority Channel

- Priority scanning allows one channel to be sampled more regularly for activity, even when the radio is currently receiving on another channel.
- If the radio is receiving on a non-priority channel, the priority channel is still scanned, once every 3 seconds. The radio will switch to the priority channel once any activity is detected.
- The priority channel is programmed by the dealer via programming software or by the radio's keypad if full radio programming is activated.

For more information visit www.jtech.com or call 800.321.6221 1400 Northbrook Parkway, Ste. 320, Suwanee, GA 30024

Documents / Resources

 The image shows the cover of a manual for JTECH EXTEND Two Way Radios. It features the JTECH logo at the top left, followed by the word 'EXTEND' in a large, bold, sans-serif font. Below this, there are six small images of different radio models arranged in two rows of three. At the bottom left, the JTECH logo is repeated, and at the bottom right, there is a small text block that reads 'For more information, please visit our website at www.jtech.com'. The entire cover has a light gray background with a subtle grid pattern.	<p>JTECH EXTEND Two Way Radios Scanning [pdf] Instructions EXTEND Two Way Radios Scanning, EXTEND Two Way Radios, EXTEND Radios, Radios, Two Way Radios, Radios Scanning</p>
--	--

References

- [JT Pager Systems for Staff & Guests | Restaurants, Hospitals & More | JTECH](#)