



Home » KARLSSON » KARLSSON KA5899 Boxed LED Alarm Clock Instruction Manual 12



Contents [hide]

- 1 KARLSSON KA5899 Boxed LED Alarm Clock
- 2 Specifications
- 3 PRODUCT OVERVIEW
- 4 Product Usage Instruction
- 5 FAQs
- 6 Documents / Resources
 - 6.1 References



KARLSSON KA5899 Boxed LED Alarm Clock




Specifications


• Power Supply: 1.5m USB-C cable (5V/1A USB adapter excluded)

• Material: MDF and PVC

• Usage: Home decoration

PRODUCT OVERVIEW





Product Usage Instruction

Hourly Format

Press the down button to switch between the 12-hour and 24-hour systems. In a 12-hour format, a PM light is displayed from noon to midnight.

Matters Needing Attention

- Use only a 5V/1A USB adapter for power supply.
- Keep the clock and power cord out of reach of infants and children.
- Seek medical attention immediately if any small part is swallowed.

Hour Setting

- Long-press the set key to enter the setting mode.
- Adjust the hour by using the up and down keys when the hour number flashes.

Minute Setting

- Press the set key to enter the minute setting mode after the hour is set.
- Adjust the minute by using the up and down keys when the minute number flashes.
- The setting interface will exit automatically if there is no operation within 15 seconds.

Power Failure

 If the clock does not run normally during a power failure, check the CR2032 battery status or replace it if needed.

MATTERS NEEDING ATTENTION

For power, only use a 5V/1A USB adapter with this product. Danger Warning: Use an adapter within the standard voltage range. Keep the clock and power cord out of reach of infants

and children. If you swallow any small part, seek medical attention immediately. If the clock does not run normally during a power failure, check whether the battery (CR2032) is installed or if it may be out of power. Replace the battery promptly if needed.

Warning

- Do not use near flammable objects or heat sources.
- Avoid using it in high-temperature or high-humidity environments.
- Do not disassemble or modify the product. Handle with care to prevent breakage.

Warranty

There is a two-year warranty against manufacturing defects on all Karlsson clocks, valid from the date of purchase.

Maintenance

A soft cloth may be used to clean your clock. Do not use corrosive cleaners or chemical solutions on the clock.

WEEE Symbol

EN The crossed-out wheeled bin symbol indicates that the item should be disposed of separately from household waste. The item should be handed in for recycling by the local

environmental regulations for waste disposal.

Karlsson is a trademark of Present Time@Televisieweg 16, 1322 AL, Almere www.presenttime.com

FAQs

Q: Can I use any USB adapter with the clock?

A: No, only use a 5V/1A USB adapter with this product for power supply to avoid

damage.

Q: How do I switch between 12-hour and 24-hour formats?

A: Press the down button to toggle between the two formats.

Q: What should I do if the clock stops during a power failure?

A: Check the CR2032 battery status or replace it if needed.

Documents / Resources



KARLSSON KA5899 Boxed LED Alarm Clock [pdf] Instruction Manual KA5899DW, KA5899WD, KA5899 Boxed LED Alarm Clock, KA5899, KA5 899 Alarm Clock, Boxed LED Alarm Clock, Boxed LED Alarm, Boxed LED Clock, Alarm, Clock

References

- User Manual
- KARLSSON
- Alarm, Alarm Clock, Boxed LED Alarm, Boxed LED Alarm Clock, Boxed LED Clock, Clock, KA5899, KA5899 Alarm Clock, KA5899 Boxed LED Alarm Clock, KA5899DW, KA5899WD, KARLSSON

Leave a comment

Your email address will not be published. Required fields are marked*

Comment *		
Name		
ivame		

Email				
Website				
☐ Save my name	email, and website in the	nis browser for the ne	ext time I comment.	

Post Comment

Search:

e.g. whirlpool wrf535swhz

Search

Manuals+ | Upload | Deep Search | Privacy Policy | @manuals.plus | YouTube

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.