



# KEMOVE K68 Mechanical Keyboard Instruction Manual

[Home](#) » [KEMOVE](#) » KEMOVE K68 Mechanical Keyboard Instruction Manual 



**REMINDER**  
kemove control hub  
[www.kemove.com](http://www.kemove.com)

## Contents

- [1 K68 Mechanical Keyboard](#)
- [2 FCC warning:](#)
- [3 KEMOVE T63 three mode function instructions](#)
- [4 Power Display:](#)
- [5 FN Combine Function Key:](#)
- [6 Documents / Resources](#)

## K68 Mechanical Keyboard

Kemove advocates environmental protection and energy saving. The Kemove series, which are released globally, "is no longer available in paper manuals".

The manual can be downloaded from the official website [www.kemove.com](http://www.kemove.com) as well as found in the upper right corner of the homepage of the Kemove control hub.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation

## FCC warning:

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected
- Consult the dealer or an experienced radio/TV technician for help.





The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

## KEMOVE T63 three mode function instructions

The three mode function are wired mode, 2.4G mode and Bluetooth mode respectively

2.4G Mode	FN+B=Turn on 2.4G, Press and hold the B button for 3 seconds and the white light will flash Bluetooth is restored to the default when connected successfully
Bluetooth Mode	FN+Z=BT1, Press and hold for 3 seconds, the red and blue lights flash alternately, and the Bluetooth is in the pairing state. If paired already, tap again to reconnect FN+X=BT2. Press and hold for 3 seconds, the red and blue lights flash alternately, and the Bluetooth is in the pairing state. If paired already, tap again to reconnect. FN+C=BT3. Press and hold for 3 seconds, the red and blue lights flash alternately, and the Bluetooth is in the pairing state. If paired already, tap again to reconnect

## Reminder:

	The ON/OFF switch on the back is a wired, wireless (battery) switch. It is unable to connect using wireless mode in wired mode
	In wireless mode, Bluetooth and 24G can be switched directly through the combination key When FN is pressed, the B key will light up in white to indicate that 24G is being used in the link. Press FN+B to switch from Bluetooth mode to 24G mode & pairing mode
	In 24G mode, you need to enter pairing first, and then insert the receiver (you also need to pair first and then insert the receiver after resetting)
<b>BT1/2/3</b>	In Bluetooth mode, when pressing FN key Z/X/C, one of the keys will flash blue to display the current channel
	FN+/XI/C keys can directly switch Bluetooth devices

## Power Display:


In wired mode.

**FN + Right Shift**



In Bluetooth mode.

**FN + Right Shift**



## FN Combine Function Key:

FN+A=	FN+S=	FN+D=	FN+F=	FN+G=	FN+H=
FN+1=F1	FN+2=F2	FN+3=F3	FN+4=F4	FN+5=F5	FN+6=F6
FN+7=F7	FN+8=F8	FN+9=F9	FN+0=F10	FN+-_=F11	FN+=+=F12
FN+U= Print Screen	FN+I=Scroll lock	FN+O=Pause	FN+})= softwarelight switch	FN+J=Insert	
FN+\ =Hardware light	FN+K=Home	FN+L=PageUp	FN+M=Delete	FN +<, =End	
FN+>.=Page Down	FN+Tab= Restore the keyboard to factory settings(Press 5 seconds)			FN+Space= FN key function lock	
FN+Win= Win key to lock / unlock		FN+Capslock = Switch the color of the default lighting effect of the keyboard			
FN+N=All keys without overrun, switch six keys without overrun			FN+Backspace= Turn off backlight, turn on backlight, turn off all lights		
FN+Enter= Enter the power saving mode		FN+Q=Profile 1	FN+W=Profile 2	FN+E=Profile 3	FN+R=Profile 4
FN +T= Switch back to Standard layer (Cannot set macro command)	FN+?/= ↑		FN+R_Alt= ←	FN+R_Ctrl= →	FN+Menu= ↓

## Documents / Resources

	<p><a href="#">KEMOVE K68 Mechanical Keyboard</a> [pdf] Instruction Manual 2A6LZ-K68, 2A6LZK68, K68, K68 Mechanical Keyboard, Mechanical Keyboard, Keyboard</p>
--	---