



Kensington VeriMark Windows 11 Optional Update and Fingerprint Set Up Installation Guide

[Home](#) » [Kensington](#) » Kensington VeriMark Windows 11 Optional Update and Fingerprint Set Up Installation Guide 

Kensington

The Professionals' Choice™

VeriMark Windows 11
Optional Update.




Contents


- [1 Install the driver through Windows 11 Update](#)
- [2 VeriMark™ Windows 11 \(Windows Hello\) Setup Guide](#)
- [3 Documents / Resources](#)
- [4 Related Posts](#)

Install the driver through Windows 11 Update


1. Rightclick on the Windows icon and select Settings.




2. Go to Windows Update.




3. Make sure your Windows 11 is up to date. If not, please install all updates first or you might not see the VeriMark driver appear on the update list.-




4. Once you make sure all the updates are installed, click “Advanced options”:-



5. Click “Optional updates”:-




6. Click “Driver updates”.-




7. Select“ Synaptics Incorporated – Biometric”, and click “Download & Install”.

The system will automatically download the VeriMark driver and install it.-




8. Kensington fingerprint key will show on device manager.-




VeriMark™ Windows 11 (Windows Hello) Setup Guide


1. Click on Start on the taskbar and click on Settings.




2. Click on Accounts to show sign in options.




3. Click on Sign-in options.




4. Alternatively, you can click on the magnifier glass on the taskbar and search for "Windows Hello".



5. Click on Fingerprint recognition (Windows Hello) and Set up.




6. On the next window click on Get Started.




7. If it is the first time using Windows Hello, you need to add a security PIN.


Enter a security key PIN then click OK for next step.




8. Once PIN has been set up enter it on the Windows Hello setup.




9. Touch the fingerprint sensor area repeatedly.




10. Continue lifting and touching the sensor to read fingerprint.



11. Click Close to finish fingerprint enrollment or Add another finger to set up another fingerprint.



12. To remove the fingerprint from the USB dongle click on remove.



All specifications are subject to change without notice. Products may not be available in all markets. Kensington and the ACCO name and design are registered trademarks of ACCO Brands. Kensington The Professionals' Choice is a trademark of ACCO Brands.

All other registered and unregistered trademarks are the property of their respective owners. © 2023 Kensington Computer


Products Group, a division of ACCO Brands. All rights reserved.

FOR MORE INFORMATION CONTACT:

1-855-692-0054

sales@kensington.com

Documents / Resources



[Kensington VeriMark Windows 11 Optional Update and Fingerprint Set Up](#) [pdf]

Installation Guide

k23-4111-vm-gen1, VeriMark Windows 11 Optional Update and Fingerprint Set Up, Optional Up
date and Fingerprint Set Up, Fingerprint Set Up, Windows 11 Optional Update, Windows 11

