

 Keychron  
**K15 Max  
Wireless  
Custom  
Mechanical  
Keyboard**



# Keychron K15 Max Wireless Custom Mechanical Keyboard User Guide

[Home](#) » [Keychron](#) » Keychron K15 Max Wireless Custom Mechanical Keyboard User Guide 

## Contents

- 1 [Keychron K15 Max Wireless Custom Mechanical Keyboard](#)
- 2 [PRODUCT INFORMATION](#)
- 3 [OVERVIEW](#)
- 4 [Connect Bluetooth](#)
- 5 [Switch To The Right System](#)
- 6 [The Backlight](#)
- 7 [Adjust The Backlight Brightness](#)
- 8 [The Layers](#)
- 9 [The Keychron Launcher App](#)
- 10 [Factory Reset & Firmware Update](#)
- 11 [Warranty](#)
- 12 [Documents / Resources](#)
  - 12.1 [References](#)
- 13 [Related Posts](#)



**Keychron K15 Max Wireless Custom Mechanical Keyboard**




## PRODUCT INFORMATION


If you are a Windows user, please find the appropriate keycaps in the box, then follow the instructions below to find and replace the following keycaps.

### Connect 2.4GHz Receiver


Connect the 2.4GHz receiver to the device's USB port.




Switch toggle to 2.4GHz mode




2.4G = 2.4GHz





**Note:** For the best wireless experience, we recommend using the extension adapter for the receiver and putting the 2.4GHz receiver somewhere on your desk close to your keyboard for a low rate of latency and fewer signal interferences.


## OVERVIEW




## Connect Bluetooth



Switch toggle to Bluetooth




Press fn + 1 (for 4 seconds) and pair with device named Keychron K15 Max.



## Connect Cable




Switch toggle to Cable




## Switch To The Right System

Please make sure the system toggle on the top left corner has been switched to the same system as your computer's operating system.




## The Backlight

Press fn + Q to change the lighting effect




Press fn + tab to turn the backlight on/off




## Adjust The Backlight Brightness

- Press fn + W to increase the backlight brightness




- Press fn + S to decrease the backlight brightness



## The Layers


- There are four layers of key settings on the keyboard. Layer 0 and Layer 1 are for the Mac system. Layer 2 and Layer 3 are for the Windows system.



- If your system toggle is switched to Mac, then layer 0 will be activated.



- If your system toggle is switched to Windows, then layer 2 will be activated. Remember that if you are using it in Windows mode, please make changes to layer 2 instead of the top layer (layer 0). This is a common mistake people are making.



## The Keychron Launcher App


Please visit [launcher.keychron.com](https://launcher.keychron.com) to use the online Launcher web app to remap the keys, create macro commands, or flash the firmware. If the Launcher cannot recognize your keyboard, please reach our support to get the instructions.

- The online Launcher can only run on the latest version of Chrome, Edge, and Opera browsers.
- The Launcher only works when the keyboard is connected by wire to the computer.



## Factory Reset & Firmware Update





## Troubleshooting? Don't know what's going on with the keyboard?

### Factory reset your keyboard

1. Power on your keyboard
2. Press and hold fn + J + Z (for 4 seconds). The keyboard backlight will flash in red quickly for 3 seconds, indicating that the keyboard has been reset.

### Flash your keyboard firmware.

1. Visit [launcher.keychron.com](https://launcher.keychron.com) to open the online Launcher web app.
2. Ensure the keyboard is in Cable or Wired mode and plug in the power cable.
3. Find the 'Firmware Update' tab on the left side of the Launcher and connect your keyboard with it.
4. Follow the instructions on the Launcher and complete the firmware update.
  - Step-by-step guide, search the keyword "firmware" on [keychron.com](https://keychron.com).

## Warranty

The keyboard is highly customizable and easy to rebuild. If anything goes wrong with any of the keyboard components of the keyboard during the warranty period, we will only replace the defective parts of the keyboard, not the whole keyboard.

## MORE INFO

### Not Happy

- [support@keychron.com](mailto:support@keychron.com)

## Documents / Resources

	<a href="#">Keychron K15 Max Wireless Custom Mechanical Keyboard</a> [pdf] User Guide K15 Max, K15 Max Wireless Custom Mechanical Keyboard, K15 Max, Wireless Custom Mechanical Keyboard, Custom Mechanical Keyboard, Mechanical Keyboard, Keyboard
--	--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

## References

- [User Manual](#)

**Manuals+ Privacy Policy**

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.