

 Keychron
Keychron Q3 HE Wireless
Custom Keyboard



Keychron Q3 HE Wireless Custom Keyboard Installation Guide

[Home](#) » [Keychron](#) » Keychron Q3 HE Wireless Custom Keyboard Installation Guide 

Contents

- [1 Keychron Q3 HE Wireless Custom Keyboard](#)
- [2 Connect 2.4 GHz Receiver](#)
- [3 Connect Bluetooth](#)
- [4 Adjust The Backlight Brightness](#)
- [5 The Keychron Launcher App](#)
- [6 The Layers](#)
- [7 Factory Reset & Firmware Update](#)
- [8 Documents / Resources](#)
 - [8.1 References](#)
- [9 Related Posts](#)



Keychron Q3 HE Wireless Custom Keyboard




Connect 2.4 GHz Receiver



Connect the 2.4 GHz receiver to the device USB port.




Switch toggle to 2.4 GHz mode




G = 2.4 GHz




Note: For the best wireless experience, we recommend using the extension adapter for receiver and putting the 2.4 GHz receiver somewhere on your desk close to your keyboard for a low rate of latency and fewer signal interferences.




Connect Bluetooth



Switch toggle to Bluetooth




Press fn + 1 (for 4 seconds) and pair with device named Keychron Q3 HE




fn + 1

Connect Cable




Switch To The Right System

Please make sure the system toggle on the top left corner has been switched to the same system as your computer's operating system.




The Backlight

Press fn + Q to change the lighting effect



fn + Q


Press fn + tab to turn the backlight on/off



fn + tab


Adjust The Backlight Brightness

Press fn + W to increase the backlight brightness



fn + W

Press fn + S to decrease the backlight brightness



fn + S

Warranty

The keyboard is highly customizable and easy to be rebuilt. If anything goes wrong with any of the keyboard components of keyboard during the warranty period, we will only replace the defective parts of the keyboard, not the whole keyboard.

The Keychron Launcher App

Please visit launcher.keychron.com to use the online Launcher web app to remap the keys, create macro commands, or flash the firmware. If the Launcher cannot recognize your keyboard, please reach our support to get the instructions.



- The online Launcher can only run on the latest version of Chrome, Edge, and Opera browsers.
- The Launcher only works when the keyboard is connected by wire to the computer.

The Layers


- There are four layers of key settings on the keyboard. The layer 0 and layer 1 are for the Mac system. The layer 2 and layer 3 are for the Windows system.
- If your system toggle is switched to Mac, then the layer 0 will be activated.



- If your system toggle is switched to Windows, then the layer 2 will be activated. Remember that if you are using it in Windows mode, please make changes to the layer 2 instead of the top layer (the layer 0). This is a common mistake people are making.



Factory Reset & Firmware Update



fn + J + Z

Troubleshooting? Don't know what's going on with the keyboard?

Factory reset your keyboard

1. Power on your keyboard.
2. Press and hold fn + J + Z (for 4 seconds). The keyboard backlight will flash in red quickly for 3 seconds, indicating that the keyboard has been reset.

Flash your keyboard firmware

1. Visit launcher.keychron.com to open the online Launcher web app.
2. Ensure the keyboard is in Cable or Wired mode and plug in the power cable.
3. Find the 'Firmware Update' tab on the left side of the Launcher and connect your keyboard with it.
4. Follow the instructions on the Launcher and complete the firmware update.

*Step-by-step guide, search the keyword "firmware" on keychron.com.

Documents / Resources



[Keychron Q3 HE Wireless Custom Keyboard](#) [pdf] Installation Guide
Q3 HE Wireless Custom Keyboard, Q3 HE, Wireless Custom Keyboard, Custom Keyboard, Keyboard

References

- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.