



# Keychron V7 Keyboard User Guide

[Home](#) » [Keychron](#) » Keychron V7 Keyboard User Guide 

## Contents

- [1 Keychron V7 Keyboard](#)
- [2 Quick Start Guide](#)
- [3 The Layers](#)
  - [3.1 Multimedia Key and Function Key](#)
- [4 The Backlight](#)
- [5 Warranty](#)
- [6 Factory Reset](#)
- [7 Documents / Resources](#)
- [8 Related Posts](#)



## Keychron V7 Keyboard




If you are a Windows user, please find the appropriate keycaps in the box, then follow the instructions below to find and replace the following keycaps.

## Quick Start Guide

### 1. Switch To The Right System

Please make sure the system toggle on the top left corner has been switched to the same system as your computer's operating system.



### 2. The VIA Key Remapping Software


Please visit [caniusevia.com](https://caniusevia.com) to download the latest VIA software to remap the keys.

If the VIA software cannot recognize your keyboard, please reach out to our support to get the instruction.


## The Layers

There are five layers of key settings on the keyboard.


- The layer 0 is for the Mac system.
- The layer 1 is for the Windows system.
- The layer 2 is for the Mac Multimedia keys.
- The layer 3 is for the Windows Multimedia keys.
- The layer 4 is for the Function keys.



If your system toggle is switched to Mac, then the layer 0 will be activated.



If your system toggle is switched to Windows, then the layer 1 will be activated.



## Multimedia Key and Function Key


Multimedia keys



Function keys

F1 / F2 / F3 / F4 / F5 / F6 / F7 / F8 / F9 / F10 / F11 / F12

In order to get Multimedia Key, you need to press fn1 and



Key.


In order to get Function Key, you need to press fn2 and




Key.

## The Backlight

Press fn1 + Q to change the lighting effect




Press fn1 + tab to turn the backlight on/off



fn1 + tab


## Adjust The Backlight Brightness

Press fn1 + W to increase the backlight brightness



fn1 + W


Press fn1 + S to decrease the backlight brightness



fn1 + S


## Adjust The Backlight Speed

Press fn1 + T to increase the light effect speed



fn1 + T

Press fn1 + G to decrease the light effect speed



## Warranty


The keyboard is highly customizable and easy to be rebuilt.

If anything goes wrong with any of the keyboard components of keyboard during the warranty period, we will only replace the defective parts of the keyboard, not the whole keyboard.

Watch The Building Tutorial On Our Website

If you are building the keyboard for the first time, we highly recommend you watch the building tutorial video on our website first, then start building the keyboard yourself.

## Factory Reset



Troubleshooting? Don't know what's going on with the keyboard?

1. Plug in the power cable and factory reset the keyboard by pressing fn1+J+z (for 4 seconds).
2. Download the right firmware and QMK Toolbox from our website.
3. Unplug the power cable and remove the space bar keycap to find the reset button on the PCB.
4. Hold the reset key first, then plug in the power cable. Release the reset key, and the keyboard will now enter DFU mode.
5. Flash the firmware with the QMK Toolbox.

Factory reset the keyboard again by pressing fn1 +J +Z (for 4 seconds).

Step by step guide can be found on our website.

Not Happy

[support@keychron.com](mailto:support@keychron.com)

## Documents / Resources



[Keychron V7 Keyboard](#) [pdf] User Guide  
V7 Keyboard, V7, Keyboard