



KHADAS Edge2 Single-Board Computer Debuts with Rockchip User Guide


[Home](#) » [KHADAS](#) » KHADAS Edge2 Single-Board Computer Debuts with Rockchip User Guide 

Contents


- [1 KHADAS Edge2 Single-Board Computer Debuts with Rockchip](#)
- [2 SETUP](#)
- [3 OOwoW Introduction](#)
- [4 Website Introduction](#)
- [5 Data Download Instruction](#)
- [6 interfaces](#)
- [7 Documents / Resources](#)
- [8 Related Posts](#)

KHADAS

KHADAS Edge2 Single-Board Computer Debuts with Rockchip



SETUP



OOwoW Introduction

- Edge2 comes with the OOWOW embedded service.
- Use OOVwoW to install your preferred OS directly from the Cloud.

- 00WoW will start automatically if the device storage is empty.
- Control Edge2 with a display and keyboard, or remotely over WiFi.
- With 00WOW you will always be in control of your Edge2.
- **Activate Oowow:** hold Function and press Reset
- **Activate Hotspot:** press Function after OOWOW starts
- **Network Name:** edge2-xxxxx (last 5 digits of serial no.)
- **Further information:** <https://docs.khadas.com/oowow>

Website Introduction

For more documentation and technical information, you can visit docs.khadas.com.
If you encounter technical issues during development, seek help at forum.khadas.com.
To purchase additional accessories, please visit shop.khadas.com.


Data Download Instruction

Schematics: dl.khadas.com/products/edge2/schematic/
Datasheets: dl.khadas.com/products/edge2/datasheet/
Specification: dl.khadas.com/products/edge2/specs/
2D DXF: dl.khadas.com/products/edge2/dxf/
3D CAD: dl.khadas.com/products/edge2/cad/

After-Sales Service

Please email support@khadas.com if you have any after-sales related questions.

interfaces



To get started, visit docs.khadas.com/edge2



[KHADAS Edge2 Single-Board Computer Debuts with Rockchip](#) [pdf] User Guide
Edge2 Single-Board Computer Debuts with Rockchip, Edge2, Single-Board Computer Debuts
with Rockchip, Single-Board Computer, Board Computer, Computer